



### **Using Your Radio** For charging microTALK radio(s) in desktop charger:



1. Insert radio(s) into desktop charger as shown.

2. Insert the micro-USB cable into jack on back of charger. 3. Plug the cable into USB-compatible power port. If charging light is not **on**, check position of radio, Radio should be upright. The charge indicator light will stay on

as long as the radio is in the charging well, and the light will go off when the charging is complete

Note: To charge a single radio, you can bypass the desktop charger and simply insert the micro-USB's connector directly into the charge jack located on the top of the radio.

The radio will display flashing battery icon while charging. Cobra recommends your radio be turned off while being charged. Non-rechargeable alkaline batteries can also be used in your radio.



Press and hold the Mode/Power button to turn on your radio.
 Press the Channel Up or Channel Down button to select a



Both radios must be tuned to the same channel/privacy code to communicate,

3. Press and hold the Talk button while speaking into the

4.When finished talking, release the Talk button and listen for

## Turning on Your microTALK® Radio



Press and hold the Mode/Power button until you hear a series of audible tones indicating the radio is on. Your microTALK® radio is now in Standby mode, ready to receive transmissions. The radio is normally in Standby mode except when the Talk, Call or Weather buttons are pressed.


### **Battery Status Indicator**

The battery charge status is shown on the display. Four bars indicates fully charged.

### Making Life Easier and Safer

Staying in touch with your family and friends is convenient and easy when using your microTALK® radio. Some of the many uses you will discover include:

Communicating with others while hiking, biking, and working; keeping track of family and friends at a crowded public event; checking with travel companions in another car; talking with neighbors; arranging meeting spots with others while shopping at the mall.



Secure your microTALK® radio while on the ao.

Carrying your microTALK® radio with you is easy when using the belt clip or optional wrist strap. The belt clip easily attaches to your belt, purse, or

## **Customer Assistance**

### **Product Service & Support**

In this user's quide, you should find all the information you need to operate your microTALK® radio. If you require further assistance after reading this guide, Cobra offers the following customer assistance services:

### For Assistance In The U.S.A.

**Battery Low** 

**Auto Battery Save** 

To Select a Channel

For any questions about operating or installing this new Cobra product, PLEASE CONTACT COBRA FIRST... do not return this product to the retail store. The contact information for Cobra will vary depending on the country in which you purchased and uses the product. For the latest contact information, please go to www.cobra.com/support or call 1-800-543-1608.

When battery power is low, the final bar in the

should be replaced or recharged, if using

rechargeable batteries.

incoming transmissions.

pressing the Talk button.

1. Press and hold the Talk button.

Communicating with Another Person

Rattery I ow icon will blink and an audible tone will

sound twice before the radio shuts off. Your batteries

while charging if the radio is on.

If there are no transmissions within 10 seconds, the

radio will automatically switch to Power Save mode

2. With the microphone about two inches (5 cm) from

Both radios must be tuned to the

With the radio on, select any of the 22 channels by

pressing the Channel Up or Channel Down button.

Both radios must be tuned to the

See page 13 for frequency allocations.

same channel to communicate

your mouth, speak in a normal voice.

3. Release the Talk button when you are

You cannot receive incoming calls while

finished talking and listen for a response

and the Power Saver icon will flash in the display.

This will not affect the radio's ability to receive

The radio will display flashing battery icon

If your product should require factory service, please go to www.cobra.com/support and follow the instructions.

> ©2024 Cobra Electronics Corporatio www.cobra.com

> > A-1

## **Product Features**

Introduction

## **12**) 8 **13 14**) **1**)... **(15) (2**) **(6)** (10) **(5)** microTALK **(4**) (9) 1 (3) Φ. (8) 7 (11)

- 1. Antenna
- 2. External Speaker/ Microphone/Charge Jack
- Mode/Power Button
- Weather/Lock Button
- Channel Un/Down Buttons Backlit I CD Display
- Speaker/Microphone

**Listening for a Response** 

To Adjust Volume

֓֞֞֞֞֓֓֓֓֓֓֓֓֓֓֓֓֓֓֓֓֓֓֓֓֓֓֓֡֓

**To Illuminate Display** 

your Maximum Range limit.

maximum range of your radio,

**Auto Squelch/Maximum Range** 

Volume Level

**Call Button** 

- Volume Up/Down Buttons Light/Max Range Button
- 10 Talk Button 11. Call Button

Release the Talk button to receive incoming

buttons are not pressed.

Down button.

(1 through 8).

communications

Press the Volume Up or Volume

the minimum and maximum volume levels

Press and release the Call button.

Light/Max Range Press and release the Light/Max Range button

to illuminate the display.

Your microTALK® radio will automatically mute weak transmissions

You can temporarily turn off auto squelch or turn on maximum range

and unwanted noise due to terrain, conditions or if you've reached

extender, allowing all signals to be received and extending the

The other person will hear a three second call

tone. This tone is used only to establish voice

See page 11 on how to select between five call tone settings.

A double beep sound is used to indicate

transmissions. Your microTALK® radio is normally

in Standby mode while the Talk, Call or Weather

- 12. Wrist Strap Connection 13. Belt Clip
- 14 Battery Compartment
- 15. Battery Door Latch

## A-2

### **Backlit LCD Display**

### Features

- 22 Channels
- 10 Channel NOAA All Hazards Radio
- 121 Privacy Codes (38 CTCSS codes/ 83 DCS codes)
- Hands-Free Operation (VOX)
- Scan Channels, privacy codes
- Backlit LCD Display
- Call Alert Five selectable tones
- Rutton Lock
- Speaker/Microphon · Charge Jack
- Roger Beep Selectable On/Off
- Battery/Power Saver
- Keystroke Tones
- Battery Level Indicator
- Auto Squelch
- Maximum Range Extender
- Belt Clip

## **(1)** THE Scan Rog \ A (6)**(9**) (8) Power Saver (13) 7 (12) (10) (11)

- 1. Battery Level Indicator
- 2 VOX Icon
- 3 Scan Icon
- 4. Roger Beep Icon
- Lock Icon
- 6. Low Power Icon 7. DCS/CTCSS Icons
- 8 Weather Icon
- 9. Weather Alert Icon
- 10. DCS/CTCSS Privacy Code Numbers
- 11 Power Saver Icon
- 12. Channel Numbers
- 13 Receive/Transmit Icon



Maximum range may vary and is based on unobstructed line-of-sight communication under ideal conditions.

Δ-3

### To temporarily turn off auto squelch:

Press the Light/Max Range button for less than five seconds.

### To turn maximum range extender on:

- Press and hold the Light/Max Range button for at least five seconds until you hear two beeps which indicates the maximum range extender is on.

### To turn maximum range extender off:

- Press and release the Light/Max Range button or change channels.

### **Lock Function**



The Lock function locks the **Channel Up, Channel** Down, Weather and Mode/Power to prevent accidental operation.

### To turn the lock on or off:



- Press and hold the Lock button for two seconds.

A double beep sound is used to confirm your lock on or off request, When in Lock mode. the Lock icon will be displayed.

## microTALK® Range

Your range will vary depending on terrain and conditions.



In flat, open country your radio will operate at maximum range. Buildings and foliage in the path of the

> signal can reduce the range of the radio. Dense foliage and hilly terrain will further reduce the range of the radio.

On Channels 8 through 14, your radio automatically switches to low power, which will limit the range the radio can communicate.



range by using maximum range extender. See page 4 for details.

### 1. Remove belt clip by releasing belt clip latch and sliding clip up. 2. Pull up on the battery door latch to remove the battery compartment cover. Pull Up Lock Latch


Caring for Your microTALK® Radio

Your microTALK® radio will give you years of trouble-free service

if cared for properly. Handle the radio gently. Keep the radio away from

dust. Never put the radio in water or in a damp place. Avoid exposure to

To install or replace batteries:






extreme temperatures

**Installing Batteries** 

4. Replace battery compartment cover and helt clin

. Do not attempt to charge alkaline batteries.



• Do not mix alkaline, standard (carbon-zinc), or rechargeable (Ni-Cd. Ni-MH, etc.) batteries.



### To charge batteries in radio:

- 1. Check to see that the batteries have been inserted properly.
- 2. Insert the cable into the charge jack located at the top of the radio.
- 3. Plug the cable into USB-compatible power port.

Use only the supplied rechargeable batteries and charger for recharging vour Cobra microTALK® radio.

Cobra recommends your radio is turned off while being charged. Non-rechargeable alkaline batteries can also be used in your radio.

# **Mode Functions**

## **Scrolling Through the Mode Function**

By scrolling through the Mode function, you will be able to select or turn on preferred features of your microTALK® radio. When scrolling through the **Mode** function, your radio features will be displayed in the same predetermined order:



Set CTCSS Privacy Codes
Set DCS Privacy Codes
Set Vox On/Off
Set Vox Sensitivity

Set Channel Scan Set CTCSS Privacy Code Scan Set DCS Privacy Code Scan

Set Call Tones

Set Roger Beep On/Off

### **Privacy Codes**

Your microTALK® radio incorporates two advanced coded squelch systems that can help to reduce interference from other users on any given channel, CTCSS (Continuous Tone Coded Squelch System) provides 38 privacy codes and DCS (Digitally Coded Squelch) provides 83 privacy codes. This provides a total of 121 Privacy Codes. Either system can be used on all channels, but both systems cannot be used on the same channel at the same time.



To successfully communicate using a privacy code, both the transmitting and receiving radios must be tuned to the same channel and to the same privacy code system (CTCSS or DCS) and privacy code number. Each channel will remember the last privacy code system and number you select.



The privacy code 00 is not a privacy code, but allows all signals to be heard on a channel that is set to 00 on both the CTCSS and DCS systems.

Mode Functions (continued on back side)

## Mode Functions (continued)

### **Set CTCSS Privacy Codes**



## 1. After selecting a channel press

## the Mode/Power button until the CTCSS icon

# appears and the small numbers next to the



- If DCS is turned on at the channel selected, the display will flash the CTCSS icon and "OFF." To switch from DCS to CTCSS, press the Channel Up or Channel Down button while the display is flashing "OFF." The display will then show the small numbers flashing and you will then be able to proceed to step 2.
- 2. Press using the Channel Up or Channel Down button to select a privacy code. You can hold the **Up** or **Down** button for fast advance.
- 3. When your desired CTCSS privacy code is displayed, choose one of the
- a. Press the Mode/Power button to enter the new setting and proceed to other functions
- b. Press the Lock button to return to Standby mode.

NOAA\* All Hazards Radio Channels

channels transmitting in your area.

Weather (WX) Alert Mode

This feature is set to **OFF** by default.

CTESS

You can use your microTALK® radio to listen to NOAA All Hazards Radio

1. Press the Weather/Lock button once, the

All Hazards Radio channel are displayed.

button to change All Hazards Radio channels,

be displayed when All Hazards Radio is on

I. To exit All Hazards Radio, press and hold the

Make sure the strongest

for your area using the NOAA

selection in the previous menu.

All Hazards Radio Channels

Weather channel is selected

3. The All Hazards Radio icon will continue to

National Oceanographic and Atmospheric Administration

All Hazards Radio icon and the currently selected

Weather Button To listen to All Hazards Radio channels:

Hazards Radio Icon 2. Use the Channel Up or Channel Down

Weather button.

Turning On the Weather Alert function will allow your radio to

to Weather and other emergency alerts broadcast by NOAA.

automatically receive NOAA Hazard Alert radio signals and warnings from

designated NOAA broadcast stations. If the radio is turned ON, it will alert

To turn Weather Alert On or Off:

to turn Weather Alert On or Off.

1. Press the Weather/Lock button twice until the

2 Press the Channel IIn and Channel Down button

3. Press and hold the Weather/Lock button again to

Weather Alert icon flashes on the display.


The current **On** or **Off** setting is displayed.

c. Do not press any buttons for 15 seconds to return to **Standby** mode.


### **Set DCS Privacy Codes**



## ■ To select a DCS privacy code: 1. After selecting a channel, press the Mode/Power







- 2. Press using the Channel Up or Channel Down button to select a DCS privacy code. You can hold the Up or Down button for fast advance.
- 3. When DCS privacy code is displayed, choose one of the following:
  - a. Press the Mode/Power button to enter the new setting and proceed to other functions.
  - b. Press the Lock button to return to Standby mode.
  - c. Do not press any buttons for 15 seconds to enter the new settings and to return to Standby mode.

### **Voice Activated Transmit (VOX)**

In VOX mode, your microTALK® radio can be used "hands-free," automatically. transmitting when you speak. You can set the VOX sensitivity level to fit the volume of your voice and avoid transmissions triggered by background noise.







Operation

Frequency Allocation

B = Frequency in MHz

C = Power Output

2

6

8

10

12

14

16

18

20

22

IMPORTANT NOTICE:

**General Specifications** 

A = Channel No. for 22 Channel Models

462.6125

462,6625

462.6875

462 7125

467 5625

467.6125

467 6625

467,7125

462.5750

462,6250

462 6500

462.6750

462 7000

462.7250

WARNING: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

conditions: 1) This device may not cause harmful interference, and 2) this device must

This device complies with part 15 of the FCC Rules. Operation is subject to the following two

accept any interference received, including interference that may cause undesired operation.

equipment generates, uses and can radiate radio frequency energy and, if not installed and

However, there is no guarantee that interference will not occur in a particular installation. If

this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct

NOTE: This equipment has been tested and found to comply with the limits for a Class B

digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide

reasonable protection against harmful interference in a residential installation. This

used in accordance with the instructions, may cause harmful interference to radio

the interference by one or more of the following measures

· Reorient or relocate the receiving antenna.

■ To turn VOX mode on or off:

- 1. Press the Mode/Power button until the VOX icon flashes on the display. The current On or Off setting is displayed.
- 2. Press the Channel Up or Channel Down button to turn VOX On or Off.

3. Choose one of the following:

- a. Press the Mode/Power button to enter the new setting and proceed to other functions.
- b. Press the Lock button to return to Standby mode.

Low

I ow

Low

High

High

High

High


13

### To set VOX sensitivity:

I. Press the Mode/Power button until the VOX icon flashes and the current sensitivity level is displayed.



displayed with letters "L" and a Number 1 through 5, with Number 5 being the most sensitive level and Number 1 being the



- 3. Choose one of the following:
- a, Press the Mode/Power button to enter the selected setting and proceed to other functions.
- b. Press the Lock button to return to Standby mode.

### **Channel Scan**

Your microTALK® radio can automatically scan channels. To scan channels:



Scan Channels

- 1. Press the Mode/Power button until the Scan icon and the channel numbers appear on the display.
- 2. Press the Channel Up or Channel Down button to begin scanning channels.



The radio ignores specific privacy codes while scapping characters.



The Scan icon will continue to be displayed when scan is **on**. Your radio will continue to scan all channels and stop if an incoming transmission is detected. Your radio will remain on that channel for 5 seconds after the last incoming transmission.

### During scanning (while receiving an incoming transmission), you can choose from the following:

- a. Press and hold the Talk button to communicate on that channel. Your radio will remain on that channel and return to Standby mode.
- b. Press the Channel Up or Channel Down button to resume scanning channels.
- c. Press the Lock button to return to Standby.
- . Connect the equipment into an outlet on a circuit different from that to which the receiver
- . Consult the dealer or an experienced radio/TV technician for help

### Safety Information for microTALK Radios

Your wireless handheld portable transceiver contains a low power transmitter. When the talk button is pushed, it sends out radio frequency (RF) signals. The device is authorized to operate at a duty factor not to exceed 50%. In August 1996, the Federal Communications Commi (FCC) adopted RF exposure guidelines with safety levels for handheld wireless devices.

ECC RF Exposure Requirements: For body-worn operation, this radio has been tested and meets the FCC RF exposure guidelines when used with Cobra accessories supplied or designated for this product. Use of other accessories may not ensure compliance with FCC RF exposure guidelines. Use only the supplied antenna. Unauthorized antennas, modifications or attachments could damage the transmitter and may violate FCC regulations.

### Normal Position:

Hold the transmitter approximately two (2) inches from your face and speak in a normal voice, with the antenna pointed up and away.

### FCC Part 15.21 Warning Statement-

NOTE: THE GRANTEE IS NOT RESPONSIBLE FOR ANY CHANGES OR MODIFICATIONS NOT EXPRESSLY APPROVED BY THE PARTY RESPONSIBLE FOR COMPLIANCE. SUCH MODIFICATIONS COULD VOID THE USER'S AUTHORITY TO OPERATE THE EQUIPMENT

### IC RSS-GEN

This device complies with Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions

- (1) this device may not cause interference, and
- (2) this device must accept any interference, including interference that may cause undesired operation of the device. Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils
- radio excempts de licence. L;exploitation est autorisée aux deux condtions suivantes: (1) l'appariel ne doit pas produire de brouillage, et
- (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

### Radiation Exposure Statement:

Under ISEDC regulations, this radio transmitter may only operate using the antenna that is affixed to the radio transmitter. Use only the supplied antenna. Unauthorized antennas, modifications, or attachments could damage the transmitter and may void the user's authority to operate the radio.

Any changes of modifications not expressly approved by the party responsible for compliance could void the user's ability to operate the equipment.

SAR tests are conducted using standard operating positions accepted by the FCC/ISEDC with the device transmitting at its highest certified power level in all tested frequency bands. Although the SAR is determined at the highest certified power level, the actual SAR level of the device while operating can be well below the maximum value.

This device has been tested and certified to not exceed the exposure limit established by the FCC/ISEDC. Tests for each device are performed in positions and locations (e.g. at the ea and worn on the body) as required by the FCC/ISEDC.

For body worn operation, this device has been tested and meets the FCC/ISEDC RF exposure guidelines when used with an accessory designated for this product or when used with an accessory that contains no metal and that positions the handset a minimum of 10mm from the body. Non-compliance with the above restrictions may result in a violation of RF

Privacy Code Scan

Your microTALK® radio can automatically scan the Privacy Codes (either CTCSS 01 through 38 or DCS 01 through 83) within one channel. Only one set of privacy codes (CTCSS or DCS) can be scanned at a time.



### ect Channel To scan privacy codes:

1. While in Standby mode, press the Channel Up or Channel Down button to choose the channel on which you wish to scan privacy codes,

2. Press the Mode/Power button until either the

CTCSS or the DCS icon appears on the display

and the Scan icon and the privacy code numbers



flash on the display 3. Press the Channel Up or Channel Down button to begin scanning privacy codes within the



channel you selected.

### During scanning (while receiving an incoming transmission), you can choose from the following:


- a, Press and hold the Talk button to communicate on that channel/ privacy code. Your radio will remain on that channel/privacy code. and return to Standby mode.
- b. Press the Channel Up or Channel Down button to resume scanning privacy codes. If you do not press any button within 5 seconds after the last incoming transmission, your radio will automatically resume scanning.
- c. Press the Lock button to return to Standby.


### **Five Call Tone Settings**

You can choose between five different Call Tone Settings to transmit a call alert To change a call tone setting:



1. Press the Mode/Power button until the letter "C" and the current call tone number (01 through 05) is displayed. The current call tone will sound for one second.








a. Press the Mode/Power button to enter the new setting and proceed to other functions.

b. Press the Lock button to return to Standby

### **Roger Beep Confirmation Tone**

Your listener will hear an audible tone when you release the Talk button. This alerts the other party that you have finished talking and it is OK for them to speak.



1. Press the Mode/Power button until the

Roger Beep icon flashes. The current on or off setting is displayed. 2. Press the Channel Up or Channel Down button



- to select roger beep on or off. 3. Choose one of the following: a. Press the Mode/Power button to return to Standby mode.
- b. Press the Lock button to return to Standby

10

### For Products Purchased Outside the U.S.A. Please contact your authorized local reseller or agent for warranty information

## Trademark Acknowledgment

©2024 Cobra Electronics Corporation. Cobra and the snake design are proprietary trademarks of Cobra Electronics Corporation, USA. Other trademarks and trade names are those of their respective owners

Cobra Electronics Corporation™ is a trademark of Cobra Electronics Corporation, USA.



### **Limited One-Year Warranty**

Cobra warrants your product against all defects in materials and workmanship for a period of one (1) year from the date of original purchase.

Cobra at our sole discretion, will repair or replace your product (with the same or comparable product) free of charge.

received COD will be refused.

Cobra will not pay shipping charges that you incur for sending your product to us. Products

To make a warranty claim, we will require proof or purchase in the form of an invoice or receipt. No proof of purchase is required for factory direct purchases

Warranty Exclusions: Warranty does not apply to your product under any of the following conditions: 1. The serial number has been removed or modified, 2. Your product has been subjected to misuse or damage (including water damage, physical abuse, and/or improper installation). 3. Your product has been modified in any way. 4. Your receipt or proof-of-purchase is from a non-authorized dealer or internet auction site including E-bay, U-bid, or other non-authorized resellers.

LIMITATION OF WARRANTY: EXCEPT AS EXPRESSLY PROVIDED HEREIN, YOU ARE ACQUIRING THE PRODUCT "AS IS" AND "WHERE IS", WITHOUT REPRESENTATION OR WARRANTY. COBRA SPECIFICALLY DISCLAIMS ANY REPRESENTATION OR WARRANTY INCLUDING BUT NOT LIMITED TO THOSE CONCERNING THE MERCHANTABILITY AND SUITABILITY OF THE PRODUCT FOR A PARTICULAR PURPOSE, COBRA SHALL NOT BE LIABLE FOR CONSEQUENTIAL SPECIAL OR INCIDENTAL DAMAGES INCLUDING WITHOUT LIMITATION. DAMAGES ARISING OUT OF THE USE, MISUSE OR MOUNTING OF THE PRODUCT.

The above limitations or exclusions shall be limited to the extent they violate the laws of any particular state. Cobra is not responsible for products lost in shipment between the owner and our service center.

### General Warranty Information

Each product we manufacture is covered by our factory warranty. While each product may have unique components and policy, the general guideline below will apply to most Cobra products.

All Cobra products purchased factory-direct or from our Authorized Resellers will come with a full one to three (1-3) year warranty from the date of the original retail purchase (see policy statement above for full warranty details and exclusions).

Standard accessories packaged with each model will have a one-year factory warranty. Accessory items have a one-year factory warranty.

Shipping to our facility is not covered in our warranty. Return shipping is included within the US. This warranty is non-transferrable

For the sake of clarity, 'repair or replace the Product or its defective part' does not include removal or installation work, costs or expenses which include but are not limited to labor costs or expenses.

Cobra will not be responsible for lost packages.



15

save the new setting and exit the Weather Alert Mode and return to Standby mode.

. Increase the separation between the equipment and receiver. 12

# Mode/Power To select a CTCSS privacy code:



11