

UNIDEN PROGRAMMING CONTROL CODES FOR USE WITH UNIDEN SCANNERS

End User License Agreement **UNIDEN AMERICA CORPORATION**

NOTICE TO USER: THIS END USER LICENSE AGREEMENT ("EULA") IS A LEGAL AGREEMENT BETWEEN YOU AND UNIDEN. PLEASE READ THIS CAREFULLY BEFORE USING THE UNIDEN CODE. BY CLICKING THE "I AGREE TO THE TERMS OF THIS LICENSE AGREEMENT", OR BY USING ALL OR ANY PORTION OF THE UNIDEN CODE, YOU ARE CONFIRMING YOUR ACCEPTANCE OF THE UNIDEN CODE AND ALL THE TERMS AND CONDITIONS OF THIS AGREEMENT. IF YOU DO NOT AGREE, DO NOT USE THE UNIDEN CODE. CLICK THE "I DO NOT AGREE TO THE TERMS OF THIS LICENSE AGREEMENT" FOR THE INSTALLATION PROCESS TO TERMINATE.

1. DEFINITIONS

- (A) "Uniden Code" means Uniden proprietary programming codes and commands used to control Uniden's scanner products.
- (B) "Use" or "Using" means to access, install, download, copy or otherwise benefit from using the functionality of the Uniden Code.
- (C) "Computer" means an electronic device that accepts information in digital or similar form and manipulates it for a specific result based on a sequence of instructions.
- (D) "Uniden" means Uniden America Corporation, a Delaware corporation, located at 4700 Amon Carter Boulevard, Fort Worth, Texas 76155, and its licensors, if any.

2. UNIDEN CODE LICENSE GRANTS

- (A) You may utilize the Uniden Code on an "as is", at-will, royalty-free, personal, non-assignable, non-exclusive basis solely for the purpose of creating software or firmware products intended to extend the functionality of Uniden scanner products, or provide compatibility of Uniden scanner products with a PC or other control devices.
- (B) You agree that the Uniden Code will not be used to create a competing scanner product.

- (C) You agree not to use the Uniden Code functionality for purposes other than to control one or more of the Uniden scanner models to which the codes apply.
- (D) You acknowledge that the Uniden Code is provided “as-is” and that Uniden has no obligation to provide any additional support in the use of the Uniden Code beyond the disclosed documentation.
- (E) User acknowledges that, while reasonable efforts have been taken to ensure accuracy in the supplied documentation, said documents have been subjected to one or more translation stages that might have resulted in unclear, inaccurate, or incomplete information and that Uniden is under no obligation to correct or clarify supplied documentation of the Uniden Code.
- (F) You acknowledge that the Uniden Code is the sole property of Uniden.
- (G) You agree that the Uniden Code, documentation thereof and the related information provided by Uniden are confidential and proprietary information of Uniden (collectively “Uniden Confidential Information”).
- (H) You agree to mark any software containing all or part of the Uniden Code, and the written user materials accompanying units that incorporate Uniden Code with notices indicating, “This product contains Uniden proprietary and/or copyright control codes. Used with permission.”
- (I) You agree that this EULA does not need to be signed for it to take effect.
- (J) You agree to use the Uniden Code in its regular and proper manner.
- (K) You acknowledge that Uniden may update, modify or revise the Uniden Code at any time and shall not be obligated to provide such updates, modifications or revisions to you.
- (L) You acknowledge that the permission granted herein does not constitute endorsement by Uniden of any software or firmware products you may create in accordance with the purpose stated in section A herein; and you are solely responsible for the configuration of said software or firmware and/or any service matters relating to said software or firmware and/or any Uniden Code used with said software or firmware.
- (M) This license is personal to you and you may make copies of the Uniden Code only for your personal use.

- (N) You agree that Uniden may audit your use of the Uniden Code for compliance with these terms at any time.
- (O) You agree and represent that any products you create which incorporate the Uniden Code are in compliance with all applicable laws.
- (P) You shall defend, indemnify and hold harmless Uniden, its subsidiaries and affiliates, and all agents, employees, officers and directors of Uniden, its subsidiaries and affiliates, from all expenses, losses, costs, damages or liability (including reasonable attorneys' fees and court costs and expenses) arising out of or in connection with any claim or action in connection with the use of any products you create which incorporate the Uniden Code.

3. LICENSE RESTRICTIONS

- (A) Other than as set forth in Section 2 of this EULA, you may not make or distribute copies of the Uniden Code, or electronically transfer the Uniden Code from one computer to another or over a network.
- (B) You may not alter, merge, modify, adapt or translate the Uniden Code, or decompile, reverse engineer, disassemble, or otherwise reduce the Uniden Code to a human-perceivable form.
- (C) You may not sell, rent, lease, assign or sublicense the Uniden Code.
- (D) You may not modify the Uniden Code or create derivative works based upon the Uniden Code.
- (E) You may not export the Uniden Code into any country prohibited by the United States Export Administration Act and the regulations thereunder.
- (F) In the event that you fail to comply with this EULA, Uniden may terminate the license and you must destroy all copies of the Uniden Code (with all other rights of both parties and all other provisions of this EULA surviving any such termination).

4. OWNERSHIP

The foregoing license gives you limited license to use the Uniden Code. Uniden retains all right, title and interest, including all copyright and intellectual property rights, in and to, the Uniden Code or any derivative works, including but not limited to the structure and organization of the Uniden Code, and all copies thereof. All rights not specifically granted in this EULA, including Federal and

International Copyrights, are reserved by Uniden. Uniden reserves the right to terminate this license at any time.

5. WARRANTY DISCLAIMER

- (A) THE UNIDEN CODE IS PROVIDED TO YOU ON AN "AS-IS" BASIS. UNIDEN PROVIDES NO TECHNICAL SUPPORT OR WARRANTIES FOR THE UNIDEN CODE.
- (B) UNIDEN AND ITS SUPPLIERS DISCLAIM ALL WARRANTIES AND REPRESENTATIONS (EXPRESS OR IMPLIED WHETHER BY STATUTE, COMMON LAW, CUSTOM, USAGE OR OTHERWISE) INCLUDING THE WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. ALSO, THERE IS NO WARRANTY OF SATISFACTORY QUALITY, INTEGRATION, NON-INFRINGEMENT OF THIRD PARTY RIGHTS AND TITLE OR QUIET ENJOYMENT. UNIDEN DOES NOT WARRANT THAT THE UNIDEN CODE IS ERROR-FREE OR WILL OPERATE WITHOUT INTERRUPTION. NO RIGHTS OR REMEDIES REFERRED TO IN ARTICLE 2A OF THE UCC WILL BE CONFERRED ON YOU UNLESS EXPRESSLY GRANTED HEREIN.
- (C) IF APPLICABLE LAW REQUIRES ANY WARRANTIES WITH RESPECT TO THE UNIDEN CODE, ALL SUCH WARRANTIES ARE LIMITED IN DURATION TO THIRTY (30) DAYS FROM THE DATE OF DELIVERY.
- (D) NO ORAL OR WRITTEN INFORMATION OR ADVICE GIVEN BY UNIDEN, ITS DEALERS, SUPPLIERS, DISTRIBUTORS, AGENTS OR EMPLOYEES SHALL CREATE A WARRANTY OR IN ANY WAY INCREASE THE SCOPE OF ANY WARRANTY PROVIDED HEREIN.

6. LIMITATION OF LIABILITY

- (A) NEITHER UNIDEN NOR ITS SUPPLIERS SHALL BE LIABLE TO YOU OR ANY THIRD PARTY FOR ANY INDIRECT, SPECIAL, INCIDENTAL, PUNITIVE, COVER OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, DAMAGES FOR THE INABILITY TO USE EQUIPMENT OR ACCESS DATA, LOSS OF BUSINESS, LOSS OF PROFITS, BUSINESS INTERRUPTION OR THE LIKE), ARISING OUT OF THE USE OF, OR INABILITY TO USE, THE UNIDEN CODE AND BASED ON ANY THEORY OF LIABILITY INCLUDING BREACH OF CONTRACT, BREACH OF WARRANTY, TORT (INCLUDING NEGLIGENCE), PRODUCT LIABILITY OR OTHERWISE, EVEN IF UNIDEN OR ITS REPRESENTATIVES HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES AND EVEN IF A REMEDY SET

FORTH HEREIN IS FOUND TO HAVE FAILED OF ITS ESSENTIAL PURPOSE.

- (B) UNIDEN'S TOTAL LIABILITY TO YOU FOR ACTUAL DAMAGES FOR ANY CAUSE WHATSOEVER WILL BE LIMITED TO THE GREATER OF \$10 OR THE AMOUNT PAID BY YOU FOR THE UNIDEN CODE THAT CAUSED SUCH DAMAGE.
- (C) THE FOREGOING LIMITATIONS ON LIABILITY ARE INTENDED TO APPLY TO THE WARRANTIES AND DISCLAIMERS ABOVE AND ALL OTHER ASPECTS OF THIS EULA.

7. COMPLIANCE WITH LAWS

Uniden and its affiliates, which offer the Uniden Code to you, are headquartered in the United States. Uniden makes no representation that the Uniden Code is appropriate or legal for use inside or outside the United States. You are responsible for all compliance with your local laws, and use of the Uniden Code where illegal is expressly prohibited.

8. GOVERNING LAW AND VENUE

This EULA shall be interpreted, construed and governed by the laws of the State of Texas, USA, without reference to its laws relating to conflicts of law and not including the provisions of the 1980 United Nations Convention on Contracts for the International Sale of Goods. Venue for all disputes arising under this Agreement shall lie exclusively in the District Courts of the State of Texas in Tarrant County or the Federal District Courts of the Northern District of Texas (as permitted by law) and each party agrees not to contest the personal jurisdiction of these courts. Notwithstanding the foregoing, however, Uniden shall have the right to commence and prosecute any legal or equitable action or proceeding before any non-US court of competent jurisdiction to obtain injunctive or other relief in the event that, in the opinion of Uniden, such action is necessary or desirable.

9. GENERAL PROVISIONS.

This EULA contains the complete agreement between the parties with respect to the subject matter hereof, and supersedes all prior or contemporaneous agreements or understandings, whether oral or written. You agree that any varying or additional terms contained in any purchase order or other written notification or document issued by you in relation to the Uniden Code licensed hereunder shall be of no effect. The failure or delay of Uniden to exercise any of its rights under this EULA or upon any breach of this EULA shall not be deemed a waiver of those rights or of the breach.

If any provision of this EULA shall be held by a court of competent jurisdiction to be contrary to law, that provision will be enforced to the maximum extent permissible, and the remaining provisions of this EULA will remain in full force and effect.

All questions concerning this EULA shall be directed to: Uniden America Corporation, 4700 Amon Carter Boulevard, Fort Worth, Texas 76155.

UNIDEN and other trademarks contained in the Uniden Code are trademarks or registered trademarks of Uniden America Corporation in the United States and/or other countries. You may not remove or alter any trademark, trade names, product names, logo, copyright or other proprietary notices, legends, symbols or labels in the Uniden Code. This EULA does not authorize you to use the UNIDEN name or any of their respective trademarks.

Trademarks and registered trademarks:

All products or service names mentioned in the Uniden Code are trademarks or registered trademarks of Uniden America Corporation.

Copyright © 2003-2004

Uniden America Corporation

ALL RIGHTS RESERVED

1. 1. REMOTE COMMAND (VER1. 02)

【Remote Communication Format】

BPS rate	:2400/4800/9600/19200bps (default :9600bps)
Start/Stop bit	:1bit, 1bit
Data Length	:8bit
Parity Check	:None
Code	:ASCII
Flow Control	:None
Return Code	:Carriage Return only

- *1 In case of controlling with program,
insert waiting time between commands.
- *2 On Bit rate establishment mode, all
commands are invalid.

【FORMAT OF THIS DOCUMENT】

<COMMAND NAME>

Summary explanation of the function of the command

Controller → Radio
Command format
Radio → Controller
Response format

※ Error message isn't described in this document,
but the unit sends error message to the controller as follows.

- | | |
|---------------------------------------|--------------|
| 1) Command format error / Value error | : "ERR<cr>" |
| 2) The command is invalid at the time | : "NG<cr>" |
| 3) Flaming error | : "FER<cr>" |
| 4) Overrun error | : "ORER<cr>" |

※ "<cr>" means "to hit the return key" or "to send the return code".

※ The bank number (1-10) assign to A-J.

※ The list number (1-10) assign to A-J.

<COMMAND AC>

Clear (Initialize) all memory.

Controller \rightarrow Radio

"AC<cr>" ※"<cr>" means "to hit the return key"
or "to send the return code".

Radio → Controller

"OK<cr>" / "NG<cr>"

This command instructs the unit to clear all the memories.

All the memories are set for initial setting

This command is valid at any time.

Note) There needs about 5seconds execute time.

Start from Channel Scanning(start channel:ch1) by initial setting.

<COMMAND AF>

Confirm/Set EDACS ID format change. (AFS[Agency, Fleet, Subfleet] to DECIMAL)

Controller \rightarrow Radio

① "AF<cr>"	: Confirm AFS ID format.
② "AFN<cr>"	: AFS change to DECIMAL ON
"AFF<cr>"	: AFS change to DECIMAL OFF

Radio → Controller

① "AFN<cr>" : AFS change to DECIMAL ON
 "AFF<cr>" : AFS change to DECIMAL OFF
 "NG<cr>"
 ② "OK<cr>"

This command instructs the unit to turn on or confirm AFS ID format.

This command acceptable is at EDACS mode.

<COMMAND AL>

Confirm/Set Auto Light function ON/OFF .

Controller \rightarrow Radio

① "AL<cr>"	: Confirm Frequency Identification function ON/OFF
② "ALN<cr>"	: Auto Light function ON
"ALF<cr>"	: Auto Light function OFF

Radio → Controller

- ① "ALN<cr>" :Auto Light ON / "ALF<cr>" : Auto Light OFF
- ② "OK<cr>"

This command instructs the unit to turn or confirm Auto Light function ON/OFF.

<COMMAND AT>

Confirm/Set ATT function ON/OFF .

Controller → Radio

- ① "AT<cr>" :Confirm ATT function ON/OFF
- ② "ATN<cr>" :ATT ON / "ATF<cr>" :ATT OFF

Radio → Controller

- ① "ATN<cr>" :ATT ON / "ATF<cr>" :ATT OFF
- ② "OK<cr>" / "NG<cr>"

This command instructs the unit to turn or confirm ATT function ON/OFF.

<COMMAND BT>

Confirm/Set S-BIT function ON/OFF .

Controller → Radio

- ① "BT<cr>" :Confirm S-BIT function ON/OFF
- ② "BTN<cr>" :S-BIT ON
- "BTF<cr>" :S-BIT OFF

Radio → Controller

- ① "BTN<cr>" :S-BIT ON
- "BTF<cr>" :S-BIT OFF
- "NG<cr>"
- ② "OK<cr>"
- "NG<cr>"

This command instructs the unit to turn or confirm S-BIT function ON/OFF.

This command is acceptable at MOTOROLA mode.

<COMMAND DL>

Confirm/Set DELAY function ON/OFF.

Controller → Radio

- ① "DL<cr>" :Confirm DELAY function ON/OFF

- ② "DLN<cr>" :delay ON
- "DLF<cr>" : delay OFF

Radio → Controller

- ① "DLN<cr>" : delay ON
- "DLF<cr>" :delay OFF
- "NG<cr>"
- ② "OK<cr>"
- "NG<cr>"

This command instructs the unit to turn or confirm DELAY function ON/OFF.

This command is acceptable at conventional / trunking mode. ただし、scan modeの時は、scan stopしている場合に限る。

<COMMAND DS>

Confirm/Set DATA SKIP function ON/OFF .

Controller → Radio

- ① "DS<cr>" :Confirm DATA SKIP function ON/OFF
- ② "DSN<cr>" :Data skip ON
- "DSF<cr>" :Data skip OFF

Radio → Controller

- ① "DSN<cr>" :Data skip ON
- "DSF<cr>" :Data skip OFF
- "NG<cr>"
- ② "OK<cr>" / "NG<cr>"

This command instructs the unit to turn or confirm DATA SKIP function ON/OFF.

This command is acceptable at conventional mode, except manual mode.

<COMMAND FB>

Program fleet block on scanner.

Controller → Radio

- "FB & # %%<cr>"
- & A-J Identifies the bank for this fleet block.
- # 0-7 Identifies the fleetmap block number.
- %% 00-14 Block size indicator.

Radio → Controller

- "OK<cr>" / "NG<cr>"

This command is acceptable at conventional mode.

<COMMAND FI>

Confirm/Set Frequency Identification function ON/OFF .

Controller → Radio

- ① "FI<cr>" :Confirm Frequency Identification function ON/OFF
- ② "FIN<cr>" :Frequency Identification ON
- "FIF<cr>" :Frequency Identification OFF

Radio → Controller

- ① "FIN<cr>" :ON
- "FIF<cr>" :OFF
- ② "OK<cr>" / "NG<cr>"

This command instructs the unit to turn or confirm Frequency Identification function ON/OFF.

This command is acceptable at conventional / trunking mode.

<COMMAND IC>

Confirm/Move/Program ID memory number.

Controller → Radio

- ① Confirm
- "IC<cr>"
- ② Move ID memory
- "IC @%<cr>" @: ID Scan List
- %: ID Location
- "0" is used to indicate "ID Location 10".

Example:

"IC A0<cr>"

Set ID memory number to "ID Scan List A" and "ID Location 10".

③ Program Talk Group ID

•TYPE 1

"IC @% &##-\$\$<cr>"	@	: ID Scan List
or "IC @% &###-\$<cr>"	%	: ID Location
	&	: Block No.
	##	: Fleet No.
	\$\$: Sub Fleet No.

Example:

"IC A0 001-05<cr>" ID in ID memory "A10" is
"BLOCK=0, FLEET=1, SUB FLEET=5".

•TYPE 2

"IC @% #####<cr>" @ :ID Scan List
% :ID Location
#####:ID

Example:

"IC A0 001234<cr>" ID in ID memory "A10" is "1234".

•EDACS

"IC @% &&-##\$<cr>" @ :ID Scan List
% :ID Location
&& :Agency No.
:Fleet No.
\$:Sub Fleet No.

Example:

"IC A0 01-025<cr>" AFS format

"IC A0 000149<cr>" DECIMAL format

ID in ID memory "A10" is "AGENCY=01, FLEET=02, SUB FLEET=5"

Radio → Controller

①, ②

•TYPE 1

or "IC @% &##-\$\$<cr>" @ :ID Scan List
"IC @% &###-\$<cr>" % :ID Location
& :Block No.
:Fleet No.
\$\$:Sub Fleet No.

Example:

"IC A0 001-05<cr>" ID in ID memory "A10" is

"BLOCK=0, FLEET=1, SUB FLEET=5".

•TYPE 2

"IC @% #####<cr>" @ :ID Scan List
% :ID Location
#####:ID

Example:

"IC A0 001234<cr>" ID in ID memory "A10" is "1234".

•EDACS

"IC @% &&-##\$<cr>" @ :ID Scan List
% :ID Location
&& :Agency No.
:Fleet No.
\$:Sub Fleet No.

Example:

"IC A0 01-025<cr>" ID in ID memory "A10" is

"AGENCY=01, FLEET=02, SUB FLEET=5"

③"OK<cr>" / "NG<cr>"

This command is acceptable at trunking mode.

This command (confirm) is acceptable at ID scan(stop), ID manual mode.

<COMMAND ID>

ON/OFF function which informs when ID reception starts or ends.

Controller → Radio

- ① "ID<cr>" :confirm "ID"command active
- ② "IDN<cr>" : "ID" command ON
- "IDF<cr>" : "ID" command OFF

Radio → Controller

- ① "IDN<cr>" : "ID" command ON
- "IDF<cr>" : "ID" command OFF
- ② "OK<cr>"

While the function is ON,when the ID reception starts or ends ,
the unit sends back as follows:

(1) ID reception starts

·TYPE 1

"ID S &##-\$\$<cr>" & :Block No.
or "ID S &###-\$\$<cr>" ###:Fleet No.
 \$\$\$:Sub Fleet No.

Example:

"ID S 001-03<cr>" ID reception starts on "Block=0,
 FLEET=1, SUB FLEET=3".

·TYPE 2

"ID S @@@@@@<cr>" @@@@@@:ID

Example:

"ID S 001234<cr>" ID reception starts on "ID=1234".

·EDACS

"ID S &&-##\$<cr>" && :Agency No.
 ## :Fleet No.
 \$:Sub Fleet No.

Example:

"ID S 01-025<cr>" AFS format
"ID S 000149<cr>" DECIMAL format

(2) ID reception ends

·TYPE 1

"ID E &##-\$\$<cr>" & :Block No.
"ID E &###-\$<cr>" ## :Fleet No.
 \$\$:Sub Fleet No.

·TYPE 2

"ID E @@@@@@<cr>" @@@@@@:ID

·EDACS

"ID E &&-##\$<cr>" && :Agency No.
 ## :Fleet No.
 \$:Sub Fleet No.

This command instructs the unit to turn the function ON/OFF.
While the function is ON, the unit is monitoring the status of
the ID reception and informs when it starts or ends.
This command is acceptable at conventional / trunking mode.

<COMMAND IL>

Read L/O ID memory.

Register an ID into L/O ID memory.

Delete an ID from L/O ID memory.

Controller → Radio

① Read

"IL###<cr>" ###:lockout memory no(001-100)

② Register

·TYPE 1

"ILR &##-\$\$<cr>" & :Block No.
"ILR &###-\$<cr>" ## :Fleet No.
 \$\$:Sub Fleet No.

·TYPE 2

"ILR @@@@@@<cr>" @@@@@@:ID

·EDACS

"ILR &&-##\$<cr>" && :Agency No.
 ## :Fleet No.
 \$:Sub Fleet No.

③ Delete

·TYPE 1

"ILD &##-\$\$<cr>" & :Block No.
"ILD &###-\$<cr>" ## :Fleet No.
 \$\$:Sub Fleet No.

・TYPE 2

"ILD @@@@<cr>" @@@@: ID

・EDACS

"ILD &-##\$<cr>" && :Agency No.
 ## :Fleet No.
 \$:Sub Fleet No.

Radio → Controller

① Read

(1) TYPE 1

"IL &@-%%<cr>" & :Block No.
 @@:Fleet No.
 %%:Sub Fleet No.

Example: "IL 001-05<cr>"

(2) TYPE 2

"IL @@@@<cr>"

Example: "IL 001234<cr>"

(3) EDACS

"IL &-##\$<cr>" && :Agency No.
 ## :Fleet No.
 \$:Sub Fleet No.

Example: "IL 01-025<cr>" AFS format
 "IL 000149<cr>" DECIMAL format

② Register

If the ID is registered into L/O ID memory, the unit sends "OK<cr>" to the controller.

If the ID is already in L/O ID memory, sends "ON<cr>".

If L/O ID memory is full, sends "FULL<cr>".

③ Delete

If the ID is deleted from L/O ID memory, the unit sends "OK<cr>" to the controller. If the ID isn't in L/O ID memory, sends "OFF<cr>".

This command is acceptable at trunking mode.

注意

READ 時、現在の BANK 以外で LOCKOUT 設定された ID も表示出来る。この ID を削除するには、登録した BANK へ移動する必要がある。

<COMMAND IS>

Confirm/Select ID scan lists.

Controller → Radio

① "IS<cr>" :confirm ID scan list name

② "IS @%O...<cr>" @, %, O, ... :ID scan list name

Example:

"IS ACE<cr>" Select "LIST A, LIST C, LIST E".
(LIST B, LIST D are not selected)

Radio → Controller

①、②

"IS @%O...<cr>" @, %, O, ... :ID scan list name

Example:

"IS ACE<cr>" Selected ID scan lists are "LIST A, C, E".

This command instructs the unit to make designated ID scan lists be selected.

This command is acceptable at trunking mode.

<COMMAND LO>

Confirm/Set LOCKOUT function ON/OFF.

Controller → Radio

① "LO<cr>" :Confirm LOCKOUT function ON/OFF

② "LON<cr>" :lockout ON

"LOF<cr>" :lockout OFF

Radio → Controller

① "LON<cr>" :lockout ON

"LOF<cr>" :lockout OFF

② "OK<cr>" / "NG<cr>"

This command instructs the unit to turn or confirm LOCKOUT function ON/OFF.

This command is acceptable at scan, manual mode.

This command (confirm) is acceptable at manual mode.

<COMMAND LL>

Confirm/Set lower edge frequency of LIMIT SEARCH.

Controller → Radio

① "LL<cr>" :Confirm lower edge frequency

② "LL@@@@@@@@<cr>" @@@@@@@@:Lower edge frequency

The order of the digits is from 1GHz digit to 100Hz digit.

Example:

"LL08510125<cr>" Set the lower edge frequency to "851.0125MHz".

Radio → Controller

① ② "LL@@@@@@@@<cr>"

The current lower edge frequency is @@@@@@@@*100Hz.

This command instructs the unit to set the lower edge frequency of limit search to @@@@@@@@*100Hz or confirm frequency.

This command is acceptable at conventional/trunking mode.

<COMMAND LU>

Confirm/Set upper edge frequency of LIMIT SEARCH.

Controller → Radio

① "LU<cr>" :Confirm upper edge frequency

② "LU@@@@@@@@<cr>" @@@@@@@@:upper edge frequency

The order of the digits is from 1GHz digit to 100Hz digit.

Example:

"LU09560000<cr>" Set the upper edge frequency to "956.0000MHz".

Radio → Controller

① ② "LU@@@@@@@@<cr>"

The current upper edge frequency is @@@@@@@@*100Hz.

This command instructs the unit to set the upper edge frequency to @@@@@@@@*100Hz or confirm frequency.

This command is acceptable at conventional/trunking mode.

<COMMAND LT>

Confirm/Set Back Light ON/OFF .

Controller → Radio

① "LT<cr>" :Confirm Back Light ON/OFF

② "LTN<cr>" :Back Light ON

"LTF<cr>" :Back Light OFF

Radio → Controller

① "LTN<cr>" :Back Light ON / "LTF<cr>" : Back Light OFF

② "OK<cr>" / "NG<cr>"

This command instructs the unit to turn or confirm Back Light ON/OFF.

This command is acceptable at conventional / trunking mode.

<COMMAND MA>

Confirm/Set channel number of MANUAL MODE.

Controller → Radio

① Confirm

"MA<cr>"

② Set

"MA@@@<cr>" @@@:channel number

Example:

"MA015<cr>" Set the channel number to "15".

Radio → Controller

①, ②

"C@@@ F%%%%%%%% T# D# L# A# R# N\$\$ <cr>"

@@@ :channel number

%%%%%%%% :frequency

The order of the frequency digits are from
1GHz digit to 100Hz digit.

: "N" or "F" (ON/OFF)

ex) TN/TF:trunking frequency / conventional frequency

DN/DF:delay on/off

LN/LF:lockout on/off

AN/AF:attenuator on/off (not supported)

RN/RF:auto record function on/off(not supported)

\$\$: "ctcss tone number(not supported)

Example:

"C015 F04060125 TF DN LF AF N00<cr>"

The current channel number is "15",
and its conventional frequency is "406.0125MHz".
Delay function is ON, Lockout is OFF,
Attenuation is OFF
CTCSS is not supported.

This command is acceptable at conventional/trunking mode.

This command (confirm) is acceptable at scan mode (stop), manual mode.

<COMMAND MD>

Confirm the Scanner mode.

Controller → Radio

"MD<cr>"

Radio → Controller

"MD@@<cr>" @@:Current scanner mode number(See following Table)

This command instructs the unit to confirm the current scanner mode .

This command is acceptable at conventional/trunking mode.

Scanner Mode

00:Scan mode
01:Manual mode
02:Limit Search mode
03:Limit Search Hold mode
04:Service Scan mode
05:Service Scan Hold mode
06:Program mode
07:Edacs Program mode
08:System Program mode
09:ID search mode
10:ID search hold mode
11:ID scan mode
12:ID manual mode
13:ID lockout review mode
14:Search control channel mode
15:Edacs ID search mode
16:Edacs ID search hold mode
17:Edacs ID scan mode
18:Edacs ID manual mode
19:Edacs ID lockout review mode
20:Edacs Search control channel mode
21:VFO mode

<COMMAND MU>

Confirm/Set status of speaker muting.

Controller → Radio

- | | |
|---------------|---------------------------------|
| ① "MU<cr>" | :confirm MUTE control mode. |
| ② "MU?<cr>" | :confirm MUTE ON/OFF condition. |
| ③ "MUN<cr>" | :set MUTE ON(by force)mode. |
| "MUF<cr>" | :set MUTE OFF(by force)mode. |
| "MUA<cr>" | :set AUTO MUTE control mode. |
| | |
| ① "MUN<cr>" | :MUTE ON(by force)mode. |
| "MUF<cr>" | :MUTE OFF(by force)mode. |
| "MUA<cr>" | :AUTO MUTE control mode. |
| ② "MU ON<cr>" | :MUTE ON condition. |
| "MU OFF<cr>" | :MUTE OFF condition. |
| ③ "OK<cr>" | |

This command instructs the unit to set or confirm the status of speaker Muting.

This command is acceptable at conventional/trunking mode.

<COMMAND PC>

Confirm/Set priority channel number of a bank.

Controller → Radio

① Confirm

"PC @<cr>" @:bank

Example:

"PC A<cr>" Confirm the priority channel number of "bank A".

② Set

"PC @%%<cr>" @:bank %%%:channel number

Example:

"PC A014<cr>" Set the priority channel number of
"bank A" to "14".

Radio → Controller

①, ②

"PC @%%<cr>" @:bank %%%:channel number

Example:

"PC A014<cr>" The priority channel number of "bank A"
is "14".

This command is acceptable at conventional/trunking mode.

<COMMAND PI>

Confirm/Set Priority Talk ID Memory Location

Controller → Radio

Confirm Priority ID location

① "PI @<cr>" @:ID list number

Example: "PI A<cr>" confirm priority Location of List "A" in current
Trunk Bank

Set Priority ID location

② "PI @#<cr>" @:ID List number
:ID location number

Example:

"PI A1<cr>" set priority to List "A", Location "1"

Radio → Controller

- ① "PI @# %%%<cr>" @:ID List number
 #:ID location number
 %%% :Talk Group ID

Example:

"PI A1 001234<cr>" Priority of List "A" is location"1" ID:001234

- ② "OK<cr>" / "NG<cr>"

This command is acceptable at trunking mode.

<COMMAND PM>

Read/write frequency of a channel.

Controller → Radio

- ① Read

"PM@@@<cr>" @@@:channel number

Example:

"PM014<cr>" Read the frequency of"14CH".

- ② Write

"PM@@@ %%%<cr>" @@@ :channel number
 %%% :frequency

The order of the frequency digits are from 1GHz digit to 100Hz digit.

Example:

"PM014 04060125<cr>" Set the frequency of "14CH" to "406.0125MHz".

Radio → Controller

- ①, ②

"C@@@ F%% T# D# L# A# R# N\$\$ <cr>"

@@@ :channel number
 %%% :frequency

: "N" or "F" (ON/OFF)

ex) TN/TF:trunking / conventional frequency
 DN/DF:delay on/off LN/LF:lockout on/off
 AN/AF:attenuator on/off (not supported)
 RN/RF:auto record function on/off(not supported)
 \$\$: "ctcss tone number (not supported)

Example:

"C015 F04060125 TF DN LF AF N00<cr>"
 CH.No : "CH15",
 Frequency : "406.0125MHz" (conventional)
 Delay : ON
 Lockout : OFF
 Attenuator: OFF (not supported)

Auto Record: OFF (not supported)
CTCSS :00.0HZ. (not supported)

This command is acceptable at conventional/trunking mode.

<COMMAND PR>

Confirm/Set PRIORITY function ON/OFF .

Controller → Radio

- ① "PR<cr>" :confirm priority function on/off
- ② "PRN<cr>" :set priority function
- "PRF<cr>" :priority function OFF

Radio → Controller

- ① "PRN<cr>" priority :ON
- "PRF<cr>" priority :OFF
- ② "OK<cr>" / "NG<cr>"

This command instructs the unit to turn or confirm PRIORITY function ON/OFF.

This command is acceptable at scan, manual, id scan, id manual mode.

<COMMAND QU>

ON/OFF function which informs when squelch condition changes.

Controller → Radio

- ① "QU<cr>" :confirm "QU" command active
- ② "QUN<cr>" : "QU" command ON
- "QUF<cr>" : "QU" command OFF

Radio → Controller

- ① "QUN<cr>" : "QU" command ON
- "QUF<cr>" : "QU" command OFF
- ② "OK<cr>" / "NG<cr>"

While the function is ON, if the squelch condition becomes

- close to open, unit sends "+<cr>" to the controller.
- open to close, unit sends "-<cr>" to the controller.

This command instructs the unit to turn the function ON/OFF.

While the function is ON, the unit is monitoring the squelch condition and informs when it changes.

This command is acceptable at conventional/trunking mode.

<COMMAND RF>

Confirm/Tune the commanded frequency.

Controller → Radio

- ① "RF@@@@@@@@(?)<cr>" @@@@@@@@@: tune frequency

The order of the digits are from 1GHz digit to 100Hz digit.

Example:

"RF04060125<cr>" tuned receiver to 406.0125MHz

if you wish to confirm the tuned frequency for this command response,
a "?" code add after the commanded frequency.

- ② "RF<cr>" :confirm tuned frequency

Radio → Controller

- ① "OK<cr>"/"NG<cr>" or " RF@@@@@@@@<cr>"

- ② "RF@@@@@@@@<cr>"

This command can be instantly tuned to a commanded frequency .

Scanner mode is VFO mode.

This command is acceptable at manual, VFO mode.

<COMMAND RI>

ON/OFF function which informs when priority receiving condition changes.

Controller → Radio

- ① "RI<cr>" :confirm "RI" command active

- ② "RIN<cr>" (ON) / "RIF<cr>" (OFF)

Radio → Controller

- ① "RIN<cr>" (ON) / "RIF<cr>" (OFF)

- ② "OK<cr>"

While the function is ON,

- if the unit stops on the priority channel by priority receiving, sends "PST<cr>" to the controller.
- if the unit returns from the priority channel, sends "PRT<cr>" to the controller.

This command instructs the unit to turn the function ON/OFF.

While the function is ON, the unit is monitoring the priority receiving condition and informs when it changes.

This command is acceptable at conventional/trunking mode.

<COMMAND RM>

Confirm Receiver modulation .

Controller → Radio

"RM<cr>"

Radio → Controller

"RM @@@<cr>" @@@:Current Receiver modulation

ex) "RM AM<cr>" AM

"RM NFM<cr>" narrow band FM

"RM WFM<cr>" wide band FM(not supported)

This command instructs the unit to confirm receiver modulation.

This command is acceptable at conventional/trunking mode.

<COMMAND RG>

Confirm /Set EDACS ID Range mode.

Controller → Radio

Confirm ID Range mode

① "RG<cr>"

Set ID Range mode

② "RG @@@<cr>" @@@:Edacs id (Agency)

"RG @@@@<cr>" @@@@:Edacs id (Agency, Fleet)

Example: "RG 01-<cr>" or "RG 01-01<cr>"

Radio → Controller

① "RGN<cr>" : Range mode ON

"RGF<cr>" : Range mode OFF

② "OK<cr>" / "NG<cr>"

This command is acceptable at conventional / trunking mode.

This command (confirm) is acceptable at EDACS mode.

<COMMAND SB>

Confirm/Select scan banks.

Controller → Radio

① "SB<cr>" :confirm scan banks

② "SB @%O...<cr>" @, %, O, ... :bank name

Example:

"SB ACEGI<cr>" Select "BANK A, C, E, G, I".

Radio → Controller

①、② "SB @%O...<cr>" @, %, O, ... :bank name

Example:

"SB ACEGI<cr>" Selected scan banks are "BANK A, C, E, G, I".

This command instructs the unit to make designated scan banks be selected.

This command is acceptable at conventional / trunking mode.

<COMMAND SI>

Confirm Scanner Information

Controller → Radio

"SI<cr>"

Radio → Controller

"SI @@@@@@@@, %%%%%%%%%%, &&&&<cr>"

@@@@@@@@ :Alphanumeric model name/number.

%%%%%%%%%% :Alphanumeric ESN number.

&&& :Remote Command Version.

Example:

SI BC245XLT, 1000000001, 102

This is the information string sent by the scanner to PC

This command is acceptable at conventional / trunking mode.

<COMMAND SQ>

Confirm squelch condition.

Controller → Radio

"SQ<cr>"

Radio → Controller

"<+><cr>" : Now squelch is OPEN.

"<-><cr>" : Now squelch is CLOSE.

This command instructs the unit to send whether the squelch is OPEN or CLOSE.

This command is acceptable at conventional / trunking mode.

<COMMAND SS>

Read a frequency in search skip memory.

Register a frequency into search skip memory.

Controller → Radio

① Read

"SS##" ##:search skip memory number (01-50)

② Register

"SS@@@@@@@@<cr>" @@@@@@@@:frequency

The order of the digits are from 1GHz digit to 100Hz digit.

Example:

"SS04060125<cr>" Register 406.0125MHz into search skip memory.

Radio → Controller

① Read

"SS@@@@@@@@<cr>"

Example:

"SS04060125<cr>"

Frequencies in search skip memory are "406.0125MHz"

② Register

"SS@@@@@@@@<cr>" @@@@@@@@:frequency

Example:

"SS04060125<cr>" 406.0125MHz is registered.

※ If the frequency is already in search skip memory,
the unit sends "ON<cr>" to the controller.

This command instructs the unit

①to send a frequencies in search skip memory.

②to register a frequency into search skip memory.

<COMMAND TB>

Confirm Active Trunking bank

Controller → Radio

"TB<cr>"

Radio → Controller

"TB # @@@@<cr>"

#: Active Trunking Bank

@@@: Trunking Type

E2-800 (Motorola Type2 800MHz)

E2-900 (Motorola Type2 900MHz)

E2-VHI (Motorola Type2 VHI)

E2-UHF (Motorola Type2 UHF)

TYPE1 (Motorola Type1)

EDACS (EDACS)

Example: "TB A E2-800<cr>"

Active Bank: "A" Trunk Type: MOTOROLA TYPE2 800MHz

"NG<cr>"

This command is acceptable at trunking mode.

<COMMAND TD>

Confirm/Set Tone Detection function ON/OFF .

Controller → Radio

- ① "TD<cr>" :Confirm Tone Detection function ON/OFF
- "TDN<cr>" :Tone Detection function ON
- "TDF<cr>" :Tone Detection function OFF

Radio → Controller

- ① "TDN<cr>" :Tone Detection function ON
- "TDF<cr>" :Tone Detection function OFF
- ② "OK<cr>" / "NG<cr>"

This command instructs the unit to turn or confirm Tone Detection function ON/OFF.

This command is acceptable at conventional/trunking mode.

<COMMAND TG>

Program Talk Group ID

Controller → Radio

·TYPE 1

"TG * @% &##-\$\$<cr>"	*	:Bank No
or "TG * @% &###-\$<cr>"	@	:ID Scan List
	%	:ID Location
	&	:Block No.
	##	:Fleet No.
	\$\$:Sub Fleet No.

Example:

"TG A A0 001-05<cr>" "ID in ID memory "A10" of BANK A is
"BLOCK=0, FLEET=1, SUB FLEET=5".

·TYPE 2

"TG * @% #####<cr>"	@	:ID Scan List
	%	:ID Location
	#####	:ID

Example:

"TG A A0 001234<cr>"
ID in ID memory "A10" of BANK A is "1234".

-EDACS "TG * @% &&-##\$<cr>" * :Bank No
@ :ID Scan List
% :ID Location
&& :Agency No.
:Fleet No.
\$:Sub Fleet No.

Example:

"TG A A0 01-025<cr>" AFS format
"TG A A0 000149<cr>" DECIMAL format
ID in ID memory "A10" of BANK "A" is
"AGENCY=01, FLEET=02, SUB FLEET=5"

Radio → Controller

"OK<cr>" / "NG<cr>"

This command is acceptable at conventional mode.

<COMMAND TR>

Set Trunking on a bank of channels.

Controller → Radio

"TR & # %%%%%%%%%% \$\$\$\$<cr>"
& A-J For bank selection.
1,2,3,4,5,6 Trunking type (Motorola and Edcas).
1:Type1, 2:Type2-800, 3:Type2-900, 4:Type2-UHF,
5:Type2-VHF 6:EDACS
%%%%%%%%%%%%
Base frequency (Motorola UHF/VHF band only).
\$\$\$\$
Offset step (Motorola UHF/VHF band only).
VHF:0005*n(1-20), UHF:0125*n(1-8)

Radio → Controller

"OK<cr>" / "NG<cr>"

This command is acceptable at conventional mode.

<COMMAND VR>

Confirm the version of Model version no.

Controller → Radio

"VR<cr>"

Radio → Controller

"VR@ .@@<cr>" @ .@@ : The version of CPU

Example:

"VR1.01<cr>" The version of Model is 1.01 .

This command is acceptable at conventional/trunking mode.

<COMMAND WI>

Read the window voltage.

Controller → Radio

"WI<cr>"

Radio → Controller

"W@@@ F%%%%%%%%<cr>" @@@ :window voltage
%%%%%%%% :frequency

Window voltage ranges from a minimum value of "000" to a maximum value of "255". The order of the frequency digits are from 1GHz digit to 100Hz digit.

Example:

"W155 F04060125<cr>" Window voltage is "155", and its frequency is "406.0125MHz".

This command instructs the unit to send the current window voltage and its frequency.

This command is acceptable at conventional/trunking mode.

<COMMAND KEY>

Work as if a key were pushed.

Controller → Radio

"KEY○○<cr>" ○○:KEY Emulate Code (see Following Table)

* To indicate "Hold Press" of each key, add "H" to each command.

Example:

"KEY06H<cr>"

This command is used instead of hold press of "[L/0]" key.

"KEY02 6<cr>"

This command is used instead of press of "[6]" key.

Radio → Controller

"OK<cr>"

- * When use [REMOTE] key, no response from the unit because this key makes the unit be out of REMOTE MODE. These commands instruct the unit to be have as if a key on the scanner's front panel were pushed.
- * This command is acceptable at conventional/trunking mode.
- * キーが無効の場合でも、応答はOKとなる。

Key Emulate Code:

KEY00 [SCAN]
KEY01 [MAN]
KEY02 [0]–[9]
KEY03 [·/ATT]
KEY04 [E/REMOTE]
KEY05 [PRI/TURBO]
KEY06 [L/O]
KEY07 [HOLD/△]
KEY08 [LIMIT/▽]
KEY09 [SRCH]
KEY10 [SVC]
KEY11 [DATA]
KEY12 [DLY/KEYLOCK]
KEY13 [TRNK]
KEY14 [LIGHT]