

Cobra Programming Software Home Screen

Connected Devices (1)

Performa 400
 O/N: RD1K24-00072
 Firmware Version: 1.3.5.19
 Profile: 1 - Default Settings
 Frequency Range: 450.0000 - 470.0000 MHz
 Maximum Channels: 2

Profiles

Index	Number	Name	Radio Model	Description	Last Updated
1	41	Warehouse Team	Performa 400	Team stocking inventory, audio settings on	11/26/2024
2	22	Front Desk	Performa 400	Customer facing, VtrAlert, audio alerts off	11/26/2024
3	1	Managers	Performa 400	Manager team, access to all settings	11/26/2024

- 1 Use the programming cable to plug radio into computer. After opening the CPS, your device(s) will display, along with associated details: firmware version, serial number, and the profile currently saved to the radio.
- 2 Select "Read Radio" to view the existing settings saved to the radio. After reading the radio, you will also have the option to change these settings if desired.
- 3 Profiles are saved files that include every setting currently programmed to the radio, including frequencies and privacy codes. These profiles are saved locally, and can be exported to be downloaded or emailed. A User can save up to 99 Profiles within the software for future use. A radio does not need to be currently connected to create or edit profiles.
- 4 Clicking on the three dots allows you to edit a profile (edit the radio settings stored in the profile), download a report (download a PDF of all the settings in this profile) or export a profile (download a file that can then be saved, emailed, sent to someone else). If a radio is connected, you can also write a profile to the device(s) you have currently connected.
- 5 Allows you to edit the display properties of the profile (number, name, description)

Create Profile

Create a New Profile

New Profile

Import from File

- 6 Select "New Profile" to set up a profile to save to your computer. "Import from File" allows you to select a profile currently saved on your computer. This profile can be one created by you or another user, emailed to you, or can be a custom frequency profile supplied by customer service. Your device does not need to be connected to create or edit profiles.

Read a Radio

Radio Details

Performa 400
 S/N: KD1K24100072

Firmware Version: 1.0.0.19
 Profile: 1 - Default Settings
 Frequency Range: 450.0000 - 470.0000 MHz
 Maximum Channels: 2

Radio Settings

Channels Information | General Settings | User Controls | Previous & Save

☐ Include Repeater Information

The Repeater functionality is turned off. The Transmit Frequency and Privacy Code corresponds to receive Frequency and Privacy Code. Turn this on if you want to see the Transmit Data and Repeater and modify it.

Index	Name	RX Frequency MHz	RX Privacy Code Hz / Number	Scan List	Transmit Power
1	Channel 1	2 - 464.5000	1 - 67 Hz CTCSS	<input type="checkbox"/>	Low High
2	Channel 2	8 - 467.9250	1 - 67 Hz CTCSS	<input type="checkbox"/>	Low High

Back Next

7 Includes the information for frequencies currently programmed into the radio's channel selection

8 Select "Write to Radio" to commit your changes to the connected radio

Editing a Channel

1 Channel 1 2 - 464.5000 1 - 67 Hz
CTCSS Low High

2 Channel 2 8 - 467.9250 1 - 67 Hz
CTCSS Low High

Back Next

9 Edit channel properties, including frequency and privacy code

General Settings

Radio Settings

Write to Radio

Channels Information

General Settings

User Controls

Preview & Save

General

Audio and Sounds

Voice Call / Announcement RX Enable

Voice Call / Announcement RX Frequency

Voice Call / Announcement RX Privacy Code

Voice Call / Announcement TX Enable

Voice Call / Announcement TX Frequency

Voice Call / Announcement TX Privacy Code

Voice Call / Announcement TX Power

Time out Timer
up to 300 seconds

Profile Announcement

Discard

Back

Next

10 Includes device settings like privacy codes, channel preferences, and features.

Radio Settings

Write to Radio

Channels Information

General Settings

User Controls

Preview & Save

General

Audio and Sounds

VoiceAlert

Call Tones

Call Tone Setting

VOX Level

Keyboard Beep

Voice Prompt Language

Roger Beep

Emergency Alert

Microphone Sensitivity

Discard

Back

Next

11 Change audio settings, VOX sensitivity levels, and toggle keyboard and roger tones.

User Controls

Channels Information

General Settings

User Controls ¹²

VOX

VOX Level

Keyboard Beep

VibraAlert

Emergency Alert

Voice Prompt Language

Roger Beep

Voice/Call Announcements

Call Tones

Call Tones Setting

Scan

Radio users will be able to enable or disable this control on their device

Radio users will not be able to enable or disable this control on their device

Discard

- ¹² Turn the settings on or off in the device menu. If a setting is “ON” (toggled red) the setting/feature will be available on the device. If “OFF” (toggled gray) the setting will NOT show up on the radio menu. A user will need to reprogram via CPS in order to access the setting again from the device.

Preview and Save

Channels Information

General Settings

User Controls

Preview & Save ¹³

Profile Information

Profile Number

41

Profile Name

Warehouse Team

Radio Model

Performa 400

Channels Information

Index	Name	RX Frequency	RX Privacy Code	Scan List	Transmit Power
1	Channel 1	2 - 464.5500	1 - 67 Hz	On	High
2	Channel 2	8 - 467.8250	1 - 67 Hz	On	High

General

Voice Call / Announcement TX Enable

On

Voice Call / Announcement RX Frequency

2 - 464.5500

Voice Call / Announcement RX Privacy Code

142 - 526

Voice Call / Announcement TX Enable

On

Voice Call / Announcement TX Frequency

2 - 464.5500

Voice Call / Announcement TX Privacy Code

142 - 526

Voice Call / Announcement TX Power

High

Time out Timer

120

- ¹³ Previews all the settings you are about to save into the profile and/or the connected device.