


UP & DOWN SWITCH



PIN No.

- #4
- #8
- #1
- #7
- #5
- #2
- #3

TO MIC PLUG

MIC CABLE WIRING  
FOR

ALR-22T, ALR-22HT, ALR-72T, ALD-24T  
DR-110T, DR-410T, DR-510T, DR-570T

| NUMBER | 8 conductor cable | 7 conductor cable |
|--------|-------------------|-------------------|
| 1      | YELLOW            | YELLOW            |
| 2      | RED               | ORANGE            |
| 3      | PURPLE            | WHITE             |
| 4      | GREEN             | GREEN             |
| 5      | WHITE             | RED               |
| 6      | NOT USED (ORANGE) | NOT USED          |
| 7      | SCHIELD (BLACK)   | SCHIELD (BLACK)   |
| 8      | GRAY              | GRAY              |