





## All-In-One Portable Power Station

User Manual

# Packing List




Power Station



User Manual



AC Adapter Charger



DC Cigarette Lighter Adapter




Car Charger



power cord

# Layout

English



	Function	Situation
1	Light Button	<ul style="list-style-type: none"> <li>• Long press the button to turn on / off the flashlight.</li> <li>• When the flashlight turns on, press the button to switch the light mode.</li> </ul>
2	LED Flashlight	<ul style="list-style-type: none"> <li>• Normal, Strobe, SOS and OFF</li> </ul>
3	Heat Dissipation Fan	<ul style="list-style-type: none"> <li>• Built-in fan ensures proper cooling for smooth operation.</li> </ul>
4	Power Button	<ul style="list-style-type: none"> <li>• Press the button to show the remaining battery.</li> <li>• Press the button before using USB, DC, Type-C Outputs to charge other devices.</li> </ul>
5	LCD Display Screen	<ul style="list-style-type: none"> <li>• Show the working and battery status of the power station.</li> </ul>
6	AC Power Button	<ul style="list-style-type: none"> <li>• Press the AC power button before using AC outputs.</li> </ul>
7	AC Output 1	<ul style="list-style-type: none"> <li>• Insert the AC adapter charger into the AC output to charge your devices(110V/220V 300W).</li> </ul>
8	AC Output 2	<ul style="list-style-type: none"> <li>• Insert the AC adapter charger into the AC output to charge your devices(110V/220V 300W).</li> </ul>
9	QC 3.0 USB Output	<ul style="list-style-type: none"> <li>• Charge your phone, tablet, camera, etc. 75% faster than a standard charge.</li> </ul>
10	DC Input	<ul style="list-style-type: none"> <li>• Charge the power station.</li> </ul>
11	Type-C PD 60W Input/Output Port	<ul style="list-style-type: none"> <li>• Charge the power station (Input)</li> <li>• Charge your laptop, phone, tablet, camera, etc. (Output)</li> </ul>
12	USB Output 2	<ul style="list-style-type: none"> <li>• Charge your phone, tablet, camera, etc.</li> </ul>
13	USB Output 3	<ul style="list-style-type: none"> <li>• Charge your phone, tablet, camera, etc.</li> </ul>
14	DC Output	<ul style="list-style-type: none"> <li>• Charge your XIEGU radios, phone, tablet, camera, etc.</li> </ul>

# Specifications

Capacity	80,000mAh 3.7V 296Wh (Bk300) 100,000mAh 3.7V 370Wh (Bk400)
Weight	3.33kg (Bk300) 3.50kg (Bk400)
Dimensions	255*230*136mm
DC Input	15V/2.5A
DC Output	12V-16V /10A
AC Outputs	110V 60Hz 220V 50Hz 300W (350W Surge)
USB Outputs	1 x QC3.0 5V/2.4A, 9V/2A,12V1.5A 2 x USB 5V/2.4A
Type-C PD Input/Output	5V/3A, 9V/3A, 12V/3A, 15V/3A, 20V/3A (60W Max)
Charging Time	Bk300: 8~9h (DC Input 15V/2.5A) 5~5.5h (Type-C Input 60W)  Bk400: 10~11h (DC Input 15V/2.5A) 6~6.5h (Type-C Input 60W)
Battery	Lithium-ion
Operating Temperature	-10°C ~ 40°C
Lifecycles	≥500

# Operation Guide

## Charging Your Power Station

### DC Input:

- Insert the one end of the AC adapter charger into the DC outlet of the power station, insert the other end of the AC adapter charger into the wall outlet. Recommended using the attached AC adapter charger for charging, which is stable and fast.
- Plug the car adapter into the car socket, then connect the DC cable into the power station.

**Type-C Input:** Plug the Type-C cable into power outlets, connect the Type-C cable into the power station.

## Charging Your Smart Phones or Any Other Devices

Bk 300/400, comes with 2 AC outputs, 1 DC output, 1 Type-C output and 3 USB outputs (one is QC 3.0, the rest are normal ports) located at the side of the unit.

**AC Outputs:** Plug the AC adaptor charger into AC Outputs on your Bk300/400, and connect it to your laptop, tablet or other devices you want to charge. Then press the AC BUTTON. You can charge two devices by using AC outputs at the same time.

**Note:** AC outputs can't charge devices more than 300W. The AC outputs will always ON even there is no load. Please turn off the AC power button Manually when not in use.

**Type-C PD 60W Output:** Plug the Type-C cable into the Type-C Output on your Bk300/400, and connect it to your phone, tablet or other devices you want to charge. Then press the POWER BUTTON.

**Note:** Type-C PD 60W output can't charge devices more than 60W. When using Type-C 60W output, recommended that customers use the attached Type-C cable or the Type-C cable that supports 60W.


**USB Outputs:** Plug the USB cable into the USB outputs on your Bk300/400,

and connect it to your phone, tablet or other devices you want to charge. Then press the POWER BUTTON. You can charge three devices by using USB outputs at the same time.

## Flashlight

1. Please press the power button, then long press the Light Button to turn on / off the flashlight.
2. In flashlight mode, press Light Button to switch from 3 light modes (normal, strobe, SOS).

## LCD Display Screen



- When there is no power, the entire icon will flash.
- When charging, the top grid icon will flash according to the current power consumption.
- When fully charged, the entire icon will always be on.
- Each grid icon represents 20% battery.

Battery Icon	1 grid	2 grids	3 grids	4 grids	5 grids
Battery Power	20%	40%	60%	80%	100%



**OUT**

When using AC Outputs, "AC" and "OUT" will always be on.



**OUT**

When using DC Output, "DC" and "OUT" will always be on.



**OUT**

When using USB Outputs, "USB", "2.4A" and "OUT" will always be on.



When using QC3.0 USB Output, “USB”, “5V/9V” and “OUT” will always be on.



When using DC Input, “IN” will always be on.



When using Type-C Input, “Type-C” and “IN” will always be on.



When using Type-C Output, “Type-C” and “OUT” will always be on.



When the internal temperature of the power station exceeds 70°C (158 °F ), this icon will light up, all interfaces will stop power supply. Please wait for the power station to cool down before using.



When the power station breaks down, such as short circuit, overload and so on, this icon will light up. Please use after troubleshooting.

#### Attention:

- Always read all instructions carefully before using your power station.
- AC outputs of Bk300/400 can't charge devices more than 300W.
- Type-C PD 60W output of Bk300/400 can't charge devices more than 60W.
- Power supplies will get hot when in use.
- The AC power button can not turn on while the power station is recharging, the DC output and USB outputs will work.
- Please turn off the AC power button before you start recharging the power station.
- The DC output will auto shut off when there is no load to save power, the AC outputs will always ON even there is no load. Please turn off the AC power button Manually when not in use.
- Be cautions of excessive drops, bumps, abrasions or other impacts to this power station.
- Do not place the unit close to a fire expose it to heat, keep out of direct sunlight.

- Don't submerge your power station in water, or expose it to rain or moisture.
- Never open or disassemble your power station as it will void your warranty.
- Only charge the product at temperatures between  $-10^{\circ}\text{C}$  ~  $40^{\circ}\text{C}$  .
- Keep the power station away from children.
- Don't insert foreign objects into ANY inputs or outputs.
- Don't dispose the unit together with household waste.
- Don't operate the unit above the specified input voltage.
- For protecting this unit, make sure the battery capacity of power station is adequate before use.
- Check the battery of the power station at least every three months, and charge the power station in time.



ポータブル電源

取扱説明書




ポータブル電源



取扱説明書



AC式充電器



DCシガーライターアダプター




車の充電器



電源コード

# スペック



番号	名称	機能
1	ライトボタン	<ul style="list-style-type: none"> <li>・ 懐中電灯のオン / オフを切り替えるには、ボタンを長押しします。</li> <li>・ 懐中電灯が点灯したら、ボタンを押してライトモードを切り替えます。</li> </ul>
2	LED ライト	<ul style="list-style-type: none"> <li>・ 点灯 / SOS / 点滅 / 消灯</li> </ul>
3	放熱ファン	<ul style="list-style-type: none"> <li>・ 内蔵ファンは、スムーズな操作のために適切な冷却を保証します。</li> </ul>
4	電源キー	<ul style="list-style-type: none"> <li>・ ボタンを押して、バッテリー残量を表示します。</li> <li>・ USB、DC、Type-C 出力を使用して他のデバイスを充電する前に、ボタンを押してください。</li> </ul>
5	液晶ディスプレイ画面	<ul style="list-style-type: none"> <li>・ 発電所の稼働状態とバッテリー状態を表示します。</li> </ul>
6	AC 電源ボタン	<ul style="list-style-type: none"> <li>・ AC 出力を使用する前に、AC 電源ボタンを押してください。</li> </ul>
7	AC 出力ポート 1	<ul style="list-style-type: none"> <li>・ AC アダプター充電器を AC 出力に挿入してデバイスを充電します(110V/220V 300W)。</li> </ul>
8	AC 出力ポート 2	<ul style="list-style-type: none"> <li>・ ACアダプター充電器をAC出力に挿入してデバイスを充電します(110V/220V 300W)。</li> </ul>
9	QC 3.0 USB 出力ポート	<ul style="list-style-type: none"> <li>・ スマホ、カメラ、タブレットなどの給電に対応できます。標準料金より 75% 高速です。</li> </ul>
10	DC 入力ポート	<ul style="list-style-type: none"> <li>・ 発電所を充電してください。</li> </ul>
11	Type-C PD 60W 入力 / 出力ポート	<ul style="list-style-type: none"> <li>・ ジャンプスターターやスマホなどに充電できます。</li> </ul>
12	USB 出力ポート 2	<ul style="list-style-type: none"> <li>・ スマホ、カメラ、タブレットなどの給電に対応できます。</li> </ul>
13	USB 出力ポート 3	<ul style="list-style-type: none"> <li>・ スマホ、カメラ、タブレットなどの給電に対応できます。</li> </ul>
14	DC 出力ポート	<ul style="list-style-type: none"> <li>・ あなたのXieguラジオ、電話、タブレット、カメラなどを充電します。</li> </ul>

## 商品特徴

電池容量	80,000mAh 3.7V 296Wh (Bk300) 100,000mAh 3.7V 370Wh (Bk400)
重量	3.33kg (Bk300) 3.50kg (Bk400)
外形寸法	255*230*136mm
DC 入力	15V/2.5A
DC 出力	12V-16V /10A
AC 出力	110V 60Hz 220V 50Hz 300W (350Wピーク)
USB 出力	1 x QC3.0 5V/2.4A, 9V/2A,12V/1.5A 2 x USB 5V/2.4A
Type-C PD 入出力	5V/3A, 9V/3A, 12V/3A, 15V/3A, 20V/3A (60W Max)
充電時間	Bk300: 8~9h (DC入力 15V/2.5A) 5~5.5h (Type-C入力 60W)  Bk400: 10~11h (DC 入力 15V/2.5A) 6~6.5h (Type-C 入力 60W)
電池	リチウムイオン
動作温度	-10°C ~ 40°C
電池循環利用寿命	≥ 500

# 操作ガイド

## 発電所の充電

### DC 入力:

- ・ AC アダプター充電器の一端を発電所の DC コンセントに挿入し、AC アダプター充電器の他端を壁のコンセントに挿入します。付属の AC アダプター充電器を使用して充電することをお勧めします。これは安定して高速です。
- ・ カーアダプターをカーソケットに差し込み、DC ケーブルを発電所に接続します。

Type-C 入力: Type-C ケーブルをコンセントに差し込み、Type-C ケーブルを発電所に接続します。

## スマートフォンまたはその他のデバイスの充電

Bk300/400 には、ユニットの側面に 2 つの AC 出力、1 つの DC 出力、1 つの Type-C 出力、および 3 つの USB 出力 (1 つは QC 3.0、残りは通常のポート) が付属しています。

AC 出力: AC アダプター充電器を Bk300/400 の AC 出力に接続し、充電するラップトップ、タブレット、またはその他のデバイスに接続します。次に、AC ボタンを押します。AC 出力を同時に使用して、2 つのデバイスを充電できます。  
注: AC 出力は、300W を超えるデバイスを充電することはできません。負荷がない場合でも、AC 出力は常にオンになります。使用しないときは、手動で AC 電源ボタンをオフにしてください。

Type-C PD 60W 出力: Type-C ケーブルを your Bk300/400 の Type-C 出力に接続し、充電する携帯電話、タブレット、またはその他のデバイスに接続します。次に、電源ボタンを押します。


注: Type-C PD 60W 出力は、60W を超えるデバイスを充電できません。Type-C 60W 出力を使用する場合は、付属の Type-C ケーブルまたは 60W 対応の Type-C ケーブルを使用することをお勧めします。

USB 出力: USB ケーブルを Bk300/400 の USB 出力に差し込み、携帯電話、タブレット、または充電するその他のデバイスに接続します。次に、電源ボタンを押します。USB 出力を同時に使用して、3 つのデバイスを充電できます。

## 懐中電灯

1. 電源ボタンを押してから、ライトボタンを長押しして懐中電灯のオン/オフを切り替えます。
2. 懐中電灯モードで、ライトボタンを押して3つのライトモード（通常、ストロボ、SOS）から切り替えます。

## 液晶ディスプレイ画面



- 電源がない場合、アイコン全体が点滅します。
- 充電中は、現在の電力消費量に応じて上部のグリッドアイコンが点滅します。
- 完全に充電されると、アイコン全体が常にオンになります。
- 各グリッドアイコンは、20%のバッテリーを表します。

LED ランプ	一つ	2つ	3つ	4つ	5つ
電池残量	20%	40%	60%	80%	100%



OUT

AC 出力を使用する場合、「AC」と「OUT」は常にオンになります。



OUT

DC 出力を使用する場合、「DC」と「OUT」は常にオンになります。



OUT


USB 出力を使用する場合、「USB」、「2.4A」、「OUT」は常にオンになります。



QC3.0 USB 出力を使用する場合、「USB」、「5V/9V」、「OUT」は常にオンになります。



DC 入力を使用する場合、「IN」は常にオンになります。



Type-C 入力を使用する場合、「Type-C」と「IN」は常にオンになります。



Type-C 出力を使用する場合、「Type-C」と「OUT」は常にオンになります。



発電所の内部温度が 70℃を超えると、このアイコンが点灯し、すべてのインターフェースが電力供給を停止します。使用する前に発電所が冷めるのを待ってください



発電所が故障、短絡、過負荷などの場合、このアイコンが点灯します。トラブルシューティング後にご利用ください。

#### 注意:

- ・ 発電所を使用する前に、すべての指示を常に注意深く読んでください。
- ・ Bk300/400 の AC 出力は、300W を超えるデバイスを充電できません。
- ・ バッカー 300/400 の Type-C PD 60W 出力は、60W を超えるデバイスを充電できません
- ・ 電源は使用中に熱くなる
- ・ 発電所の充電中は AC 電源ボタンをオンにできません。DC 出力と USB 出力は機能します。
- ・ パワーステーションの充電を開始する前に、AC 電源ボタンをオフにしてください。
- ・ 電力を節約するために負荷がない場合、DC 出力は自動的に遮断され、負荷がない場合でも AC 出力は常にオンになります。使用しないときは、手で AC 電源ボタンをオフにしてください。
- ・ この発電所への過度の落下、衝突、擦り傷またはその他の影響に注意してください。
- ・ 火気の近くに置かないでください。直射日光を避けてください。

- 発電所を水に浸したり、雨や湿気にさらしたりしないでください。
- 保証が無効になるため、発電所を開けたり分解したりしないでください。
- 充電は -10℃～ 40℃の範囲で行ってください。
- 発電所を子供に近づけないでください。
- 入力または出力に異物を挿入しないでください。
- ユニットを家庭ごみと一緒に廃棄しないでください。
- 指定された入力電圧を超えて装置を操作しないでください。
- この装置を保護するために、使用する前に発電所のバッテリー容量が十分であることを確認してください。
- 少なくとも3か月ごとに発電所のバッテリーをチェックし、時間内に発電所を充電してください。





Contact Us

