


uniden®

UST-4800 SUPER

Integrated Receiver/Descrambler


PRELIMINARY REFERENCE MANUAL



Connecting Components to the UST-4800 SUPER

Because of the complex nature of TVRO systems, the placement and adjustment of the dish antenna and satellite system components is critical. Therefore, it is recommended that you do not attempt to install the system yourself. Your dealer can perform a professional installation that will provide you with the best reception possible.


The **UST-4800 SUPER** has two video inputs and two stereo audio inputs. The **UST-4800 SUPER** also has two video outputs and two stereo audio outputs. These connections provide a variety of ways to customize the complete home entertainment center. The two sets of video outputs and the stereo audio outputs are intended for a TV set and a VCR. The two sets of video inputs and the stereo audio inputs allow you to connect a second viewing source, such as a second VCR or a videodisc player.



Connecting a TV Set or Monitor


TV Set with Separate Audio And Video Inputs

Connect RCA cables from the **TV OUTPUT** audio and video RCA jacks on the **UST-4800 SUPER** to the audio and video inputs on the TV set.



TV Set with Single Coaxial Input

Connect a coaxial cable from the **TV OUT** coaxial connector on the **UST-4800 SUPER** to the VHF input on the back of the TV.




TV Set with Screw Terminals

If the TV set does not have a coaxial antenna connector, you will need an adaptor that matches the impedance (75 Ω) of the **UST-4800 SUPER TV OUT** coaxial connector.

- a. Connect a coaxial cable from the **TV OUT** coaxial connector on the **UST-4800 SUPER** to the F type connector on the adaptor.

Connect the two leads of the adaptor to the screw terminals on the rear of the TV set.



- b. If the TV set has separate UHF inputs, connect the broadcast UHF antenna directly to the TV set.


Tuning the TV Set

Tune the TV set to channel 3 or 4, whichever corresponds to the setting on the 3/4 switch on the back of the **UST-4800 SUPER**. If you are unable to get good reception on one channel, change the setting on the 3/4 switch of the **UST-4800 SUPER** and change the channel on the TV set to match the new setting. If there is no reception or reception is poor, you may need to adjust the fine tuning on the TV set. During satellite TV viewing, the TV set must stay on the channel set on the 3/4 switch on the **UST-4800 SUPER**. This channel number should be written on the inside back cover of this Manual.

Connecting a Monitor


You may be using a monitor for your satellite viewing instead of a TV set. If so, follow these directions for connecting it to your **UST-4800 SUPER** receiver.

1. Connect an RCA cable from the **VIDEO OUTPUT (TV)** connection on the back panel of the **UST-4800 SUPER** to the **VIDEO** input of the monitor.




- 2 Connect the audio from the **UST-4800 SUPER** to the monitor:

- a. For a monitor with mono sound, connect an RCA cable from the Left **AUDIO OUTPUT (TV)** connection on the back panel of the **UST-4800 SUPER** to the **AUDIO** input of the monitor.



Or ...


- b. For a monitor with stereo sound, connect an RCA cable from the Left **AUDIO OUTPUT (TV)** connection on the back panel of the **UST-4800 SUPER** to the Left **AUDIO** input of the monitor. Connect an RCA cable from the Right **AUDIO OUTPUT (TV)** connection on the back panel of the **UST-4800 SUPER** to the Right **AUDIO** input of the monitor.



Connecting Auxiliary Equipment


Connecting the Primary VCR

1. Connect the VCR inputs:
 - a. Connect RCA cables from the **VCR OUT-PUT** audio and video RCA jacks on the **UST-4800 SUPER** to the audio and video inputs on the VCR.




Or ...

- b. Connect the VCR to the **TV OUT** output on the back of the **UST-4800 SUPER** using a coaxial cable.
2. Connect the **EXT 1** video and audio inputs on the back of the **UST-4800 SUPER** to the corresponding outputs on the VCR.




Connecting a Second VCR or Videodisc Player

Connect a second VCR, videodisc player or other external source to the **EXT 2** video and audio inputs on the back of the **UST-4800 SUPER**.



Connecting Stereo Audio Equipment

To attain the full dynamic sound of satellite television, connect the left and right TV audio outputs of the **UST-4800 SUPER** to the auxiliary left and right inputs of a stereo system. Many satellite channels and audio services provide left and right audio signals for full reproduction of the sound.



Viewing With SuperGuide

SuperGuide™ is a satellite broadcast subscription service from SuperGuide Corporation that provides the **UST-4800 SUPER** with a comprehensive built-in satellite viewing guide. The guide covers approximately 12 days, and is automatically updated daily from a satellite by SuperGuide Corporation. Working with your **UST-4800 SUPER**, the SuperGuide Subscription Service allows you to automatically control satellite channel selection and dish antenna movement based on your viewing choices.

Notice: *SuperGuide is a paid subscription service from SuperGuide Corporation, formerly known as Triple-D Publishing, Inc., and is not provided by Uniden America Corporation. All questions or comments concerning the SuperGuide Subscription Service should be addressed to SuperGuide at:*
P.O. Box 167, Shelby, NC 28151-9903
(704) 482-0491

Note: *Some programming is scrambled, and requires a paid subscription before you can view it. This is over and above the paid subscription for the SuperGuide Subscription Service.*

This Chapter covers all the instructions for using SuperGuide to view and listen to satellite programming.

Before using any of the procedures discussed in this Chapter, turn your TV set on and make sure it is tuned to the channel shown on the inside back cover of this Manual.

Note: *The illustrations in this Chapter are representative of typical SuperGuide screens, and are shown for information only. The actual screens you see on your TV may vary from those shown here, depending upon how your **UST-4800 SUPER** was installed and configured.*

Note: *Some features of your **UST-4800 SUPER** may work differently from those described in this Chapter, depending upon how your **UST-4800 SUPER** was installed and configured.*

Note: *The directions throughout this Chapter begin with pressing **GUIDE**. This is necessary only if a program is showing on your screen. If you are already at the SuperGuide Listings, skip Step 1 and go to Step 2.*

In some procedures in this Chapter you are given directions to use **W▶** to go to the next page of listings or **◀E** to go to the previous page of listings. You can also use the following keys to move between pages of listings:

2	Go backward 30 minutes	3	Go forward 30 minutes
5	Go backward 1 day	6	Go forward 1 day
8	Go backward 1 week	9	Go forward 1 week

Press **GUIDE** twice to return to the first page of the current listings from any SuperGuide screen.

You make choices within a SuperGuide screen by using the **▼** and **▲** keys to move the pointer (▶) to the desired position, and then pressing **SELECT** (On some screens you may be directed to press **RETURN** to go back to a previous screen.

Listings Screen Symbols

The SuperGuide Listings and Program Description Screens display special symbols that provide information about the programs. The symbols describe the scrambling format, type of program, movie ratings, and other general information. The location and appearance of these symbols may vary, depending upon how your **UST-4800 SUPER** is configured.

Scrambling Format

The symbol for Scrambling Format appears only for those programs that are scrambled.

SYMBOL	SCRAMBLING FORMAT
≈	VideoCipher [®] II Plus. (This is the type of descrambler provided with the UST-4800 SUPER at this time.)
≈	Oak
≈	B-MAC
≈	Sony scrambled service
≈	VideoCipher I
\$	This program is available only on a pay-per-view basis.
No Symbol	This program is not scrambled






Type of Program

The symbol for the Type of Program usually appears before the program name. Movie titles appear in quotes (" ") and there is no Type of Program symbol.





SYMBOL	TYPE OF PROGRAM
†	Religious program
☺	Children's program
⋈	Sports Program
☺	Talk Show
Ⓔ	Special
♪	Musical program
\$	Financial program
†	Special feed

Movie Ratings

The symbols on the Listings and Program Description reflect some critics' ratings, from poor to excellent. The different symbols used in the Listings are different from those used in the Program Description.

LISTING SCREEN	PROGRAM DESCRIPTION	RATING
		Not rated
	*	Poor
	**	Fair
	***	Good
	****	Excellent




General Information

SYMBOL	DESCRIPTION
	This program is broadcast in stereo
	This program is closed captioned for the hearing impaired
	Your UST-4800 SUPER has been programmed to automatically show this "event" at broadcast time.
	This program is broadcast in Dolby Surround Sound
Fr	This program is broadcast in French
ES	This program is broadcast in Spanish

Selecting and Viewing Programs

Determining What You Are Viewing

1. When you have a picture on your viewing screen, press **TYPE** to see the program information.
2. The **Program Description** screen will be superimposed on the picture.
3. Press **TYPE** to continue watching the program.



Viewing A Specific Program

1. Press **GUIDE** to show the listings for the current time and date.

Listings For Tuesday, May 29		5:00 PM
► GALA	Cine	
≈ USA E	He-Man	
DISC	Profiles of Nature	
≈ DIS W	Welcome to Pooh Corner	
LEARN	Great Chefs of the West	
TBN	Praise the Lord	
CNBC	\$ Business View	
UN	Univision y los Ninos (R)	
≈ USA W	Tic Tac Dough	
≈ FNN	\$ Investment Advice	
TRAV	Travel World	
≈ LIFE W	○ Attitudes	
All		5:15

This is the first page of the listings for the current time.

The format of SuperGuide listings depends upon how your **UST-4800 SUPER** has been configured. In the accompanying illustration the screen shows the name of the **Service**, the name of the **Program**, the current time, and special symbols for each program in the list. Movie titles appear in quotes (" "). The screen also shows the day of the week, the date, and the time of the listing.

2. Use **W▶** to see the next page of listings, or **◀F** to see the previous page of listings, as needed.

Note: See Page D-2 for other keys used to move between listings.

Listings For Tuesday, May 29		5:00 PM
► COM	The Sweet Life	
≈ WGN	Charles in Charge	□
≈ DIS E	"Tiger Town"	●
≈ SHO E	\$ Mighty Moose & the Quarterback	
≈ CNN	The World Today	
≈ ESPN	★ NBA Today	
≈ TMC E	"Magic Moments"	□
≈ FAM E	Hardcastle & McCormick	
≈ A&E	Decades: '60s	
≈ WWOR	Who's the Boss?	
INSP	Shiloh Christian Retreat	
≈ WTBS	Beverly Hillsbillies	
All		5:15

3. Use **▼** or **▲** to move the pointer to choose the program you want to view.

Listings For Tuesday, May 29		5:00 PM
≈ COM	The Sweet Life	
≈ WGN	Charles in Charge	□
≈ DIS E	"Tiger Town"	●
≈ SHO E	\$ Mighty Moose & the Quarterback	
≈ CNN	The World Today	
≈ ESPN	★ NBA Today	
► TMC E	"Magic Moments"	□
≈ FAM E	Hardcastle & McCormick	
≈ A&E	Decades: '60s	
≈ WWOR	Who's the Boss?	
INSP	Shiloh Christian Retreat	
≈ WTBS	Beverly Hillsbillies	
All		5:15

4. Press **SELECT** to see a description of the program.

5. Press **VIEW** to view the program you've highlighted.






Note: If the selected program is scrambled, you must have a subscription to that service to see the program.

a. If the program you've selected is on the satellite you are tuned to, it will appear directly. If the program is on a different satellite, you will see a graphic display while SuperGuide automatically adjusts the satellite dish and tunes to the correct satellite channel.

b. Pressing any key on the **UST 4800r** Remote Control will stop dish movement.

c. Press **RETURN** to display the program on the satellite and channel where the dish stopped.

Note: The dish may have stopped on a satellite and channel on which there is no program, or for which you have no subscription.



Or ...

- d. Press **GUIDE** to return to the first page of the listings and select another program to view using the steps above.

Listings For Tuesday, May 29		5:00 PM
► GALA	Cine	
► USA E	He-Man	
DISC	Profiles of Nature	
► DIS W	Welcome to Pooh Corner	
LEARN	Great Chefs of the West	
TBN	Praise the Lord	
CNBC	\$ Business View	
UNI	Univision y los Ninos (R)	
► USA W	Tic Tac Dough	
► FNN	\$ Investment Advice	
TRAV	Travel World	
► LIFE W	○ Attitudes	
All		5:15

6. Use **▲VOLUME▼** to adjust the viewing volume. Press **MUTE** to turn the sound off temporarily. When **MUTE** is in effect, pressing **MUTE** or **▲VOLUME▼** will return normal audio.

Viewing a Different Program

1. If you are viewing a program, press **GUIDE** to return to the listings.

Listings For Tuesday, May 29		5:00 PM
► COM	The Sweet Life	
► WGN	Charles in Charge	□
► DIS E	"Tiger Town"	□
► SHO E	\$ Mighty Moose & the Quarterback	
► CNN	The World Today	
► ESPN	★ NBA Today	
► TMC E	"Magic Moments"	□
► FAM E	Hardcastle & McCormick	
► A&E	Decades: '60s	
► WWOH	'Who's the Boss?	
INSP	Shiloh Christian Retreat	
► WTBS	Beverly Hillsbillies	
All		5:15

2. Repeat steps 2 through 6 above.

Watching Broadcast Television

1. Press **OFF**. If a standard TV antenna or a cable TV decoder is connected to the **UST-4800 SUPER**, you can select and watch standard broadcast or cable programs using your normal methods. (You cannot use the **UST 4800r** remote control to change channels on your TV set).
2. When you are finished watching, turn your TV set off, or press **GUIDE** to return to satellite viewing.



Finding Program Schedules

Many programs air more than once during a two-week period. You can easily display the schedule for any specific program using SuperGuide.

1. Press **GUIDE** to show the listings for the current time and date.

Listings For Tuesday, May 29		5:00 PM
► GALA	Cine	
~ USA E	He-Man	
DISC	Profiles of Nature	
~ DIS W	Welcome to Pooh Corner	
LEARN	Great Chefs of the West	
TBN	Praise the Lord	
CNBC	\$ Business View	
UNI	Univision y los Ninos (R)	
~ USA W	Tic Tac Dough	
~ FNN	\$ Investment Advice	
TRAV	Travel World	
~ LIFE W	Attitudes	
All		5:15

2. Use **W▶** to see the next page of listings, or **◀L** to see the previous page of listings, as needed.

Listings For Tuesday, May 29		5:00 PM
► ~ COM	The Sweet Life	
~ WGN	Charles in Charge □	
~ DIS E	"Tiger Town" Ⓜ	
~ SHO E	3 Mighty Moose & the Quarterback	
~ CNN	The World Today	
~ ESPN	★ NBA Today	
~ TMC E	"Magic Moments" Ⓜ	
~ FAM E	Hardcastle & McCormick	
~ A&E	Decades: '60s	
~ WWOR	Who's the Boss?	
INSP	Shiloh Christian Retreat	
~ WTBS	Beverly Hillsbillies	
All		5:15

3. Use **▼** or **▲** to move the pointer to choose the program you want to view.


Listings For Tuesday, May 29		5:00 PM
~ COM	The Sweet Life	
~ WGN	Charles in Charge □	
~ DIS E	"Tiger Town" Ⓜ	
~ SHO E	3 Mighty Moose & the Quarterback	
~ CNN	The World Today	
~ ESPN	★ NBA Today	
► ~ TMC E	"Magic Moments" Ⓜ	
~ FAM E	Hardcastle & McCormick	
~ A&E	Decades: '60s	
~ WWOR	Who's the Boss?	
INSP	Shiloh Christian Retreat	
~ WTBS	Beverly Hillsbillies	
All		5:15

4. Press **SELECT** to see a description of the program.


Listings For Tuesday, May 29		5:00 PM
~ TMC E	The Movie Channel East	
	"Magic Moments"	
	(1989) 'NR' (1:43) * *	
A famous magician's lover produces the TV show on which he plans to be burned at the stake.		
John Shea, Jenny Seagrove, Paul Freeman		
		5:15

5. Press **SELECT** again to see the **Program Grid**.

The **Program Grid** graphically shows an 11-day period. You can see the schedule for this program for the entire period.



6. Use **▼** or **▲** to choose a day on the **Program Grid**.



7. Press **SELECT** to see a text list of air times for that day.

You can now see the times and channels that the program is on for the day you selected.

"Magic Moments"	
10:00 AM	TMC E
9:00 PM	TMC E
Tuesday, June 5 5:15	

8. Press **RETURN** to return to the listings.

Note: You may have to press **RETURN** more than once to get back to the listings.

Listings For Tuesday, May 29		5:00 PM
COM	The Sweet Life	
WGN	Charles in Charge	
DIS E	"Tiger Town"	
SHO E	Mighty Moose & the Quarterback	
CNN	The World Today	
ESPN	NBA Today	
TMC E	"Magic Moments"	
FAM E	Hardcastle & McCormick	
A&E	Decades: '60s	
WWOR	Who's the Boss?	
INSP	Shiloh Christian Retreat	
WTBS	Beverly Hillsbillies	
All		5:15

Or ...

Press **GUIDE** to return to the program you were watching.



Listing Only Certain Types of Programs

SuperGuide is normally configured to display listings for all types of programs. You can change this to display listings for the types of programs you are interested in viewing. Even if you want to display all the programs most of time, you can change the listings temporarily to find a specific type of program.

1. Press **GUIDE** to show the listings for the current time and date.

Note: The lower left of the Screen indicates the types of programs that are listed. This screen shows **ALL** types.

Listings For Tuesday, May 29		5:00 PM
► COM	The Sweet Life	
◄ WGN	Charles in Charge	□
◄ DIS E	"Tiger Town"	□
◄ SHO E	▶ Mighty Moose & the Quarterback	
◄ CNN	The World Today	
◄ ESPN	★ NBA Today	
◄ TMC E	"Magic Moments"	□
◄ FAM E	Hardcastle & McCormick	
◄ A&E	Decades: '60s	
◄ WWOR	Who's the Boss?	
◄ INSP	Shiloh Christian Retreat	
◄ WTBS	Beverly Hillsbillies	
All		5:15

2. Press **RETURN** once to move to the **SuperGuide™ Menu**.

SuperGuide™ Menu	
► What's On	
Articles	
Set-Up Guide	
List Services	
Audio Services	
Choose Time Of Day	
Choose Type Of Show	
Browse Descriptions	
Load Database	
5:15	

- a. If you press **RETURN** too many times you may get the **Main Menu** instead of the **SuperGuide™ Menu**.

Main Menu	
► Use Programming Guide	
Operate Receiver	
Set-Up Screen	
Choose Menu Access	
Self Check	
(VIEW) to Watch TV	
SuperGuide	
PO Box 167	
Shelby, NC 28151-9903 USA	
1-800-234-0139	
5:15	

- b. If you do, press **SELECT** and you will be at the -
SuperGuide™ Menu.

3. Use **▼** to move the pointer to **Choose Type of Show**.






4. Press **SELECT** to move to the next screen.

5. Use **▼** or **▲** to move the pointer to choose the type of show you want listed.

*For example, to list only movies, choose **movies** on this screen.*

6. Press **SELECT** to set the listings to show only movies.

Notice that **Movies** now appears in the lower left of the screen instead of **All**.



7. You can now select and view one of the movies listed if you have subscribed to the appropriate services.
Use **▼** or **▲** to move the pointer to choose the movie you want to view.



8. a. Press **VIEW** to view the movie you've highlighted.

Or ...

- b. Press **GUIDE** to return to the program you were previously watching.

Note: The SuperGuide listings will now show only Movies. To display a different type of program repeat Steps 3 through 7 above, selecting the new type of program you want listed. To display all programs, choose **all** in Step 5.

Listings For Tuesday, May 29		5:00 PM
~DIS E	"Tiger Town" ●	
~TMC E	"Magic Moments" ●	
~TMC W	"Animal House" ●	
~MAX E	"Rocky III" ●	
▶~FAM E	"It's a Wonderful Life" ●	
~A&E	"From Here to Eternity" ●	
~WTBS	"Starman" ●	
~WGN	"Superman III" ●	
~SHO E	"Love Story" ●	
~NICK	"LIT Abner" ●	
Movies		5:15



Choose Type-Of-Show		5:15
▶all		
choose listings package		
movies		
sports		
general		
talk shows		
specials		
religious/gospel		
childrens'		
music		
financial		

Finding When Other Programs are On.

SuperGuide provides viewing information for up to 14 days of programming. You can page back and forth through the listings to see what is on now, what was on earlier, and what will be on later.

Note: You can view only those programs that are currently showing.

Press **GUIDE** to show the listings for the current time and date.

Listings For Tuesday, May 29		5:00 PM
► COM	The Sweet Life	
► WGN	Charles in Charge	□
► DIS E	"Tiger Town"	□
► SHO E	Mighty Moose & the Quarterback	
► CNN	The World Today	
► ESPN	NBA Today	
► TMC E	"Magic Moments"	□
► FAM E	Hardcastle & McCormick	
► A&E	Decades: '60s	
► WWOR	Who's the Boss?	
► INSP	Shloh Christian Retreat	
► WTBS	Beverly Hillsbillies	
All		5:15

1. Use **W▶** to see the next page or pages of listings.

Listings For Tuesday, May 29		5:00 PM
► GALA	Cine	
► USA E	He-Man	
► DISC	Profiles of Nature	
► DIS W	Welcome to Pooh Corner	
► LEARN	Great Chefs of the West	
► TBN	Praise the Lord	
► CNBC	Business View	
► UN	Univision y los Ninos (R)	
► USA W	Tic Tac Dough	
► FNN	Investment Advice	
► TRAV	Travel World	
► LIFE W	Attitudes	
All		5:15

2. Press **3** to see listings for 30 minutes later.

Listings For Tuesday, May 29		5:30 PM
► SHO E	"Alien From L.A."	□ □
► TMC W	"Lucky Stiff"	□ □
► DIS W	Care Bears	□
All		5:15

3. Press **6** to see listings for the next day.

Listings For Wednesday, May 30		5:00 PM
► DIS E	"Cheetah"	□ □
► SHO E	"A Summer Story"	□ □
► TMC E	Short Film Showcase	
► DIS W	The Raccoons	□
► FC	"America, America"	●
► SVC1	"Dick Tracy"	□ □
► ACT	"Back Stab"	●
► REQ2	"Cadillac Man"	□
► DRIVE	"Demon Wind"	●
All		5:15

4. Press **9** to see listings for the next week.

5. Use **◀E** to see the previous page or pages of listings.

6. Press **2** to see listings for the previous 30 minutes.

7. If you have moved ahead one or more days or a week in the listings, you can:

a. Press **5** to see listings for the previous day.

OR ...

b. Press **8** to see listings for the previous week.

Note: Listings for the previous day or previous week will display only if you are at a screen that is later than the current day and week. The SuperGuide information is reset at each download so that the listings begin with the week, day, and time of download.

Listings For Tuesday, June 5		5:00 PM
▶ COM	S.A.S.T. Daytime	
▶ WGN	Andy Griffith	
▶ DIS E	Teen Win, Lose, or Draw	◻
▶ CNN	The World Today	
▶ ESPN	★ Running & Racing	
▶ FAM E	Our House	
▶ A&E	The Avengers	◻
▶ WWOR	The Cosby Show	◻
▶ TNT	Gilligan's Island	
▶ WTBS	Bewitched	
All		5:15

Listings For Tuesday, May 29		5:00 PM
▶ PSN	Hockey Week	
▶ CNN	Showbiz Today	
▶ CNBC	Smart Money	
▶ CBMT	Golden Girls	◻
▶ PBS A	✓ Sesame Street	
▶ NIK E	Hey Dude	
▶ AMC	"The Woman Between"	◻
▶ HSE	Coach's Show	
▶ DISC	Wildlife Chronicles	
▶ USA E	Dance Party USA	◻
▶ CINE	"The Big Picture"	◻
▶ WPIX	Charles in Charge	
All		5:15

Listings For Tuesday, May 29		4:30 PM
▶ DIS E	▶ Mickey Mouse Club	◻ ◻
▶ SHO E	▶ Kids-TV	◻
▶ HBO E	▶ "The Goonies"	◻ ◻
▶ DIS W	▶ Mouse Factory	
▶ AMC	▶ "Easy Living"	◻
All		5:15

Using the Event Round-Up

The normal **Listings** screen displays a list of programs on all the Services (Channels) on a given day and at a given time.

The **Event Round-Up** displays a list of programs on a single Service (Channel) grouped by viewing time.

1. Press **GUIDE** to show the listings for the current time and date.

Listings For Tuesday, May 29		5:00 PM
► COM	The Sweet Life	
► WGN	Charles in Charge	□
► DIS E	"Tiger Town"	●
► SHO E	Mighty Moose & the Quarterback	
► CNN	The World Today	
► ESPN	NBA Today	
► TMC E	"Magic Moments"	□
► FAM E	Hardcastle & McCormick	
► A&E	Decades: '60s	
► WWOR	Who's the Boss?	
► INSP	Shiloh Christian Retreat	
► WTBS	Beverly Hillsbillies	
All		5:15

2. Use **▼** or **▲** to move the pointer to choose a program on the Service you are interested in.

Listings For Tuesday, May 29		5:00 PM
► COM	The Sweet Life	
► WGN	Charles in Charge	□
► DIS E	"Tiger Town"	●
► SHO E	Mighty Moose & the Quarterback	
► CNN	The World Today	
► ESPN	NBA Today	
► TMC E	"Magic Moments"	□
► FAM E	Hardcastle & McCormick	
► A&E	Decades: '60s	
► WWOR	Who's the Boss?	
► INSP	Shiloh Christian Retreat	
► WTBS	Beverly Hillsbillies	
All		5:15

3. Press **1** to see up to five consecutive programs and their viewing times on the Service you highlighted.

Notice that the pointer is next to the current time.

Listings For Tuesday, May 29		5:00 PM
Event Round-Up For:		
► WGN	WGN (Chicago)	
4:30 PM	Tale Spin	
► 5:00 PM	Charles in Charge	
5:30 PM	Perfect Strangers	
6:00 PM	Cheers	
6:30 PM	Night Court	
All		5:15

4. Use **◀E** to see up to five programs on the preceding **Event Round-Up** screen ...

Listings For Tuesday, May 29		5:00 PM
Event Round-Up For:		
► WGN	WGN (Chicago)	
2:00 PM	The Honeymooners	
► 2:30 PM	Cooly's Cartoon Club	
3:00 PM	Gummi's Bears	□
3:30 PM	Duck Tails	□
4:00 PM	Chip 'N Dale's Rescue Rangers	□
All		5:15

... or use **W▶** up to five programs on the next **Event Round-Up** screen.


5. Press **RETURN** to return to the **Listings** screen to select a different Service.

Or ...

Press **GUIDE** to return to the program you were viewing.

Listings For Tuesday, May 29		5:00 PM
Event Round-Up For:		
~ WGN WGN (Chicago)		
7:00 PM		
"Finish Line" Ⓜ		
> 9:00 PM		
News Ⓜ		
10:00 PM		
Night Court		
10:30 PM		
Hunter		
11:30 PM		
"Warlords of the 21st Century" Ⓜ		
All		5:15

Listings For Tuesday, May 29		5:00 PM
~ COM	The Sweet Life	
> ~ WGN	Charles in Charge Ⓜ	
~ DIS E	"Tiger Town" Ⓜ	
~ SHO E	Mighty Moose & the Quarterback	
~ CNN	The World Today	
~ ESPN	* NBA Today	
~ TMC E	"Magic Moments" Ⓜ	
~ FAM E	Hardcastle & McCormick	
~ A&E	Decades: '60s	
~ WWOR	Who's the Boss?	
~ INSP	Shiloh Christian Retreat	
~ WTBS	Beverly Hillsbillies	
All		5:15



Viewing and/or Taping at a Later Time

Once you know when a specific program will be on later, you can set your **UST-4800 SUPER** to tune in to that program at the right time. You can also set up your VCR to tape that program using the IR VCR Control (VCR "Mouse"). The VCR "Mouse" sends infrared signals to your VCR to begin recording and to stop recording at the appropriate times.

Note: *The operation of the VCR "Mouse" (IR VCR Control) may not be compatible with the specific brand and model of your VCR. If not, you will need to program your VCR separately.*

Setting up the VCR "Mouse"

1. Press **GUIDE** to show the listings for the current time and date.

Listings For Tuesday, May 29		5:00 PM
► GALA	Cine	
→ USA E	He-Man	
DISC	Profiles of Nature	
→ DIS W	Welcome to Pooh Corner	
LEARN	Great Chefs of the West	
TBN	Praise the Lord	
CNBC	\$ Business View	
UN	Univision y los Niños (R)	
→ USA W	Tic Tac Dough	
→ FNN	\$ Investment Advice	
TRAV	Travel World	
→ LIFE W	○ Attitudes	
All		5:15


2. Press **RETURN** to get to the SuperGuide™ Menu.

SuperGuide™ Menu		
► What's On		
Articles		
Set-Up Guide		
List Services		
Audio Services		
Choose Time Of Day		
Choose Type Of Show		
Browse Descriptions		
Load Database		
		5:15


3. Use **▼** to move the pointer to **Set-Up Guide**.

SuperGuide™ Menu		
What's On		
Articles		
► Set-Up Guide		
List Services		
Audio Services		
Choose Time Of Day		
Choose Type Of Show		
Browse Descriptions		
Load Database		
		5:15


4. Press **SELECT** to get to the **SuperGuide Set-up Menu**.




5. Use **▼** to move the pointer to **Set-Up VCR**.



6. Press **SELECT** to get to the **VCR setup function** menu.




7. Press **SELECT** to get to the **Choose VCR Brand** menu.



8. Use **▼** to move the pointer to choose your VCR brand.

For example: If you have a Sony VCR, move the pointer to Sony.



11. Press **GUIDE** twice to return to the first page of current listings.

Listings For Tuesday, May 29		5:00 PM
► GALA	Cine	
► USA E	He-Man	
DISC	Profiles of Nature	
► DIS W	Welcome to Pooh Corner	
LEARN	Great Chefs of the West	
TBN	Praise the Lord	
CNBC	\$ Business View	
UNI	Univision y los Niños (R)	
► USA W	Tic Tac Dough	
► FNN	\$ Investment Advice	
TRAV	Travel World	
► LIFE W	○ Attitudes	
All		5:15

Setting up a Programmed Event

1. Use any of the methods in the previous sections to determine the day and time the desired program is on.
2. If the **Listings** screen is displayed:
 - a. Use **▼** or **▲** to move the pointer to choose the program.

Listings For Tuesday, May 29		8:00 PM
► HA	Comics Only	
CSPAN1	Washington Press Foundation	
► KTLA	Hunter	
► CINE	"Cocoon: The Return" ●	
ABC W	ABC News	
FAM	† The King Is Coming	
► MSG	* Sports Forum	
INT	Korean Film	
NOST	"The Smallest Show on Earth" ●	
► PLAY	Playmates: Where are They Now	
NBC E	Night Court	
► WBBM	\$ The Movie Awards	
All		5:15

- b. Press **TAPE** and the **Event Programmed** screen will appear.

Listings For Tuesday, May 29		8:00 PM
Event 1 successfully programmed. You may wish to program your VCR now.		
Tuesday, May 29 Event #1		
from 8:00 PM to 9:56 PM (1:56)		
Service: ► CINE Cinemax East		
Show:		
"Cocoon: The Return" ●		
(RETURN) To Continue		5:15

- c. Press **RETRV** and a reminder screen will appear.

Note: If you do not have the VCR "Mouse" turned ON, you will not see this screen. You will then need to program your VCR separately. In either case, be sure to turn the VCR power on or you will not record the event.

Listings For Tuesday, May 29		8:00 PM
Remember to leave your VCR on with		
a tape in it if you really want		
to videotape the show.		
Also be sure the input to the VCR		
is set to your satellite receiver.		
(RETURN) To Continue		5:15

- d. Press **RETURN** to return to the **Listings** screen. You will see **●●** next to the selected program.

Listings For Tuesday, May 29		8:00 PM
► HA	Comics Only	
CSPAN1	Washington Press Foundation	
~ KTLA	Hunter	
~ CINE	"Cocoon: The Return" ●●	
ABC W	ABC News	
FAM	↑ The King Is Coming	
~ MSG	★ Sports Forum	
INT	Korean Film	
NOST	"The Smallest Show on Earth" ●	
~ PLAY	Playmates: Where are They Now	
NBC E	Night Court (●) □	
~ WBBM	★ The Movie Awards (●) □	
All		5:15

3. If the **Event Round-Up** screen is displayed:

- a. Use **▼** or **▲** to move the pointer to choose the program.

Listings For Tuesday, May 29		8:00 PM
Event Round-Up For:		
~ CINE	Cinemax East	
6:05 PM	"The Front Page" ●	
► 8:00 PM	"Cocoon: The Return" ●	
10:00 PM	"Defense Play" □	
12:00 PM	"Play Misty for Me" ●	
2:00 AM	"Quintet" ●	
All		5:15

- b. Press **TAP** and the **Event Programmed** screen will appear.

Listings For Tuesday, May 29		8:00 PM
Event 1 successfully programmed. You may wish to program your VCR now.		
Tuesday, May 29 Event #1		
from 8:00 PM to 9:56 PM (1:56)		
Service: ~ CINE Cinemax East		
Show: "Cocoon: The Return" ●		
(RETURN) To Continue		5:15

- c. Press **RETURN** and a reminder screen will appear.

Note: If you do not have the VCR "Mouse" turned **ON**, you will not see this screen. You will then need to program your VCR separately. In either case, be sure to turn the VCR power on or you will not record the event.

Listings For Tuesday, May 29		8:00 PM
Remember to leave your VCR on with a tape in it if you really want to videotape the show. Also be sure the input to the VCR is set to your satellite receiver.		
(RETURN) To Continue		5:15

- d. Press **RETURN** to return to the **Event Round-up** screen. You will see **●●** next to the selected program.

4. Approximately one minute before the programmed event is due to come on, a tone will sound and the **Taped Event** warning screen will appear.

You can:

- a. Press **SELECT** to view (and/or videotape) the program.




Note: If the program you've selected is on the satellite you are tuned to, it will appear directly. If the program is on a different satellite, you will see a graphic display while SuperGuide automatically adjusts the satellite dish and tunes to the correct satellite channel.

Or ...

- b. Press **RETURN** to skip the program and continue watching the program that's on.

Listings For Tuesday, May 29		8:00 PM
Event Round-Up For:		
- CINE Cinemax East		
6:05 PM	"The Front Page" ●	
8:00 PM	"Cocoon: The Return" ●●	
10:00 PM	"Defense Play" ●	
12:00 PM	"Play Misty for Me" ●	
2:00 AM	"Quintet" ●	
All		5:15



Taped event 1 is starting now!	
(SELECT) to view this event.	
(RETURN) to cancel this event.	
Tuesday, May 29	
Event #1	
from 8:00 PM to 9:56 PM (1:56)	
Service: - CINE Cinemax East	
Show:	
"Cocoon: The Return" ●	
7:59	

Automatic Dish Movement in Progress	
	 S1
Moving to G1	
	
Current Position is: 2652	
Target Position is: 3000	
Press Any Key to Stop Dish	
5:15	



Note: If you don't press any key, the **UST-4800 SUPER** will still tune to the taped event and signal the VCR to begin recording. Pressing **SELECT** will cause it to tune in and signal the VCR immediately.

Cancelling a Programmed Event



1. Use any of the methods in the previous section to determine the day and time the desired program is on.
2. If the **Listings** screen is displayed:
 - a. Use  or  to move the pointer to choose the programmed event.

Listings For Tuesday, May 29		8:00 PM
► HA	Comics Only	
CSPAN1	Washington Press Foundation	
~ KTLA	Hunter	
~ CINE	"Cocoon: The Return" ● ●	
ABC W	ABC News	
FAM	† The King Is Coming	
~ MSG	★ Sports Forum	
INT	Korean Film	
NOST	"The Smallest Show on Earth" ●	
~ PLAY	Playmates: Where are They Now	
NBC E	Night Court n □	
~ WBBM	§ The Movie Awards n □	
All		5:15

- b. Press  .
The ●● next to the selected program disappears.

Listings For Tuesday, May 29		8:00 PM
► HA	Comics Only	
CSPAN1	Washington Press Foundation	
~ KTLA	Hunter	
~ CINE	"Cocoon: The Return" ●	
ABC W	ABC News	
FAM	† The King Is Coming	
~ MSG	★ Sports Forum	
INT	Korean Film	
NOST	"The Smallest Show on Earth" ●	
~ PLAY	Playmates: Where are They Now	
NBC E	Night Court n □	
~ WBBM	§ The Movie Awards n □	
All		5:15

Or ...

3. If the **Event Round-Up** screen is displayed:
 - a. Use  or  to move the pointer to choose the programmed event.

Listings For Tuesday, May 29		8:00 PM
Event Round-Up For:		
~ CINE	Cinemax East	
6:05 PM	"The Front Page" ●	
► 8:00 PM	"Cocoon: The Return" ● ●	
10:00 PM	"Defense Play" □	
12:00 PM	"Play Misty for Me" ●	
2:00 AM	"Quintet" ●	
All		5:15

b. Press **PAUSE**.

The **●●** next to the selected program disappears.

Listings For Tuesday, May 29		8:00 PM
Event Round-Up For:		
-- CINE Cinemax East		
6:05 PM	"The Front Page" ●	
▶8:00 PM	"Cocoon: The Return" ●●	
10:00 PM	"Defense Play" ●	
12:00 PM	"Play Misty for Me" ●	
2:00 AM	"Quintet" ●	
All		5:15

Note: *If you have manually set up your VCR, remember to cancel the programming..*

Other Functions

Listening to Music / Talk Shows

Many satellite channels carry audio programs as well as video programs. You can access these audio programs using SuperGuide.

1. Press **GUIDE** to show the listings for the current time and date.

Listings For Tuesday, May 29		5:00 PM
► COM	The Sweet Life	
► WGN	Charles in Charge	□
► DIS E	"Tiger Town"	■
► SHO E	Mighty Moose & the Quarterback	
► CNN	The World Today	
► ESPN	* NBA Today	
► TMC E	"Magic Moments"	■
► FAM E	Hardcastle & McCormick	
► A&E	Decades: '60s	
► WWOR	Who's the Boss?	
► INSP	Shiloh Christian Retreat	
► WTBS	Beverly Hillsbillies	
All		5:15

2. Press **RETURN** to move to the SuperGuide™ Menu.

SuperGuide™ Menu
► What's On
Articles
Set-Up Guide
List Services
Audio Services
Choose Time Of Day
Choose Type Of Show
Browse Descriptions
Load Database
5:15

3. Use **▼** to move the pointer to Audio Services.

SuperGuide™ Menu
What's On
Articles
Set-Up Guide
List Services
► Audio Services
Choose Time Of Day
Choose Type Of Show
Browse Descriptions
Load Database
5:15

4. Press **SELECT** to move to the next screen.

Choose Audio Type
► classical
contemporary
country/western
easy listening
international
jazz
news/talk
nostalgia
religious
rock
special interest
variety
5:15

5. Use **▼** or **▲** to move the pointer to choose the type of music you want to hear.

*For example: To listen to "Easy Listening" selections, choose **easy listening** on this screen.*

6. Press **SELECT** to see the Services that broadcast Easy Listening selections via satellite.

7. Select an audio program from this list, or use **W▶** or **◀E** to find other audio programs of interest.

8. When you find a screen containing the audio program you want, use **▼** or **▲** to move the pointer to choose the program you want to hear.

9. Press **VIEW** to hear the program.

Note: You will see the regular program for that channel. However, you will hear the selected audio program instead of the normal sound that accompanies the video.

Choose Audio Type	
classical	
contemporary	
country/western	
▶ easy listening	
international	
jazz	
news/talk	
nostalgia	
religious	
rock	
special interest	
variety	

5:15

Choose Audio Service	
▶ CHFI-FM (TORONTO)	
D1 8 6.80 mono	
Super Radio Soft Sounds	
G3 11 5.58/5.76 discrete	
Instore Satellite Network	
S1 17 5.04 mono	
Instore Satellite Network	
S1 17 5.40 mono	
Instore Satellite Network	
S1 17 5.76 mono	
Instore Satellite Network	
S1 17 5.94 mono	

easy listening 5:15

Choose Audio Service	
▶ CRN (Cable Radio Network)	
F3 11 7.23 mono	
United Video Background Music	
F4 8 5.89 mono	
WJIB (Boston)	
F4 13 6.80 mono	



easy listening 5:15

Choose Audio Service	
CRN (Cable Radio Network)	
F3 11 7.23 mono	
United Video Background Music	
F4 8 5.89 mono	
▶ WJIB (Boston)	
F4 13 6.80 mono	

easy listening 5:15



- a. If the program you've selected is on the satellite you are tuned to, you will hear the music directly. If the program is on a different satellite, you will see a graphic display while SuperGuide automatically adjusts the satellite dish and tunes to the correct satellite channel.
- b. Pressing any key on the **UST 4800r** Remote Control will stop dish movement.




- c. Press **RETURN** to display the program on the satellite and channel where the dish stopped.

Note: The dish may have stopped on a satellite and channel on which there is no program, or for which you have no subscription.

Or ...

- d. Press **GUIDE** to return to the first page of the listings.



Listings For Tuesday, May 29		5:00 PM
► GALA	Cine	
~USA E	He-Man	
DISC	Profiles of Nature	
~DIS W	Welcome to Pooh Corner	
LEARN	Great Chefs of the West	
TBN	Praise the Lord	
CNBC	\$ Business View	
UNI	Univision y los Niños (R)	
~USA W	Tic Tac Dough	
~FNN	\$ Investment Advice	
TRAV	Travel World	
~LIFE W	Attitudes	
All		5:15

10. Use **VOLUME** to adjust the viewing volume. Press **MUTE** to turn the sound off temporarily. When **MUTE** is in effect, pressing **MUTE** or **VOLUME** will return normal audio.

Returning to Video

1. Press **GUIDE** to return to the listings for the current time and date, and use any of the methods in the previous sections to select and view a program.

Or ...

2. While viewing a program you can press **▼** or **▲** to view a program on another Channel on the same Satellite.

Listings For Tuesday, May 29		5:00 PM
► COM	The Sweet Life	
≈ WGN	Charles in Charge □	
≈ DIS E	"Tiger Town" ■	
≈ SHO E	5 Mighty Moose & the Quarterback	
≈ CNN	The World Today	
≈ ESPN	★ NBA Today	
≈ TMC E	"Magic Moments" ■	
≈ FAM E	Hardcastle & McCormick	
≈ A&E	Decades: '60s	
≈ WWOR	Who's the Boss?	
INSP	Shiloh Christian Retreat	
≈ WTBS	Beverly Hillsbillies	
All		5:15

Listing Services


A "service" is a particular satellite and channel combination. You may know it more commonly as a "Channel", such as: The Movie Channel, HBO, The Disney Channel, etc. When your **UST-4800 SUPER** was first installed, or when you selected your paid subscription package, a group of Services were specified for downloading.

You can get information about the Services you have using the built-in features of SuperGuide.


1. Press **GUIDE** to show the listings for the current time and date.

Listings For Tuesday, May 29		5:00 PM
► COM	The Sweet Life	
≈ WGN	Charles in Charge □	
≈ DIS E	"Tiger Town" ■	
≈ SHO E	5 Mighty Moose & the Quarterback	
≈ CNN	The World Today	
≈ ESPN	★ NBA Today	
≈ TMC E	"Magic Moments" ■	
≈ FAM E	Hardcastle & McCormick	
≈ A&E	Decades: '60s	
≈ WWOR	Who's the Boss?	
INSP	Shiloh Christian Retreat	
≈ WTBS	Beverly Hillsbillies	
All		5:15

2. Press **RETURN** to move to the **SuperGuide™ Menu**.




3. Use **▼** to move the pointer to **List Services**.




4. Press **SELECT** to move to the next screen.

This screen lists those Services that have been installed in your **UST-4800 SUPER IRD**. You can get more information about any of the Services listed on this screen.




5. Use **▼** or **▲** to move the pointer to choose the Service you are interested in.

*For example: To get more information about "ESPN", choose **ESPN** on this screen.*



6. Press **SELECT** to see more information about "ESPN".

This screen gives you technical information such as **Satellite Number** and **Channel**, **Scrambler Type**, and **Audio Frequency**.



You already know which package or packages you have subscribed to, and that at least one of them has ESPN. However, if you are thinking about adding one or more packages, you may want to see which other packages have ESPN.

7. Press **SELECT** to see which packages include ESPN.

ESPN Sports	
APS Package	
Cox Package	
HBO Package	
Netlink Package	
NPS Package	
NSOA Package	
Showtime Package	
Prog Ware Package	
Prog Clear Package	
One Stop Package	
Disney Package	
All Star Programming	
...MORE...	5:15

8. Use **W** or **←** to see other packages that include ESPN.

ESPN Sports	
Tele-Media Package	
SuperStar Package	
TCI Package	
(RETURN) To Continue	5:15


9. At this point you have several choices:

a. Press **RETURN** to go back to the previous screen.

ESPN Sports	
APS Package	
Cox Package	
HBO Package	
Netlink Package	
NPS Package	
NSOA Package	
Showtime Package	
Prog Ware Package	
Prog Clear Package	
One Stop Package	
Disney Package	
All Star Programming	
...MORE...	5:15

Or ...

b. Press **GUIDE** to go back to the program you were watching.



Or ...

- c. Press **GUIDE** twice to return to the first page of the current listings.

Listings For Tuesday, May 29		5:00 PM
► GALA	Cine	
► USA E	He-Man	
DISC	Profiles of Nature	
► DIS W	Welcome to Pooh Corner	
LEARN	Great Chefs of the West	
TBN	Praise the Lord	
CNBC	\$ Business View	
UN	Univision y los Ninos (R)	
► USA W	Tic Tac Dough	
► FNN	\$ Investment Advice	
TRAV	Travel World	
► LIFE W	Attitudes	
All		5:15

Reading Articles

The SuperGuide Subscription Service includes text articles that can be viewed. These articles are divided into a number of categories, such as: Letters, Satellite Industry News, Sports, US News, and Program Notes.

When your **UST-4800 SUPER** was installed, you indicated which of these article categories you wanted to download. You can read any of the articles in these categories at any time.


1. Press **GUIDE** to show the listings for the current time and date.

Listings For Tuesday, May 29		5:00 PM
► COM	The Sweet Life	
► WGN	Charles in Charge	□
► DIS E	"Tiger Town"	□
► SHO E	Mighty Moose & the Quarterback	
► CNN	The World Today	
► ESPN	★ NBA Today	
► TMC E	"Magic Moments"	□
► FAM E	Hardcastle & McCormick	
► A&E	Decades: '60s	
► WWOR	Who's the Boss?	
INSP	Shiloh Christian Retreat	
► WTBS	Beverly Hillsbillies	
All		5:15


2. Press **RETURN** to move to the SuperGuide™ Menu.

SuperGuide™ Menu	
► What's On	
Articles	
Set-Up Guide	
List Services	
Audio Services	
Choose Time Of Day	
Choose Type Of Show	
Browse Descriptions	
Load Database	
5:15	

3. Use **▼** to move the pointer to **Articles**.




4. Press **SELECT** to move to the next screen.




5. Use **▼** or **▼** to move the pointer to choose the type of articles you want to read.

*For example: To see the Program Notes, choose **Program Notes** on this screen.*



6. Press **SELECT** to see the types of Program Notes available.



The Program Notes listed here are the ones you received at the last SuperGuide download. As an example, suppose you have a TV set that has Dolby Surround sound capabilities. You may want to know which movies this week will have Dolby Surround sound.

7. Use **▼** to move the pointer to **Dolby Movie List**.

8. Press **SELECT** to see the List of Movies. Notice the Number 1 in the upper right corner. This lets you know that there are more screens in this category.

9. Use **W▶** or **◀E** to move back and forth between the screens for this article.

10. At this point you have two choices:

a. Press **RETURN** to save the article and go back to the **Choose Article** screen,

Or...

b. Press **SELECT** to erase the article.. This will take you back to the **Choose Article** screen. However, you'll note that the **Dolby Movie List** article has been erased from the screen.

Choose Article	
Notes & Comments	
Program Notes	
► Dolby Movie List	
Program Notes	5:15


Dolby Movie List	1
May 28 - Jun 3	
The following movies will be airing this week in * Dolby Surround Sound.	
Please consult the "Browse Movie Description" list for complete descriptions, air times and locations of these movies.	
The Accidental Tourist	
Action Jackson	
The Adventures of Baron Munchausen	
The Adventures of Ford Fairlane	
(RETURN) To Save/ (SELECT) To Toss	
5:15	

Dolby Movie List	2
Alien Nation Altered States Always Another 48 Hours Au Revoir, Les Enfants Baby Boom Back To School Back To The Future Part II Blaze The Blue Lagoon The Beast	
(RETURN) To Save/ (SELECT) To Toss	
5:15	

Choose Article	
► Notes & Comments	
Program Notes	
Program Notes	5:15

11. You can now:

- a. Press **GUIDE** to go back to the program you were watching.



Or ...

- b. Press **GUIDE** twice to return to the first page of the current listings.

Listings For Tuesday, May 29		5:00 PM
► GALA	Cine	
≈ USA E	He-Man	
DISC	Profiles of Nature	
≈ DIS W	Welcome to Pooh Corner	
LEARN	Great Chefs of the West	
TBN	Praise the Lord	
CNBC	\$ Business View	
UNI	Univision y los Niños (R)	
≈ USA W	Tic Tac Dough	
≈ FNN	\$ Investment Advice	
TRAV	Travel World	
≈ LIFE W	○ Attitudes	
All		5:15

Restoring Tossed Articles


Once you "toss" (erase) an Article, you will not be able to read it again until SuperGuide is downloaded again. If you decide you want to see it again, you must restore all "tossed" Articles.

Note: You cannot restore an individual Article; you must restore all Articles.


1. Press **GUIDE** to show the listings.

Listings For Tuesday, May 29		5:00 PM
► COM	The Sweet Life	
≈ WGN	Charles in Charge □	
≈ DIS E	"Tiger Town" ●	
≈ SHO E	z Mighty Moose & the Quarterback	
≈ CNN	The World Today	
≈ ESPN	* NBA Today	
≈ TMC E	"Magic Moments" ●	
≈ FAM E	Hardcastle & McCormick	
≈ A&E	Decades: '60s	
≈ WWOR	Who's the Boss?	
INSP	Shiloh Christian Retreat	
≈ WTBS	Beverly Hillsbillies	
All		5:15


2. Press **RETURN** to move to the **SuperGuide™ Menu**.




3. Use **▼** to move the pointer to **Set-Up Guide**.




4. Press **SELECT** to move to the next screen.




5. Use **▼** to move the pointer to **Set-Up Download**.




6. Press **SELECT** to move to the next screen.




7. Use **▼** to move the pointer to **Set-Up Articles**.



8. Press **SELECT** to move to the next screen.




9. Use **▼** to move the pointer to **Restore All Tossed Articles**.



10. Press **SELECT** to restore the tossed Articles.


Note: The Screen does not change when you press

SELECT.



You may now:

1. Press **GUIDE** to go back to the program you were watching.



Or ...

2. Press **GUIDE** twice to return to the first page of the current listings.

Listings For Tuesday, May 29		5:00 PM
> GALA	Cine	
~ USA E	He-Man	
DISC	Profiles of Nature	
~ DIS W	Welcome to Pooh Corner	
LEARN	Great Chefs of the West	
TBN	Praise the Lord	
CNBC	\$ Business View	
UNI	Univision y los Niños (R)	
~ USA W	Tic Tac Dough	
~ FNN	\$ Investment Advice	
TRAV	Travel World	
~ LIFE W	o Attitudes	
AM		5:15


Using The Integrated Control Panel

You will control most of your satellite viewing via the SuperGuide screens described in the previous Chapter. The Integrated Control Panel is used when you want to view programs and feeds that may not be covered by the SuperGuide listings. You can also find programs that have already started on any satellite without actually viewing the program or scrolling through the SuperGuide listings.

Note: The directions throughout this Chapter begin with pressing **RIC**. This is necessary only if you are viewing a program or a SuperGuide screen. If you are already at the Integrated Control Panel, skip Step 1 and go to Step 2.

Note: SuperGuide screens and Integrated Control Panels used throughout this Chapter are for illustration only, and may differ from the actual screens and Panels seen on your TV.D

The Integrated Control Panel consists of three separate Panels: Top, Middle, and Bottom. Each Panel controls a different set of functions.



The Fields (**NOW PLAYING**, **SATELLITE**, **CH**, etc.) within each Panel display important information, and some are used to make adjustments.

The settings controlled by the Middle and Bottom Panels were adjusted when your **UST-4800 SUPER** was installed; they do not need to be changed for normal operation. Therefore, these Panels are closed when you press **REC** the first time. You must open each Panel separately to adjust the settings. You can then close the Panels or leave them open for later adjustments.

uniden 4800 Integrated Control Panel					
The Family Channel East					
NOW PLAYING					
Hardcastle & McCormick					
SATELLITE 2498	CH 11	START 5:00	LENGTH 1:00	PLOC OFF	
PUSH TO OPEN					
uniden 4800					
PUSH TO OPEN					
(SELECT) A Service					5:15

In each Panel you can identify the specific Field you are on by the highlight box (a darker border). For example, if you are at the **CH** (Channel) Field, it will be highlighted as shown.

Use **W▶** or **◀F** to move the highlight box from one Field to the next.

Use **▼** and **▲** to make adjustments in the highlighted Field.

uniden 4800 Integrated Control Panel					
The Family Channel East					
NOW PLAYING					
Hardcastle & McCormick					
SATELLITE 2498	CH 11	START 5:00	LENGTH 1:00	PLOC OFF	
PUSH TO OPEN					
uniden 4800					
PUSH TO OPEN					
(SELECT) A Channel					5:15

The Top Panel

The Top Panel displays information about the currently selected service, satellite and channel.

Note: The **SERVICE NAME**, **PROGRAM NAME**, **START**, and **LENGTH** fields may be blank, depending upon the specific satellite and channel.

uniden 4800 Integrated Control Panel					
The Family Channel East					
NOW PLAYING					
Hardcastle & McCormick					
SATELLITE 2498	CH 11	START 5:00	LENGTH 1:00	PLOC OFF	
PUSH TO OPEN					
uniden 4800					
PUSH TO OPEN					
(SELECT) A Channel					5:15

Service Name → The Family Channel East

Program Name → Hardcastle & McCormick

Satellite Name → GALAXY G1

Actuator Counter → 11

Channel Number → 11

Parental Lock (ON/OFF) → PLOC OFF


Length of Program → 1:00

Start Time of Program → 5:00

Within this Panel you can change the service, satellite and/or channel, and limit access to the current channel via Parental Lockout. This Panel is always displayed when you press **REC**. (It cannot be closed.)


The Middle Panel

Use the Middle Panel to adjust the audio settings for the current channel. The Middle Panel also has indicators showing the signal strength of the left audio signal strength, right audio signal strength, satellite signal strength, and the current volume setting.



The Bottom Panel

Use the Bottom Panel to adjust the settings of the incoming satellite signal, and the audio/video output signals from the **UST-4800 SUPER** to the TV and VCR.



Making Changes Permanent

If you make certain changes in the Middle or Bottom Panel for a particular satellite and channel, you can lock those changes in by pressing **CUST**. Customizing satellite channels is covered in the paragraphs on "Using the Middle Panel" and "Using the Bottom Panel".

When you customize a satellite channel, a **C** appears in the upper right corner of the Integrated Control Panel displaying information about that satellite and channel.

uniden 4800 Integrated Control Panel					C
The Family Channel East					
NOW PLAYING					
Hardcastle & McCormick					
SATELLITE	2498	CH	START	LENGTH	PLOC
GALAXY G1		11	5:00	1:00	OFF
PUSH TO OPEN					
uniden 4800					
PUSH TO OPEN					
(SELECT) A Service					5:15

If you do not customize a satellite channel, any changes will be temporary and in effect only until you change to a different channel or satellite.

Note: The changes you make in the Integrated Control Panel do not take effect until you press **VIEW**.

Using the Top Panel

Getting Information About the Current Program

1. Press **REC** to display the Integrated Control Panel.

uniden 4800 Integrated Control Panel					
The Movie Channel East					
NOW PLAYING					
Magic Moments					
SATELLITE	2498	CH	START	LENGTH	PLOC
GALAXY G1	10	5:00	1:43	OFF	
PUSH TO OPEN					
uniden 4800					
PUSH TO OPEN					
(SELECT) A Service 5:15					

2. If the **NOW PLAYING** Field is not highlighted, use **W▶** or **◀E** to move the highlight to **NOW PLAYING**.

uniden 4800 Integrated Control Panel					
The Movie Channel East					
NOW PLAYING					
Magic Moments					
SATELLITE	2498	CH	START	LENGTH	PLOC
GALAXY G1	10	5:00	1:43	OFF	
PUSH TO OPEN					
uniden 4800					
PUSH TO OPEN					
5:15					


3. Press **SELECT** for a description of the current program.

Listings For Tuesday, May 29		5:00 PM
~ TMC E The Movie Channel East		
"Magic Moments"		
(1989) 'NR' (1:43) * *		
A famous magician's lover produces the TV show on which he plans to be burned at the stake.		
John Shea, Jenny Seagrove, Paul Freeman		
5:15		


4. Press **SELECT** again to see the Program Grid.

"Magic Moments"	
	MID 6AM NOON 6PM
5/29 T	
5/30 W	
5/31 T	
6/1 F	
6/2 S	
6/3 S	
6/4 M	
6/5 T	
6/6 W	
6/7 T	
6/8 F	

5. Use **▼** and **▲** to move the pointer to highlight the day you want on the Program




6. Press **SELECT** to see a text list of air times for that day.



7. When you have the information you want, you can:

- a. Press **REC** to return to the program you were watching.



Or ...

- b. Press **RETURN** repeatedly to go back through the screens until you get back to the Integrated Control Panel.

Changing Services

1. Press **REC** to display the Integrated Control Panel.
2. If the **SERVICE NAME** Field is not highlighted, use **W▶** or **◀E** to move the highlight to **SERVICE NAME**.
3. Press **SELECT** to see a list of available services.
4. Use **W▶** to see the next page(s) or **◀E** to see the previous page(s) of the service listings, if desired.

uniden 4800 Integrated Control Panel					
The Family Channel East					
NOW PLAYING					
Hardcastle & McCormick					
SATELLITE	2498	CH	START	LENGTH	PLOC
GALAXY G1		11	5:00	1:00	OFF
PUSH TO OPEN					
uniden 4800					
PUSH TO OPEN					
(SELECT) A Channel 5:15					

uniden 4800 Integrated Control Panel					
The Family Channel East					
NOW PLAYING					
Hardcastle & McCormick					
SATELLITE	2498	CH	START	LENGTH	PLOC
GALAXY G1		11	5:00	1:00	OFF
PUSH TO OPEN					
uniden 4800					
PUSH TO OPEN					
(SELECT) A Service 5:15					

Choose A Service	
~TNN	The Nashville Network
~WGN	WGN
~DIS E	Disney Channel East
~SHO E	Showtime East
~CNN	Cable News Network
~CNN-H	CNN Headline News
~ESPN	ESPN Sports
~TMC E	The Movie Channel East
▶~FAM E	The Family Channel East
~A&E	Arts & Entertainment
~TMC W	The Movie Channel West
~WWOR	WWOR (New Jersey)
5:15	

Choose A Service	
▶~BRAVO	Bravo
~LIFE E	Lifetime East
~LIFE W	Lifetime West
~DISC	Discovery Channel
~FAM	The Family Network
~TNT	TNT
~TRAV	The Travel Channel
~BET	Black Entertainment TV
~GALA	Galavision (Spanish)
~UNI	Univision (Spanish)
~WTBS	WTBS (Atlanta)
~HBO E	Home Box Office East
5:15	

5. When you are at the desired list of Services, use **▼** and **▲** to move the pointer to highlight the service you want.


6. Press **SELECT** to select the service.

Choose A Service	
~ TNN	The Nashville Network
~ WGN	WGN
~ DIS E	Disney Channel East
~ SHO E	Showtime East
~ CNN	Cable News Network
~ CNN-H	CNN Headline News
~ ESPN	ESPN Sports
▶ ~ TMC E	The Movie Channel East
~ FAM E	The Family Channel East
~ A&E	Arts & Entertainment
~ TMC W	The Movie Channel West
~ WWOR	WWOR (New Jersey)
5:15	


uniden 4800 Integrated Control Panel				
The Movie Channel East				
NOW PLAYING				
Magic Moments				
SATELLITE	2498	CH	START	LENGTH
GALAXY G1	10	5:00	1:43	PLOC
OFF				
PUSH TO OPEN				
uniden 4800				
PUSH TO OPEN				
(SELECT) A Service				
5:15				

7. At this point you can view the new service:

- a. Press **VIEW** to go to the new service.




Note: If the service is not on the current satellite, you will see a graphic display while the **UST-4800 SUPER** automatically adjusts the satellite dish and tunes to the correct satellite channel.



Or cancel the change:

- b. Press **REC** to cancel any change(s) and return to the program you were watching.



Changing Satellites

1. Press **REC** to display the Integrated Control Panel.

2. If the **SATELLITE** Field is not highlighted, use **W▶** or **◀E** to move the highlight to **SATELLITE**.

uniden 4800 Integrated Control Panel					
The Family Channel East					
NOW PLAYING					
Hardcastle & McCormick					
SATELLITE	2498	CH	START	LENGTH	PLOC
GALAXY G1	11		5:00	1:00	OFF
PUSH TO OPEN					
uniden 4800					
PUSH TO OPEN					
(SELECT) A Service 5:15					

uniden 4800 Integrated Control Panel					
The Family Channel East					
NOW PLAYING					
Hardcastle & McCormick					
SATELLITE	2498	CH	START	LENGTH	PLOC
GALAXY G1	11		5:00	1:00	OFF
PUSH TO OPEN					
uniden 4800					
PUSH TO OPEN					
(SELECT) A Satellite 5:15					

There are two different methods used to change the satellite.

3. Use **▼** and **▲** to directly change to a different satellite. Then press

Note: The **SERVICE** and **NOW PLAYING** information will change as well as the **SATELLITE** Field.

uniden 4800 Integrated Control Panel					
Encore					
NOW PLAYING					
Hardcastle & McCormick					
SATELLITE		CH	START	LENGTH	PLOC
SATCOM F3		11			OFF
PUSH TO OPEN					
uniden 4800					
PUSH TO OPEN					
(SELECT) A Satellite 5:15					

Or...

4. Use the SuperGuide screens to select and change the satellite.

a. Press **SELECT** to see a list of available satellites.

Choose A Satellite	
F1	SATCOM C1 •
▶ G1	GALAXY G1 •
F3	SATCOM F3 •
T3	TELSTAR T3 •
W5	WESTAR W5 •
S1	SPACENET S1 •
A2	ANIK D2 •
AD	ANIK D1 •
W4	WESTAR W4 •
T1	TELSTAR T1 •
G3	GALAXY G3 •
S3	SPACENET S3 •

Choose A Satellite 5:15

b. Use **W▶** to see the next page(s) or **◀F** to see the previous page(s) of the satellite listings, if desired.

Choose A Satellite	
▶ T2	TELSTAR T2 •
F4	SATCOM F4 •
G2	GALAXY G2 •
F2	SATCOM F2 •
S2	SPACENET S2 •
S4	SPACENET •

Choose A Satellite 5:15

c. When you see the the satellite you want in the list, use **▼** and **▲** to move the pointer to highlight the satellite.

Choose A Satellite	
F1	SATCOM C1 •
G1	GALAXY G1 •
▶ F3	SATCOM F3 •
T3	TELSTAR T3 •
W5	WESTAR W5 •
S1	SPACENET S1 •
A2	ANIK D2 •
AD	ANIK D1 •
W4	WESTAR W4 •
T1	TELSTAR T1 •
G3	GALAXY G3 •
S3	SPACENET S3 •

Choose A Satellite 5:15


d. Press **SELECT** to select the satellite.

Note: The **SERVICE** and **NOW PLAYING** information will change as well as the **SATELLITE** Field.

uniden 4800 Integrated Control Panel				
Encore				
NOW PLAYING				
SATELLITE	CH	START	LENGTH	PLOC
SATCOM F3	11			OFF
PUSH TO OPEN				
uniden 4800				
PUSH TO OPEN				
(SELECT) A Satellite 5:15				


5. At this point you can move to the new satellite:

- a. Press **VIEW** to go to the new satellite. You will see a graphic display while the **UST-4800 SUPER** automatically adjusts the satellite dish.



Or cancel the change:

- b. Press **REC** to cancel any change(s) and return to the program you were watching.



Changing Channels on the Current Satellite

1. Press **REC** to display the Integrated Control Panel.

uniden 4800 Integrated Control Panel					
The Family Channel East					
NOW PLAYING					
Hardcastle & McCormick					
SATELLITE	2498	CH	START	LENGTH	PLOC
GALAXY G1		11	5:00	1:00	OFF
PUSH TO OPEN					
uniden 4800					
PUSH TO OPEN					
(SELECT) A Service 5:15					

2. If the **CH** Field is not highlighted, use **W▶** or **◀E** to move the highlight to **CH**.

uniden 4800 Integrated Control Panel					
The Family Channel East					
NOW PLAYING					
Hardcastle & McCormick					
SATELLITE	2498	CH	START	LENGTH	PLOC
GALAXY G1		11	5:00	1:00	OFF
PUSH TO OPEN					
uniden 4800					
PUSH TO OPEN					
(SELECT) A Channel 5:15					

There are two different methods used to change the channel: The Direct Method, and The SuperGuide Screens Method.

3. The Direct Method:


- a. Use **▼** and **▲** to change to a different channel.

uniden 4800 Integrated Control Panel					
The Movie Channel East					
NOW PLAYING					
Magic Moments					
SATELLITE	2498	CH	START	LENGTH	PLOC
GALAXY G1		10	5:00	1:43	OFF
PUSH TO OPEN					
uniden 4800					
PUSH TO OPEN					
(SELECT) A Channel 5:15					

Or...

- b. Use the numeric keys on the UST 4800r remote control to type the channel number directly.

Note: If you do not type the "0" for channels "01" through "09", the **UST-4800 SUPER** will wait 3 seconds and then automatically add the "0". If you want to return to the previously selected channel and satellite, type "00".



4. SuperGuide Screens Method:

- a. Press **SELECT** to see a list of available channels.

G1 GALAXY G1	
1 ≈	The Comedy Channel
2 ≈	The Nashville Network
3 ≈	WGN
4 ≈	Disney Channel East
5 ≈	Showtime East
6	
7 ≈	Cable News Network
8 ≈	CNN Headline News
9 ≈	ESPN Sports
10 ≈	The Movie Channel East
▶ 11 ≈	The Family Channel East
12 ≈	Arts & Entertainment
5:15	

- b. Use **W▶** to see the next page(s) or **◀E** to see the previous page(s) of the channel listings, as desired.

G1 GALAXY G1	
▶ 13	Country Music Television
14 ≈	The Movie Channel West
15 ≈	WWOR (New Jersey)
16 ≈	Showtime West
17 ≈	TNT
18 ≈	WTBS (Atlanta)
19 ≈	Cinemax East
20	Galavision (Spanish)
21 ≈	USA Network East
22 ≈	Discovery Channel
23 ≈	Home Box Office East
24 ≈	Disney Channel West
5:15	

- c. Use **▼** and **▲** to move the pointer to highlight the channel you want.


G1 GALAXY G1	
1 ≈	The Comedy Channel
2 ≈	The Nashville Network
3 ≈	WGN
4 ≈	Disney Channel East
5 ≈	Showtime East
6	
7 ≈	Cable News Network
8 ≈	CNN Headline News
9 ≈	ESPN Sports
▶ 10 ≈	The Movie Channel East
11 ≈	The Family Channel East
12 ≈	Arts & Entertainment
5:15	

d. Press **SELECT** to select the channel.

uniden 4800 Integrated Control Panel					
The Movie Channel East					
NOW PLAYING					
Magic Moments					
SATELLITE	2498	CH	START	LENGTH	PLOC
GALAXY G1	10		5:00	1:43	OFF
PUSH TO OPEN					
uniden 4800					
PUSH TO OPEN					
(SELECT) A Channel					5:15


5. At this point you can:

a. Press **VIEW** to go to the new channel.



Or ...

b. Press **REC** to cancel any change(s) and return to the program you were watching.



Locking Out Channels

1. Press **REC** to display the Integrated Control Panel.

uniden 4800 Integrated Control Panel					
The Movie Channel East					
NOW PLAYING					
Magic Moments					
SATELLITE	2498	CH	START	LENGTH	PLOC
GALAXY G1	10		5:00	1:43	OFF
PUSH TO OPEN					
uniden 4800					
PUSH TO OPEN					
					5:15

2. If the **PLOC** Field is not highlighted, use **W** or **←** to move the highlight to **PLOC**.
3. Press **SELECT** to turn **PLOC ON**. A screen will appear to prompt you for the password
4. Use the numeric keys on the remote control to enter the four digit password set up during installation.
5. As soon as you enter the last digit, the Integrated Control Panel will reappear indicating that the channel is locked.

uniden 4800 Integrated Control Panel					
The Movie Channel East					
NOW PLAYING					
Magic Moments					
SATELLITE	2498	CH	START	LENGTH	PLOC
GALAXY G1	10	5:00	1:43	OFF	
PUSH TO OPEN					
uniden 4800					
PUSH TO OPEN					
Enable/Disable Parental Lock 5:15					

Enter Parental Lock Password	
Password:	
Enter Password 5:15	

Enter Parental Lock Password	
Password: ****	
Enter Password 5:15	

uniden 4800 Integrated Control Panel					
The Movie Channel East					
NOW PLAYING					
Magic Moments					
SATELLITE	2498	CH	START	LENGTH	PLOC
GALAXY G1	10	5:00	1:43	ON	
PUSH TO OPEN					
uniden 4800					
PUSH TO OPEN					
Enable/Disable Parental Lock 5:15					

Note: If you type the wrong password, the screen in step 2 reappears indicating that you did not lock out that channel.

Unlocking Channels

1. Press **REC** to display the Integrated Control Panel.
2. If the **PLOC** Field is not highlighted, use **W▶** or **◀E** to move the highlight to **PLOC**.
3. Press **SELECT** to turn **PLOC OFF**. A screen will appear to prompt you for the password
4. Use the numeric keys on the remote control to enter the four digit password set up during installation.

uniden 4800 Integrated Control Panel				
The Movie Channel East				
NOW PLAYING				
Magic Moments				
SATELLITE 2498	CH	START	LENGTH	PLOC
GALAXY G1	10	5:00	1:43	ON
PUSH TO OPEN				
uniden 4800				
PUSH TO OPEN				
(SELECT) A Service 5:15				

uniden 4800 Integrated Control Panel				
The Movie Channel East				
NOW PLAYING				
Magic Moments				
SATELLITE 2498	CH	START	LENGTH	PLOC
GALAXY G1	10	5:00	1:43	ON
PUSH TO OPEN				
uniden 4800				
PUSH TO OPEN				
Enable/Disable Parental Lock 5:15				

Enter Parental Lock Password	
Password:	
Enter Password 5:15	

Enter Parental Lock Password	
Password: ●●●●	
Enter Password 5:15	

5. As soon as you enter the last digit, the Integrated Control Panel will appear indicating that the channel is unlocked.

uniden 4800 Integrated Control Panel				
The Movie Channel East				
NOW PLAYING				
Magic Moments				
SATELLITE 2498	CH	START	LENGTH	PLOC
GALAXY G1	10	5:00	1:43	OFF
PUSH TO OPEN				
uniden 4800				
PUSH TO OPEN				
Enable/Disable Parental Lock				5:15

Note: If you type the wrong password, the screen in step 2 reappears indicating that the channel is still locked.




Viewing a Locked Channel

If you have set the Parental Lock for a particular channel, you must temporarily unlock it before you can watch any programs on that channel

1. Use the SuperGuide Listings to select a program, or the Integrated Control Panel to select a satellite and channel.
2. Press **V.V.W.** to go to the channel.




Note: If the Program is not on the current satellite, you will see a graphic display while the **UST-4800 SUPER** automatically adjusts the satellite dish and tunes to the correct satellite channel.

3. If Parental Lock is in effect, a program description screen will appear with the word **LOCKED** at the bottom.

Automatic Dish Movement in Progress	
	 S1
Moving to G1	
	
Current Position is: 2652	
Target Position is: 3000	
Press Any Key to Stop Dish	
5:15	

Listings For Tuesday, May 29		5:00 PM
TMC E The Movie Channel East		
"Magic Moments"		
(1989) 'NR' (1:43) * *		
A famous magician's lover produces the TV show on which he plans to be burned at the stake.		
John Shea, Jenny Seagrove, Paul Freeman		
LOCKED		
(SELECT) To Enter Password		5:15

4. Press **SELECT** to get to the Password screen.
5. Use the numeric keys on the remote control to type the four digit password.
6. As soon as you enter the last digit, the program you have selected will appear indicating that the channel is unlocked.



Note: If you type the wrong password, the screen in step 3 reappears indicating that the channel is still locked.

Note: If you later change channels and then return to a channel you temporarily unlocked, it will be locked again, and you must enter the password to view a program on that channel.

Using the Middle Panel

The audio for each channel was set when your **UST-4800 SUPER** was installed. However, if you wish to change the audio settings for any reason (to view an occasional feed on the Ku band, etc.) you can do so using the Middle Panel.

1. Press **REC** to display the Integrated Control Panel.

uniden 4800 Integrated Control Panel					
The Family Channel East					
NOW PLAYING					
Hardcastle & McCormick					
SATELLITE 2498	CH 11	START 5:00	LENGTH 1:00	PLOC OFF	
GALAXY G1					
PUSH TO OPEN					
uniden 4800					
PUSH TO OPEN					
(SELECT) A Service 5:15					

2. If the Middle Panel is not open, use **W▶** or **◀E** to highlight the **PUSH TO OPEN** Field in the Middle Panel.

uniden 4800 Integrated Control Panel					
The Family Channel East					
NOW PLAYING					
Hardcastle & McCormick					
SATELLITE 2498	CH 11	START 5:00	LENGTH 1:00	PLOC OFF	
GALAXY G1					
PUSH TO OPEN					
uniden 4800					
PUSH TO OPEN					
5:15					

3. Press **SELECT** to open the Middle Panel.

uniden 4800 Integrated Control Panel					
The Family Channel East					
NOW PLAYING					
Hardcastle & McCormick					
SATELLITE 2498	CH 11	START 5:00	LENGTH 1:00	PLOC OFF	
GALAXY G1					
SIG	PUSH TO CLOSE		VOL		
AUDIO L 6.80 N	AUDIO MODE Discrete		AUDIO R 5.00 N		
SIG			SIG		
PUSH TO OPEN					
5:15					

The Signal Strength Meter (**SIG**) just to the left of the **PUSH TO CLOSE** Field indicates the strength of the received satellite signal.

The Volume Indicator (**VOL**) just to the right of the **PUSH TO CLOSE** Field indicates the output volume of the **UST-4800 SUPER** receiver. Use the **▲VOLUME▼** keys to adjust the output volume.

Note: The actual volume you get is a function of the volume setting of the TV set, or the speakers and/or amplifiers you have connected to the **UST-4800 SUPER**.

Changing the Audio Mode

1. If the **AUDIO MODE** Field is not highlighted, use **W▶** or **◀E** to move the highlight to **AUDIO MODE**.
2. Use **▼** and **▲** to select one of the following modes:

Mono. This sets the audio mode to monaural. The sound will come out of both speakers, but will be the same monaural audio, not stereo.

Discrete. This sets the audio mode to stereo. The sound coming from the left and right speakers will be stereo.

VCII. This sets the audio mode so digital stereo broadcast on VideoCipher II® channels can be received digitally by the **UST-4800 SUPER**.

Note: Although digital stereo may be received by the **UST-4800 SUPER**, it is converted to analog stereo within the VideoCipher II module. The sound coming from the speakers will be analog stereo.

uniden 4800 Integrated Control Panel				
The Family Channel East				
NOW PLAYING				
Hardcastle & McCormick				
SATELLITE 2498	CH	START	LENGTH	PLOC
GALAXY G1	11	5:00	1:00	OFF
SIG	PUSH TO CLOSE		VOL	
AUDIO L 6.80 N	AUDIO MODE Discrete		AUDIO R 5.00 N	
SIG	PUSH TO OPEN		SIG	
Audio Mode ((SELECT) =DNR)				
			5:15	

uniden 4800 Integrated Control Panel				
The Family Channel East				
NOW PLAYING				
Hardcastle & McCormick				
SATELLITE 2498	CH	START	LENGTH	PLOC
GALAXY G1	11	5:00	1:00	OFF
SIG	PUSH TO CLOSE		VOL	
AUDIO L 6.80 N	AUDIO MODE Mono		AUDIO R	
SIG				
PUSH TO OPEN				
Audio Mode ((SELECT) =DNR)				
5:15				

uniden 4800 Integrated Control Panel				
The Family Channel East				
NOW PLAYING				
Hardcastle & McCormick				
SATELLITE 2498	CH	START	LENGTH	PLOC
GALAXY G1	11	5:00	1:00	OFF
SIG	PUSH TO CLOSE		VOL	
AUDIO L 6.80 N	AUDIO MODE Discrete		AUDIO R 5.00 N	
SIG	PUSH TO OPEN		SIG	
Audio Mode ((SELECT) =DNR)				
			5:15	

uniden 4800 Integrated Control Panel				
The Family Channel East				
NOW PLAYING				
Hardcastle & McCormick				
SATELLITE 2498	CH	START	LENGTH	PLOC
GALAXY G1	11	5:00	1:00	OFF
SIG	PUSH TO CLOSE		VOL	
AUDIO L	AUDIO MODE VCI		AUDIO R	
PUSH TO OPEN				
Audio Mode ((SELECT) =DNR) 5:15				

3. You can also turn **DNR** (Dynamic Noise Reduction) on to reduce any background noise you hear on the channel. Press **SELECT** to turn **DNR** on or off. When Dynamic Noise Reduction is on, **DNR** displays beneath the Audio Mode (**Mono**, **Discrete**, or **VCII**).

uniden 4800 Integrated Control Panel					
The Family Channel East					
NOW PLAYING					
Hardcastle & McCormick					
SATELLITE 2498	CH	START	LENGTH	PLOC	
GALAXY G1	11	5:00	1:00	OFF	
SIG	PUSH TO CLOSE		VOL		
AUDIO L	AUDIO MODE		AUDIO R		
6.80 N	Discrete		5.00 N		
SIG	DNR		SIG		
PUSH TO OPEN					
Audio Mode ((SELECT) = DNR) 5:15					

Setting the Left and Right Audio for a particular channel.

Note: You cannot adjust the Left and Right Audio in **VCII** Audio Mode. In **Mono** Audio Mode you can set only the Left Audio.

1. If the **AUDIO L** Field is not highlighted, use **W▶** or **◀E** to move the highlight to **AUDIO L**.

uniden 4800 Integrated Control Panel					
The Family Channel East					
NOW PLAYING					
Hardcastle & McCormick					
SATELLITE 2498	CH	START	LENGTH	PLOC	
GALAXY G1	11	5:00	1:00	OFF	
SIG	PUSH TO CLOSE		VOL		
AUDIO L	AUDIO MODE		AUDIO R		
6.80 N	Discrete		5.00 N		
SIG			SIG		
PUSH TO OPEN					
Audio L Frequency ((SELECT) = BW) 5:15					

2. The audio carrier frequency for the Left Audio is displayed in MHz. Press **▲** or **▼** to tune the frequency.

Each time you press **▲**, the carrier frequency increases by 10 kHz. Each time you press **▼**, the carrier frequency decreases by 10 kHz.

uniden 4800 Integrated Control Panel					
The Family Channel East					
NOW PLAYING					
Hardcastle & McCormick					
SATELLITE 2498	CH	START	LENGTH	PLOC	
GALAXY G1	11	5:00	1:00	OFF	
SIG	PUSH TO CLOSE		VOL		
AUDIO L	AUDIO MODE		AUDIO R		
6.83 W	Discrete		5.00 N		
SIG			SIG		
PUSH TO OPEN					
Audio L Frequency ((SELECT) = BW) 5:15					

Or...

Use the number keys on the remote control to type in the new carrier frequency directly.

3. Press **SELECT** to select the audio bandwidth. You can switch between wide (W) and narrow (N). The corresponding letter will appear next to the frequency.

Note: If you select a particular bandwidth and you hear static in the audio, press **SELECT** to switch to the other bandwidth.

4. A signal strength indicator beneath the frequency shows how strong the received audio signal is.
5. Use **W▶** or **◀E** to move the highlight to **AUDIO R**.

uniden 4800 Integrated Control Panel					
The Family Channel East					
NOW PLAYING					
Hardcastle & McCormick					
SATELLITE	2498	CH	START	LENGTH	PLOC
GALAXY G1	11	5:00	1:00	OFF	
SIG	PUSH TO CLOSE			VOL	
AUDIO L 6.83 N	AUDIO MODE Discrete			AUDIO R 5.00 N	
SIG	PUSH TO OPEN			SIG	
Audio L Frequency ((SELECT) = BW)				5:15	

uniden 4800 Integrated Control Panel					
The Family Channel East					
NOW PLAYING					
Hardcastle & McCormick					
SATELLITE 2498	CH 11	START 5:00	LENGTH 1:00	PLOC OFF	
GALAXY G1					
SIG	PUSH TO CLOSE			VOL	
AUDIO L 6.80 N	AUDIO MODE Discrete			AUDIO R 5.00 N	
SIG	PUSH TO OPEN			SIG	
Audio R Frequency (SELECT) = BW				5:15	

6. Repeat steps "2" through "5" to adjust the Right Audio.

Exiting the Middle Panel

1. After you make changes to any of the settings in the Middle Panel, you have two choices:
 - a. You can make changes in **AUDIO L**, **AUDIO R**, and/or **AUDIO MODE** permanent for this satellite and channel by pressing **CUST**.
 - Or ...
 - b. You can make the changes temporary for this satellite and channel by pressing **VIEW**. The changes will remain in effect until you change channels or satellites. When you return to this channel and satellite, the settings will revert to the standard settings.


2. You can cancel any permanent changes you have previously made for this channel and satellite by pressing **SID**.

When you have finished making adjustments to the audio, you can leave the Middle Panel open or close it.

2. To close the Middle Panel, use **W▶** or **◀P** to move the highlight to **PUSH TO CLOSE**, and press **SELECT**.

3. You can now press **VIEW** to continue watching satellite television.

uniden 4800 Integrated Control Panel					
The Family Channel East					
NOW PLAYING					
Hardcastle & McCormick					
SATELLITE	2498	CH	START	LENGTH	PLOC
GALAXY G1		11	5:00	1:00	OFF
PUSH TO OPEN					
uniden 4800					
VFT	PUSH TO CLOSE			SKW	
POL	TI	RF	TV OUTPUT	VCR OUTPUT	
H	OFF	C	VCI OUTPUT	VCI Recx.	
5:15					



Using the Bottom Panel

Use the Bottom Panel to adjust settings for the incoming satellite signal, and the audio/video outputs of the **UST-4800 SUPER** to the TV and VCR. The adjustments in the Bottom Panel were set when your **UST-4800 SUPER** was installed and normally do not need to be changed. However, if you wish to change these settings for any reason (a new VCR, etc.) you can do so using the Bottom Panel.

1. Press **REC** to display the Integrated Control Panel.

uniden 4800 Integrated Control Panel					
The Family Channel East					
NOW PLAYING					
Hardcastle & McCormick					
SATELLITE	2498	CH	START	LENGTH	PLOC
GALAXY G1	11		5:00	1:00	OFF
PUSH TO OPEN					
uniden 4800					
PUSH TO OPEN					
(SELECT) A Service 5:15					

2. If the Bottom Panel is not open, use **W▶** or **◀E** to move the highlight box to the **PUSH TO OPEN** Field in the Bottom Panel.

uniden 4800 Integrated Control Panel					
The Family Channel East					
NOW PLAYING					
Hardcastle & McCormick					
SATELLITE	2498	CH	START	LENGTH	PLOC
GALAXY G1	11		5:00	1:00	OFF
PUSH TO OPEN					
uniden 4800					
PUSH TO OPEN					
5:15					

3. Press **SELECT** to open the Bottom Panel.

uniden 4800 Integrated Control Panel					
The Family Channel East					
NOW PLAYING					
Hardcastle & McCormick					
SATELLITE	2498	CH	START	LENGTH	PLOC
GALAXY G1	11		5:00	1:00	OFF
PUSH TO OPEN					
uniden 4800					
VFT	PUSH TO CLOSE		SKW I.....	
POL	TI	RF	TV OUTPUT	VCR OUTPUT	
H	OFF	C	VCR OUTPUT	VCR/Recv.	
(SELECT) Polarity 5:15					

Tuning the Satellite Signal

1. The **VFT** indicator in the top left-hand corner of the Bottom Panel indicates the video fine tuning. You would not normally make any adjustment to this setting. However, if there is objectionable interference to the signal, you can try making small adjustments with the **VIDEO** keys. As you adjust the tuning, the **VFT** indicator will change accordingly.
2. The **SKW** indicator in the top right-hand corner of the Bottom Panel indicates the amount of skew of the polarizer. You would not normally make any adjustment to this setting. However, if there is rotation in the position of the satellite, you may need to make small adjustments to this setting with the **SKW** keys. As you adjust the skew, the **SKW** indicator will change accordingly.

uniden 4800 Integrated Control Panel									
The Family Channel East									
NOW PLAYING									
Hardcastle & McCormick									
SATELLITE	2498	CH	START	LENGTH	PLOC				
GALAXY G1	11	5:00	1:00	OFF					
PUSH TO OPEN									
uniden 4800									
VFT	PUSH TO CLOSE		SKW						
POL	TI	RF	TV OUTPUT	VCR OUTPUT					
H	OFF	C	VCI OUTPUT	VCI/Recv.					
5:15									

uniden 4800 Integrated Control Panel									
The Family Channel East									
NOW PLAYING									
Hardcastle & McCormick									
SATELLITE	2498	CH	START	LENGTH	PLOC				
GALAXY G1	11	5:00	1:00	OFF					
PUSH TO OPEN									
uniden 4800									
VFT	PUSH TO CLOSE		SKW						
POL	TI	RF	TV OUTPUT	VCR OUTPUT					
H	OFF	C	VCI OUTPUT	VCI/Recv.					
5:15									

Changing Channel Polarity

The polarity of a satellite channel (either horizontal or vertical) is established by the orientation of the satellite. Once your **UST-4800 SUPER** is installed, you should not need to adjust this setting. (Changing the polarity may cause loss of signal.)

If you do need to change the setting:

1. Use **W** or **E** to move the highlight box to the **POL**.

uniden 4800 Integrated Control Panel									
The Family Channel East									
NOW PLAYING									
Hardcastle & McCormick									
SATELLITE	2498	CH	START	LENGTH	PLOC				
GALAXY G1	11	5:00	1:00	OFF					
PUSH TO OPEN									
uniden 4800									
VFT	PUSH TO CLOSE		SKW						
POL	TI	RF	TV OUTPUT	VCR OUTPUT					
H	OFF	C	VCI OUTPUT	VCI/Recv.					
(SELECT) Polarity 5:15									

2. Press **▼**, **▲**, or **SELECT** to switch between horizontal (H) and vertical (V) polarity.

Note: If you change the polarity and cannot get picture or sound, change it back.

Or ...

3. Press **TAPE** to switch between horizontal (H) and vertical (V) polarity.

Note: You do not have to have the **POL** field highlighted if you use **TAPE** to switch polarity.

If you change the polarity and cannot get picture or sound, change it back.

uniden 4800 Integrated Control Panel					
The Family Channel East					
NOW PLAYING					
Hardcastle & McCormick					
SATELLITE	2498	CH	START	LENGTH	PLOC
GALAXY G1	11		5:00	1:00	OFF
PUSH TO OPEN					
uniden 4800					
VFT	PUSH TO CLOSE		SKW		
POL	TI	RF	TV OUTPUT	VCR OUTPUT	
V	OFF	C	VCR OUTPUT	VCR Recv.	
(SELECT) Polarity					5:15

The Terrestrial Interference Filter

If you are experiencing Terrestrial Interference (snowy video, sparkles, or a distorted picture,) on any channel, you may improve your reception by turning the TI Filter on.

1. Use **W▶** or **◀E** to move the highlight box to TI.

uniden 4800 Integrated Control Panel					
The Family Channel East					
NOW PLAYING					
Hardcastle & McCormick					
SATELLITE	2498	CH	START	LENGTH	PLOC
GALAXY G1	11		5:00	1:00	OFF
PUSH TO OPEN					
uniden 4800					
VFT	PUSH TO CLOSE		SKW		
POL	TI	RF	TV OUTPUT	VCR OUTPUT	
H	OFF	C	VCR OUTPUT	VCR Recv.	
(SELECT) Terrestrial Filter					5:15

2. Press **SELECT**, **▼**, or **▲** to turn the Terrestrial Interference Filter **ON** or **OFF**.

uniden 4800 Integrated Control Panel									
The Family Channel East									
NOW PLAYING									
Hardcastle & McCormick									
SATELLITE 2498		CH	START	LENGTH	PLOC				
GALAXY G1		11	5:00	1:00	OFF				
PUSH TO OPEN									
uniden 4800									
VFT		PUSH TO CLOSE		SKW					
POL	TI	RF	TV OUTPUT		VCR OUTPUT				
H	ON	C	VCI OUTPUT		VCI/Recv.				
(SELECT) Terrestrial Filter 5:15									

Changing the Satellite Band

Most satellite TV programs are broadcast on the C-band. However, in the next few years a strong growth is expected in the Ku-band. If your TVRO satellite system was installed to receive Ku-Band signals, you can adjust the **UST-4800 SUPER** for this satellite band.

1. Use **W▶** or **◀E** to move the highlight box to **RF**.

uniden 4800 Integrated Control Panel									
The Family Channel East									
NOW PLAYING									
Hardcastle & McCormick									
SATELLITE 2498		CH	START	LENGTH	PLOC				
GALAXY G1		11	5:00	1:00	OFF				
PUSH TO OPEN									
uniden 4800									
VFT		PUSH TO CLOSE		SKW					
POL	TI	RF	TV OUTPUT		VCR OUTPUT				
H	ON	C	VCI OUTPUT		VCI/Recv.				
(SELECT) RF Source 5:15									

2. Press **SELECT**, **▼**, or **▲** to switch between **C** and **Ku**.

Note: If you change the band and cannot get picture or sound, switch the band back.

uniden 4800 Integrated Control Panel									
The Family Channel East									
NOW PLAYING									
Hardcastle & McCormick									
SATELLITE 2498		CH	START	LENGTH	PLOC				
GALAXY G1		11	5:00	1:00	OFF				
PUSH TO OPEN									
uniden 4800									
VFT		PUSH TO CLOSE		SKW					
POL	TI	RF	TV OUTPUT		VCR OUTPUT				
H	ON	Ku	VCI OUTPUT		VCI/Recv.				
(SELECT) RF Source 5:15									

Changing the TV Output

The video and audio outputs to your TV set can be switched from the **UST-4800 SUPER** satellite reception to either of two external audio-video sources (typically a VCR and/or videodisc player) connected to the back of the **UST-4800 SUPER**.

1. If the **TV OUTPUT** Field is not highlighted, use **W▶** or **◀L** to move the highlight box to **TV OUTPUT**.

uniden 4800 Integrated Control Panel						
The Family Channel East						
NOW PLAYING						
Hardcastle & McCormick						
SATELLITE	2498	CH	START	LENGTH	PLOC	
GALAXY G1		11	5:00	1:00	OFF	
PUSH TO OPEN						
uniden 4800						
VFT	...	I	PUSH TO CLOSE		SKW	...
POL	TI	RF	TV OUTPUT		VCR OUTPUT	
H	ON	C	VCI OUTPUT		VCI/Recv.	
(SELECT) TV Source						5:15

2. Use **SELECT**, **▼**, or **▲** to choose one of the following outputs to your TV set:

VCII OUTPUT. The video and audio to the TV set come from the output of the VideoCipher II module within the **UST-4800 SUPER**, providing you are viewing a channel that is VideoCipher II encrypted.

Note: The picture will be scrambled on VideoCipher II channels unless you have a subscription to the service on this channel.

uniden 4800 Integrated Control Panel						
The Family Channel East						
NOW PLAYING						
Hardcastle & McCormick						
SATELLITE	2498	CH	START	LENGTH	PLOC	
GALAXY G1		11	5:00	1:00	OFF	
PUSH TO OPEN						
uniden 4800						
VFT	...	I	PUSH TO CLOSE		SKW	...
POL	TI	RF	TV OUTPUT		VCR OUTPUT	
H	ON	C	VCI OUTPUT		VCI/Recv.	
(SELECT) TV Source						5:15

Receiver The video and audio to the TV set come from the output of the **UST-4800 SUPER** without passing through the VideoCipher II module.

Note: The picture will be scrambled on VideoCipher II channels even if you have a subscription to the service on this channel.

uniden 4800 Integrated Control Panel						
The Family Channel East						
NOW PLAYING						
Hardcastle & McCormick						
SATELLITE	2498	CH	START	LENGTH	PLOC	
GALAXY G1		11	5:00	1:00	OFF	
PUSH TO OPEN						
uniden 4800						
VFT	...	I	PUSH TO CLOSE		SKW	...
POL	TI	RF	TV OUTPUT		VCR OUTPUT	
H	ON	C	Receiver		VCI/Recv.	
(SELECT) TV Source						5:15

EXTERNAL 1 or EXTERNAL 2 The video and audio to the TV set come from the video source (typically a VCR or videodisc player) connected to the corresponding (**EXTERNAL 1** or **EXTERNAL 2**) inputs on the back of the **UST-4800 SUPER**.

Note: These inputs can be customized at installation with names such as: **VCR, DISC, GAMES, etc.**

uniden 4800 Integrated Control Panel					
The Family Channel East					
NOW PLAYING					
Hardcastle & McCormick					
SATELLITE	2498	CH	START	LENGTH	PLOC
GALAXY G1	11	5:00	1:00	OFF	
PUSH TO OPEN					
uniden 4800					
VFT	TI	RF	PUSH TO CLOSE	SKW	
POL	ON	C	TV OUTPUT	VCR OUTPUT	
H			EXTERNAL 1	VCR/Rec.	
(SELECT) TV Source					5:15

Changing the VCR Output

If you have a VCR connected to the back of the **UST-4800 SUPER**, you can switch the video and audio to the VCR to come from the **UST-4800 SUPER** or from either of two external video sources. The are typically a VCR and/or videodisc player connected to the back of the **UST-4800 SUPER**.


1. If the **VCR OUTPUT** Field is not highlighted, use **W** or **E** to move the highlight box to **VCR OUTPUT**.

uniden 4800 Integrated Control Panel					
The Family Channel East					
NOW PLAYING					
Hardcastle & McCormick					
SATELLITE	2498	CH	START	LENGTH	PLOC
GALAXY G1	11	5:00	1:00	OFF	
PUSH TO OPEN					
uniden 4800					
VFT	TI	RF	PUSH TO CLOSE	SKW	
POL	ON	C	TV OUTPUT	VCR OUTPUT	
H			VCR OUTPUT	VCR/Rec.	
(SELECT) VCR Source					5:15

2. **P**
C

▼, or **▲** to choose one of the
s to your VCR:

Not
soun



and audio to the VCR come
the **UST-4800 SUPER**.

scrambled on VideoCipher II
description to the service

uniden 4800 Integrated Control Panel					
The Family Channel East					
NOW PLAYING					
Hardcastle & McCormick					
SATELLITE	2498	CH	START	LENGTH	PLOC
GALAXY G1	11	5:00	1:00	OFF	
PUSH TO OPEN					
uniden 4800					
VFT	TI	RF	PUSH TO CLOSE	SKW	
POL	ON	C	TV OUTPUT	VCR OUTPUT	
H			VCR OUTPUT	VCR/Rec.	
(SELECT) VCR Source					5:15

EXTERNAL 1 or **EXTERNAL 2** The video and audio to the VCR come from the video source (typically a VCR or videodisc player) connected to the corresponding (**EXTERNAL 1** or **EXTERNAL 2**) inputs on the back of the **UST-4800 SUPER**.

Note: These inputs can be customized at installation with names such as: **VCR**, **DISC**, etc.

uniden 4800 Integrated Control Panel					
The Family Channel East					
NOW PLAYING					
Hardcastle & McCormick					
SATELLITE	2498	CH	START	LENGTH	PLOC
GALAXY G1	11	5:00	1:00	OFF	
PUSH TO OPEN					
uniden 4800					
VFT	...	PUSH TO CLOSE	SKW		
POL	TI	RF	TV OUTPUT	VCR OUTPUT	
H	ON	C	VCR OUTPUT	EXTERNAL 1	
(SELECT) VCR Source					5:15

SUPERGUIDE Some SuperGuide screens may be output to the VCR. Uniden does not recommend using this option.

Exiting the Bottom Panel


1. After you make changes to any of the settings in the Bottom Panel, you have four choices:
 - a. You can make changes in **POL** and/or **TV OUTPUT** permanent for this satellite and channel by pressing **CUST**.
 - b. You can make the changes temporary for this satellite and channel by pressing **VIEW**. The changes will remain in effect until you change channels or satellites. When you return to this channel and satellite, the settings will revert to the standard settings.
 - c. You can cancel any previous customized changes for this channel and satellite by pressing **STD**.
 - d. You can leave the Integrated Control Panel without making any changes by pressing **REC**.

When you have finished making adjustments to the video, you can leave the Bottom Panel open or close it.

2. To close the Bottom Panel, use **W▶** or **◀E** to move the highlight box to **PUSH TO CLOSE**, and press **SELECT**.

3. You can now press **VIEW** to continue watching satellite television.

uniden 4800 Integrated Control Panel					
The Family Channel East					
NOW PLAYING					
Hardcastle & McCormick					
SATELLITE 2498	CH	START	LENGTH	PLOC	
GALAXY G1	11	5:00	1:00	OFF	
PUSH TO OPEN					
uniden 4800					
VFT	PUSH TO CLOSE		SKW	
POL	TI	RF	TV OUTPUT		VCR OUTPUT
H	OFF	C	VCI OUTPUT		VCI/Recv.
					5:15



Direct Satellite Access


With the **UST-4800 SUPER** you can move your dish antenna directly to a programmed satellite without going through any SuperGuide menus or without using the Integrated Control Panel.

Note: You will be able to directly access only those satellites that have been programmed into your **UST-4800 SUPER** Integrated Receiver/Descrambler.

1. Be sure you in View mode.

If you are at any SuperGuide screen, press **GUIDE**.

If you are at the Integrated Control Panel, press **REC**.



2. Press **SELECT**. A graphic keypad will appear on the screen.

Note: If you do not press another key within about 15 seconds, the screen will go back to video.

Direct Satellite Entry:		
1 G	2 T	3 F
4 D	5 W	6 C
7 S	8 X	9 K
0-M		

5:15

3. Press a key to enter the letter code for the desired satellite.

For Example: To enter the code for Galaxy 1 (G1), press **1** for "G".

Sat: G

5:15


4. Next, press a key to enter the number code for the desired satellite.

For Example: To complete the code for Galaxy 1 (G1), press **1** for "1".

Sat: G1


5:15

5. If you have entered the code properly, the dish antenna will move to the desired satellite. You will see a graphic representation of the dish moving. The channel will be the same as the one on the satellite you were viewing.



Or ...

6. If you entered a code that did not match one of the programmed satellites, you will see this screen. In that case repeat steps 1 through 5 above using the correct code.



Use the following letter codes to move directly to a programmed satellite:

SATELLITE	LETTER CODE
Anik	D
Anik (Ku)	C
G Star	X
Galaxy	G
Morelos	M
Satcom	F
Satcom (Ku)	K
Spacenet	S
Telstar	T
Westar	W