
Ambient Weather WS-1400-IP OBSERVER Solar Powered Wireless IP Weather Station User Manual



Table of Contents

1.	Introduction	1
2.	Warnings and Cautions	2
3.	Quick Start Guide.....	2
4.	Pre-Installation Checkout and Site Survey.....	2
4.1	Pre Installation Checkout	2
4.2	Site Survey	2
5.	Getting Started	3
5.1	Parts List.....	3
5.2	Recommend Tools.....	5
5.3	Sensor Array Set Up.....	5
5.3.1	Install Wind Vane	6
5.3.2	Install Mounting Pole.....	7
5.3.1	Install Batteries.....	9
5.3.2	Mount Weather Station.....	11
5.3.3	Reset Button and Transmitter LED	13
5.4	Indoor Thermo-Hyrometer-Barometer Transmitter.....	14
5.5	Best Practices for Wireless Communication	15
5.6	ObserverIP Receiver.....	15
5.6.1	Hardware Requirements	15
5.6.2	Software Requirements	15
5.6.3	ObserverIP Connections.....	16
5.6.4	Finding the ObserverIP from your computer	17
5.6.5	Local Device Network Settings.....	19
5.6.6	Weather Network Settings.....	20
5.6.7	Station Settings.....	22
5.6.8	Live Data.....	23
5.6.9	Calibration.....	24
6.	Glossary of Terms	28
7.	Specifications.....	29
7.1	Wireless Specifications	29
7.2	Measurement Specifications.....	29
7.3	Power Consumption	30
8.	Maintenance.....	30
9.	Troubleshooting Guide.....	30
10.	Accessories.....	32
11.	Liability Disclaimer.....	32
12.	FCC Statement.....	33
13.	Warranty Information	33

1. Introduction

Thank you for your purchase of the WS-1400-IP OBSERVER Solar Powered Wireless WiFi Weather

Station. The following user guide provides step by step instructions for installation, operation and troubleshooting. To download the latest manual, firmware upgrades and IP Finder Tools, visit:

<http://www.ambientweather.com/observerip.html>

2. Warnings and Cautions

! Warning: Any metal object may attract a lightning strike, including your weather station mounting pole. Never install the weather station in a storm.

! Warning: Installing your weather station in a high location may result in injury or death. Perform as much of the initial check out and operation on the ground and inside a building or home. Only install the weather station on a clear, dry day.

3. Quick Start Guide

Although the manual is comprehensive, much of the information contained may be intuitive. In addition, the manual does not flow properly because the sections are organized by components.

The following Quick Start Guide provides only the necessary steps to install, operate the weather station, and upload to the internet, along with references to the pertinent sections.

Required		
Step	Description	Section
1	Assemble and power up the sensor array	5.3.1 - 5.3.1
2	Power up the indoor thermometer-hygrometer-barometer	5.4
3	Power up the ObserverIP, connect to your router and synchronize with sensor array and thermo-hygrometer-barometer.	5.6
6	Mount the sensor array	5.3.2
5	Calibrate the relative pressure to sea-level conditions (local airport) on console	5.6.9
7	Reset the rain to zero on console	5.6.9
9	Register and upload to Weather Server	5.6.6

4. Pre-Installation Checkout and Site Survey

4.1 Pre Installation Checkout

Before installing your weather station in the permanent location, we recommend operating the weather station for one week in a temporary location with easy access. This will allow you to check out all of the functions, insure proper operation, and familiarize you with the weather station and calibration procedures. This will also allow you to test the wireless range of the weather station.

4.2 Site Survey

Perform a site survey before installing the weather station. Consider the following:

1. You must clean the rain gauge every few months and change the rechargeable batteries every 2-3 years. Provide easy access to the weather station.
2. Avoid radiant heat transfer from buildings and structures. In general, install the sensor array at least 5' from any building, structure, ground, or roof top.
3. Avoid wind and rain obstructions. The rule of thumb is to install the sensor array at least four times the distance of the height of the tallest obstruction. For example, if the building is 20' tall, and the mounting pole is 6' tall, install $4 \times (20 - 6) = 56'$ away.




4. **Wireless Range.** The radio communication between receiver and transmitter in an open field can reach a distance of up to 330 feet, providing there are no interfering obstacles such as buildings, trees, vehicles, high voltage lines. Wireless signals will not penetrate metal buildings. Under most conditions, the maximum wireless range is 100’.
5. Radio interference such as PCs, radios or TV sets can, in the worst case, entirely cut off radio communication. Please take this into consideration when choosing ObserverIP receiver or mounting locations. Make sure your ObserverIP receiver is at least five feet away from any electronic device to avoid interference.
6. Visit Ambient Weather Mounting Solutions for assistance and ideas for mounting your weather station:







<http://www.ambientweather.com/amwemoso.html>


5. Getting Started

The WS-1000-WiFi weather station consists of a ObserverIP receiver, an all in one sensor array, and wireless thermo-hygrometer-barometer.

5.1 Parts List

QTY	Item	Image
1	ObserverIP Receiver Dimensions (LxWxH): 3x2x1”	
1	Thermo-hygrometer-barometer transmitter	
1	Thermo-hygrometer-barometer mounting bracket plus 3 mounting screws	

QTY	Item	Image
1	Sensor Array	
1	Wind Vane	
1	5V DC Adaptor	
1	Ethernet Cable	
2	Pole (straight and crimped)	
2	Pole mounting U-bolt	
4	Pole mounting clamps	
4	Pole mounting U-bolt nuts	
1	Allen wrench	

QTY	Item	Image
1	User manual	

5.2 Recommend Tools

- Precision screwdriver (for small Phillips screw on battery cover door)
- Adjustable wrench (for mounting pole)
- Compass or GPS (for wind direction calibration)

5.3 Sensor Array Set Up





Figure 1

No	Description	No	Description
1	Wind Vane (measures wind direction)	6	Reset button


2	Wind Speed Sensor (measures wind speed)	7	Thermo-hygrometer Sensor (measures temperature and humidity)
3	Solar collector	9	Solar Radiation Sensor
4	Rechargeable battery compartment	10	Rain Collector (self emptying)
5	LED transmission indicator (turns on for 4 seconds on power up, flashes once per 16 seconds)	11	Bubble Level

5.3.1 Install Wind Vane

Reference Figure 2. (a) Locate and align the flat key on the wind vane shaft to the flat key on the wind vane and push the vane on to the shaft. (b) tighten the set screw with the hex wrench (included).



(a)



(b)

Figure 2

5.3.2 Install Mounting Pole

Reference Figure 3. Remove the mounting pole collar by rotating counter clockwise.




Figure 3

Reference Figure 4. Locate and align the groove on the sensor array and mounting pole.




Figure 4

Reference Figure 5. Turn the mounting pole collar to lock the pole into place by rotating clockwise.




Figure 5

5.3.1 Install Batteries

Reference Figure 6. Locate the battery door on the bottom of the sensor array. Turn the set screw counter clockwise to open the battery compartment. Insert the 3xAA rechargeable batteries (included). The LED indicator on the bottom of the sensor array will turn on for four seconds and normally flash once per 16 seconds (the transmission update period).

Close the battery door and tighten the set screw.




Figure 6

5.3.2 Mount Weather Station

There are two methods for attaching your weather station:

A. Option 1: Mounting Clamps. Fasten the mounting pole to your mounting pole or bracket (purchased separately) with the two U-bolts, mounting pole brackets and nuts, as shown in Figure 7. Tighten the mounting pole to your mounting pole with the U-Bolt assembly.




Figure 7

B. Option 2: Swedged Pole Mount. Insert the swedged end of the included mounting pole into the open end of any standard mounting pole solution (1 3/8" diameter) available from Ambient Weather, as shown in Figure 8. For more information on mounting solutions, visit:

<http://www.ambientweather.com/amwemoso.html>




Figure 8

1. Reference Figure 9. Locate the four wind vane compass rose indicators of N, E, S, W (representing North, East, South and West). Align the compass rose direction upon final installation with a compass or GPS.




Figure 9

2. Reference Figure 10. Make sure the sensor array is completely level upon final installation. Failure to do so will result in inaccurate rain gauge readings.




Figure 10

5.3.3 Reset Button and Transmitter LED

In the event the sensor array is not transmitting, reset the sensor array.

With an open ended paperclip, press and hold the **RESET BUTTON** for three seconds to completely discharge the voltage.

Take out the batteries and wait one minute, while covering the solar panel to drain the voltage.

Put batteries back in and resynchronize with the ObserverIP receiver by powering down and up the ObserverIP receiver with the sensor array about 10 feet away.




Figure 11

5.4 Indoor Thermo-Hygrometer-Barometer Transmitter

The indoor thermometer, hygrometer and barometer measures and displays the indoor temperature, humidity and pressure and transmits this data to the ObserverIP receiver.






Figure 12

 **Note:** Do not install the thermo-hygrometer-barometer transmitter outside. This will cause errors in the barometric pressure due to large variations in temperature (barometric pressure is temperature compensated for accuracy). Note that pressure readings made inside your home, business, or facility will correspond closely to the actual barometric pressure outside.

 **Note:** The thermo-hygrometer-transmitter transmits directly to the ObserverIP receiver. For best results, place between 5 to 20 feet from the ObserverIP receiver.

 **Note:** To avoid permanent damage, please take note of the battery polarity before inserting the batteries.


Remove the battery door on the back of the sensor with a Philips screwdriver (there is only one screw, at the bottom of the unit). Insert two AAA batteries, as shown in Figure 13.

Replace the battery door and set screw. Note that the temperature, humidity and barometric pressure will be displayed on the LCD display. Looking at the back of the unit from left to right, the polarity is (-) (+) for the top battery and (+) (-) for the bottom battery.



Figure 13

5.5 Best Practices for Wireless Communication

 **Note:** To insure proper communication, mount the remote sensor(s) upright on a vertical surface, such as a wall. **Do not lay the sensor flat.**

Wireless communication is susceptible to interference, distance, walls and metal barriers. We recommend the following best practices for trouble free wireless communication.

1. **Electro-Magnetic Interference (EMI).** Keep the ObserverIP receiver several feet away from computer monitors and TVs.
2. **Radio Frequency Interference (RFI).** If you have other 433 MHz devices and communication is intermittent, try turning off these other devices for troubleshooting purposes. You may need to relocate the transmitters or receivers to avoid intermittent communication.
3. **Line of Sight Rating.** This device is rated at 300 feet line of sight (no interference, barriers or walls) but typically you will get 100 feet maximum under most real-world installations, which include passing through barriers or walls.
4. **Metal Barriers.** Radio frequency will not pass through metal barriers such as aluminum siding. If you have metal siding, align the remote and ObserverIP receiver through a window to get a clear line of sight.

The following is a table of reception loss vs. the transmission medium. Each “wall” or obstruction decreases the transmission range by the factor shown below.

Medium	RF Signal Strength Reduction
Glass (untreated)	5-15%
Plastics	10-15%
Wood	10-40%
Brick	10-40%
Concrete	40-80%
Metal	90-100%

5.6 ObserverIP Receiver

5.6.1 Hardware Requirements

1. Broadband router
2. An “always-on” connection to the Internet. A high speed DSL or cable internet connection that maintains constant connection to the internet.

5.6.2 Software Requirements

An IP scan tool is required to locate the ObserverIP on the network.

Important Note: Download ObserverIP tools at the following location:


www.AmbientWeather.com/observerip.html

5.6.3 ObserverIP Connections

Connect the ObserverIP receiver power jack to AC power with the power adapter (included), as shown in Figure 15, reference 10.


Connect the ObserverIP receiver to your router using the Ethernet cable (included), as shown in Figure 15, reference 8.

Place the sensor array and indoor thermo-hygrometer transmitter about 5 to 10 feet from the ObserverIP receiver and wait several minutes for the remote sensors to synchronize with the receiver. Once synchronized, the Indoor blue LED (Figure 14, reference 2) and Outdoor blue LED (Figure 14, reference 3) will be illuminated.



Ref.	LED	Description
1	RF	On when radio frequency receiver is operating properly
2	Indoor	On when indoor sensor received
3	Outdoor	On when outdoor sensor array received
4	Server	On when connected to Wunderground.com internet hosting service
5	ACT	Flashes when there is internet activity
6	Link	Connected to the Internet (or router)
7	Power	AC Power connected

Figure 14



Ref.	Description
8	LAN connection (connect to router)
9	Reset button
10	AC Power connection

Figure 15

5.6.4 Finding the ObserverIP from your computer

5.6.4.1 PC Users

To find the ObserverIP receiver, launch the IP Tools application downloaded here:

www.AmbientWeather.com/observerip.html



The HostIP (your computers IP address) will be displayed. Press the **OK** button to continue.




Figure 16

Select the **Search** button to find the ObserverIP on your local area network.




Figure 17

Select the ObserverIP device on your network and select the **Open** button to view within your browser. Alternately, you can type I the IP address in your web browser address bar (example, Figure 19):




Figure 18




Figure 19

You are now communicating directly to the ObserverIP and can proceed to Section 5.6.5.

5.6.4.2 Mac and Linux Users

If you use an Apple or Linux operating system, download any commercially available IP scan tool, such as AngryIP Scanner and find the MAC address of the ObserverIP. The MAC address is a unique identifier for internet enabled devices.

The MAC address will be printed on the bottom of the ObseverIP receiver. An example MAC address is 00:0E:C6:00:00:19.

We have included links to free IP Scan Tool applications here:

Figure 20 shows typical scan results. Locate the IP address of the ObserverIP by cross referencing the Mac address. In the example below, the IP address is 192.168.0.105.




Figure 20

Type the IP address you located from the IP Scan Tool into your web browser (example, Figure 21):




Figure 21

You are now communicating directly to the ObserverIP and can proceed to Section 5.6.5.


5.6.5 Local Device Network Settings

From your web browser, access the ObserverIP from the IP address obtained in the previous section.

Select the **Local Network** tab to program the local network settings. Reference Figure 22:

1. **IP Address.** The default setting is receive automatically (DCHP), which is recommended. The network will assign an IP address. To statically assign an IP address, select **Static** from the pull down menu. This will prevent the IP address from changing each time you power up the ObserverIP receiver.
2. **Static IP Address.** If Static is selected as the IP address, enter the IP address you wish to access the ObserverIP device.
3. **Static Subnet Mask.** Default is 255.255.255.0. This should not be changed unless you are familiar with networking and subnet masking.
4. **Static Default Gateway.** This is typically the IP address of your router.
5. **Static DNS Server.** This is your DNS Server setting based on your router connection.
6. **Server Listening Port.** Default is 5000. Enter an integer between 1024 – 65535.

To confirm the changes, select **Apply** and **Reboot**.



The screenshot shows the 'Local Device Network Settings' page in the ambient weather observerIP 1.0 web interface. The 'Weather Network' tab is selected. The settings are as follows:


Setting	Value
IP Address	Receive Automatically(DHCP)
Static IP Address	192.168.0.3
Static Subnet Mask	255.255.255.0
Static Default Gateway	192.168.0.1
Static DNS Server	168.95.1.1
Server Listening Port	5000

Buttons at the bottom: Apply, Cancel, Restore default, Reboot.

Figure 22

5.6.6 Weather Network Settings

Select the **Weather Network** tab to program the Weather Underground station settings. Reference Figure 23:



The screenshot shows the 'Weather Underground Station Settings' page in the ambient weather observerIP 1.0 web interface. The 'Weather Network' tab is selected. The settings are as follows:

Setting	Value
Station ID	KAZCHAND33 Example: KAZPHOEN11
Password	*****

Buttons at the bottom: Apply, Cancel.

Figure 23

Enter the Station ID and password obtained from Wunderground.com. Select the **Apply** button to confirm changes.




Note: How to create a Wunderground.com account and station ID.

1. Join the Wunderground.com Community. Visit:

<https://www.wunderground.com/members/signup.asp>

and sign up with Wunderground.com.



The screenshot shows the 'Join Our Community' page on Wunderground.com. The page has a dark navigation bar with the 'wunderground' logo and links for 'Maps & Radar', 'Severe Weather', 'News & Blogs', 'Photos & Video', 'Activities', and 'More'. Below the navigation bar, there is a weather widget for Tucson, AZ, showing 75°F and Clear. A 'Recent Cities' section lists Los Altos, CA, Phoenix, AZ, Phoenix Area, AZ, Santa Rosa, CA, and Manistique, MI. The main heading is 'Join Our Community'. The sign-up form includes the following fields and options:


- Become a Member** (Section Header)
- Email**: Input field containing 'support@ambientweatherstore.com'.
- Password**: Input field containing six dots.
- Confirm Password**: Empty input field.
- Handle [What's This?]**: Empty input field.
- Upgrade my membership for only \$10 per year.
- I agree to the [Terms of Service](#).
- Become a Member** (Submit Button)

2. **Join the Personal Weather Station (PWS) network.** Visit:

<http://www.wunderground.com/weatherstation/about.asp>

and **Get Started!** to add your weather station and you will receive a Station ID.

Get your own FRONT-DOOR FORECAST!
Get Started!



WHAT IS A PWS?

A personal weather station (PWS) is an outdoor instrument that measures weather conditions.

Basic stations may include a thermometer, barometer, anemometer, hygrometer, and wind vanes. More sophisticated stations may also measure UV index, leaf wetness, soil moisture and temperature, and water temperature.

[Learn More](#)

THE BENEFITS OF JOINING OUR NETWORK

By purchasing your own station and joining our PWS community, you can:


- Get personalized forecasts based on your own weather data
- Access archived data with charts & graphs
- Easily share your weather data

Your PWS data will go into our proprietary forecasting model, making forecasts more local and more accurate.

Our **PWS network** is the world's largest, with over 25,000 active stations and growing. Be a part of our community and join today!

[Learn More](#) Get Started!

Enter the Station ID obtained and password you entered into the ObserverIP Weather Server panel.

 **Note:** If Wunderground.com is not updating, make sure the Station ID and Password are correct. The Station ID is all capital letters, and the password is case sensitive. The most common issue is substituting an O for 0 in the Station ID. Example, You live in Phoenix, AZ and you are station number 11:

KAZPHOEN11, not KAZPHOEN11
 K = USA station designation
 AZ = Arizona
 PHOEN = Phoenix
 11 = station 11 in Phoenix, AZ

5.6.7 Station Settings

Select **Apply** to confirm any of the changes in this section.

5.6.7.1 Wireless Transmitter Settings


1. **Indoor Sensor Type:** Enter WH25 for the indoor thermometer-hygrometer-barometer (default).
2. **Outdoor Sensor1 Type:** Enter WH24 for the outdoor sensor array (default).
3. **Outdoor Sensor2 Type:** Enter none. At the present time, additional sensors are not available.

5.6.7.2 Time Zone Setting

Enter your local time zone and daylight Savings Time.

5.6.7.3 Units of Measure

Enter your preferred units of measure for each parameter.



ambient weather observerIP 1.0

Local Network Weather Network **Station Settings** Live Data Correction

Wireless Transmitter Settings

Indoor Sensor Type	WH25 ▼
Outdoor Sensor1 Type	WH24 ▼
Outdoor Sensor2 Type	None ▼
Wireless Receive Frequency	915 ▼

Time Zone Setting

Time Zone	-7
-----------	----

Please enter an integer between -12~12

Units of Measure

Wind	mph ▼
Rainfall	in ▼
Pressure	inhg ▼
Temperature	degF ▼
Solar Radiation	w/m2 ▼

Apply Cancel

Figure 24

5.6.8 Live Data

Select the **Live Data** tab to view your live data from the weather station. To freeze the live data updates, select the **Stop Refresh** button.





Figure 25

5.6.9 Calibration

Select the Calibration tab to view your calibration data from the weather station. Select the **Apply** button to confirm changes.

Calibration of most parameters is not required, with the exception of Relative Pressure, which must be calibrated to sea-level to account for altitude effects. For more information on sea-level pressure calibration, please reference note (3) below.


ambient weather observerIP 1.0

Local Network
Weather Network
Station Settings
Live Data
Correction

Correction

Solar Radation Wavelength <small>(w/m² vs lux)</small>	<input style="width: 80%;" type="text" value="126.7"/>	Range: 1.0 to 6000.0 Default: 126.7
Solar Radation Gain	<input style="width: 80%;" type="text" value="1.00"/>	Range: 0.10 to 5.00 Default: 1.00
Wind Speed Gain	<input style="width: 80%;" type="text" value="1.00"/>	Range: 0.10 to 5.00 Default: 1.00
Rain Gain	<input style="width: 80%;" type="text" value="1.00"/>	Range: 0.10 to 5.00 Default: 1.00
Indoor Temperature Offset	<input style="width: 80%;" type="text" value="0.0"/>	Range: -10C/-18F to 10C/18F Default: 0.0
Indoor Humidity Offset	<input style="width: 80%;" type="text" value="0"/>	Range: -10 to 10 Default: 0
Absolute Pressure Offset	<input style="width: 80%;" type="text" value="0.00"/>	Range: -30.00hpa/-0.89inhg/-22.39mmhg to 30.00hpa/0.89inhg/22.39mmhg Default: 0.00
Relative Pressure Offset	<input style="width: 80%;" type="text" value="0.00"/>	Range: -30.00hpa/-0.89inhg/-22.39mmhg to 30.00hpa/0.89inhg/22.39mmhg Default: 0.00
Outdoor Temperature Offset	<input style="width: 80%;" type="text" value="0.0"/>	Range: -10C/-18F to 10C/18F Default: 0.0
Outdoor Humidity Offset	<input style="width: 80%;" type="text" value="0"/>	Range: -10 to 10 Default: 0
Wind Direction Offset	<input style="width: 80%;" type="text" value="0"/>	Range: -180 to 180 Default: 0

Figure 26

Parameter	Type of Calibration	Default	Typical Calibration Source
Temperature	Offset	Current Value	Red Spirit or Mercury Thermometer (1)
Humidity	Offset	Current Value	Sling Psychrometer (2)
ABS Barometer	Offset	Current Value	Calibrated laboratory grade barometer
REL Barometer	Offset	Current Value	Local airport (3)
Wind Direction	Offset	Current Value	GPS, Compass (4)
Solar Radiation	Gain	1.00	Calibrated laboratory grade solar radiation sensor
1 w/m ²	Gain	126.7 lux	Solar radiation conversion from lux to w/m ² for wavelength correction (5)
Wind	Gain	1.00	Calibrated laboratory grade wind meter (6)
Rain	Gain	1.00	Sight glass rain gauge with an aperture of at least 4" (7)
Daily Rain	Offset	Current Value	Apply an offset if the weather station was not operating for the entire day.
Weekly Rain	Offset	Current Value	Apply an offset if the weather station was not operating for the entire week.
Monthly Rain	Offset	Current Value	Apply an offset if the weather station was not operating for the entire month.
Yearly Rain	Offset	Current Value	Apply an offset if the weather station was not operating for the entire year.

- (1) Temperature errors can occur when a sensor is placed too close to a heat source (such as a building structure, the ground or trees).

To calibrate temperature, we recommend a mercury or red spirit (fluid) thermometer. Bi-metal (dial) and digital thermometers (from other weather stations) are not a good source and have their own margin of error. Using a local weather station in your area is also a poor source due to changes in location, timing (airport weather stations are only updated once per hour) and possible calibration errors (many official weather stations are not properly installed and calibrated).

Place the sensor in a shaded, controlled environment next to the fluid thermometer, and allow the sensor to stabilize for 48 hours. Compare this temperature to the fluid thermometer and adjust the ObserverIP receiver to match the fluid thermometer.

- (2) Humidity is a difficult parameter to measure electronically and drifts over time due to contamination. In addition, location has an adverse affect on humidity readings (installation over dirt vs. lawn for example).

Official stations recalibrate or replace humidity sensors on a yearly basis. Due to manufacturing tolerances, the humidity is accurate to $\pm 5\%$. To improve this accuracy, the indoor and outdoor humidity can be calibrated using an accurate source, such as a sling

psychrometer.

- (3) The ObserverIP receiver displays two different pressures: absolute (measured) and relative (corrected to sea-level).

To compare pressure conditions from one location to another, meteorologists correct pressure to sea-level conditions. Because the air pressure decreases as you rise in altitude, the sea-level corrected pressure (the pressure your location would be at if located at sea-level) is generally higher than your measured pressure.

Thus, your absolute pressure may read 28.62 inHg (969 mb) at an altitude of 1000 feet (305 m), but the relative pressure is 30.00 inHg (1016 mb).

The standard sea-level pressure is 29.92 in Hg (1013 mb). This is the average sea-level pressure around the world. Relative pressure measurements greater than 29.92 inHg (1013 mb) are considered high pressure and relative pressure measurements less than 29.92 inHg are considered low pressure.

To determine the relative pressure for your location, locate an official reporting station near you (the internet is the best source for real time barometer conditions, such as Weather.com or Wunderground.com), and set your weather station to match the official reporting station.

- (4) Only use this if you improperly installed the weather station sensor array, and did not point the direction reference to true north.
- (5) The default conversion factor based on the wavelength for bright sunlight is 126.7 lux / w/m². This variable can be adjusted by photovoltaic experts based on the light wavelength of interest, but for most weather station owners, is accurate for typical applications, such as calculating evapotranspiration and solar panel efficiency.
- (6) Wind speed is the most sensitive to installation constraints. The rule of thumb for properly installing a wind speed sensor is 4 x the distance of the tallest obstruction. For example, if your house is 20' tall and you mount the sensor on a 5' pole:

$$\text{Distance} = 4 \times (20 - 5)' = 60'$$

Many installations are not perfect and installing the weather station on a roof can be difficult. Thus, you can calibrate for this error with a wind speed multiplier.


In addition to the installation challenges, wind cup bearings (moving parts) wear over time.

Without a calibrated source, wind speed can be difficult to measure. We recommend using a calibrated wind meter (available from Ambient Weather) and a constant speed, high speed fan.

- (7) The rain collector is calibrated at the factory based on the funnel diameter. The bucket tips every 0.01" of rain (referred to as resolution). The accumulated rainfall can be compared to a sight glass rain gauge with an aperture of at least 4". The following is a link to an accurate sight glass rain gauge:

<http://www.ambientweather.com/stpraga.html>

Make sure you periodically clean the rain gauge funnel.

 **Note:** The purpose of calibration is to fine tune or correct for any sensor error associated with the devices margin of error. Errors can occur due to electronic variation (example, the temperature sensor is a resistive thermal device or RTD, the humidity sensor is a capacitance device), mechanical variation, or degradation (wearing of moving parts, contamination of sensors).

Calibration is only useful if you have a known calibrated source you can compare it against, and is optional. This section discusses practices, procedures and sources for sensor calibration to reduce manufacturing and degradation errors. Do not compare your readings obtained from sources such as the internet, radio, television or newspapers. The purpose of your weather station is to measure conditions of your surroundings, which vary significantly from location to location.

6. Glossary of Terms

Term	Definition
Absolute Barometric Pressure	Absolute pressure is the measured atmospheric pressure and is a function of altitude, and to a lesser extent, changes in weather conditions. Absolute pressure is not corrected to sea-level conditions. <i>Refer to Relative Barometric Pressure.</i>
Accuracy	Accuracy is defined as the ability of a measurement to match the actual value of the quantity being measured.
Barometer	A barometer is an instrument used to measure atmospheric pressure.
Calibration	Calibration is a comparison between measurements – one of known magnitude or correctness of one device (standard) and another measurement made in as similar a way as possible with a second device (instrument).
Dew Point	The dew point is the temperature at which a given parcel of humid air must be cooled, at constant barometric pressure, for water vapor to condense into water. The condensed water is called dew. The dew point is a saturation temperature. The dew point is associated with relative humidity. A high relative humidity indicates that the dew point is closer to the current air temperature. Relative humidity of 100% indicates the dew point is equal to the current temperature and the air is maximally saturated with water. When the dew point remains constant and temperature increases, relative humidity will decrease.
HectoPascals (hPa)	Pressure units in SI (international system) units of measurement. Same as millibars (1 hPa = 1 mbar)
Hygrometer	A hygrometer is a device that measures relative humidity. Relative humidity is a term used to describe the amount or percentage of water vapor that exists in air.
Inches of Mercury (inHg)	Pressure in Imperial units of measure. 1 inch of mercury = 33.86 millibars
Rain Gauge	A rain gauge is a device that measures liquid precipitation (rain), as opposed to solid precipitation (snow gauge) over a set period of time. All digital rain gauges are self emptying or self dumping (also referred

Term	Definition
	to as tipping rain gauge). The precision of the rain gauge is based on the volume of rain per emptying cycle.
Range	Range is defined as the amount or extent a value can be measured.
Relative Barometric Pressure	Measured barometric pressure relative to your location or ambient conditions.
Resolution	Resolution is defined as the number of significant digits (decimal places) to which a value is being reliably measured.
Solar Radiation	<p>A solar radiation sensor measures solar energy from the sun.</p> <p>Solar radiation is radiant energy emitted by the sun from a nuclear fusion reaction that creates electromagnetic energy. The spectrum of solar radiation is close to that of a black body with a temperature of about 5800 K. About half of the radiation is in the visible short-wave part of the electromagnetic spectrum. The other half is mostly in the near-infrared part, with some in the ultraviolet part of the spectrum.</p>
Thermometer	A thermometer is a device that measures temperature. Most digital thermometers are resistive thermal devices (RTD). RTDs predict change in temperature as a function of electrical resistance.
Wind Vane	A wind vane is a device that measures the direction of the wind. The wind vane is usually combined with the anemometer. Wind direction is the direction from which the wind is blowing.

7. Specifications

7.1 Wireless Specifications

- Line of sight wireless transmission (in open air): 330 feet, 100 feet under most conditions
- Update Rate: Outdoor Sensor: 16 seconds, Indoor Sensor: 64 seconds
- Frequency: 915 MHz

7.2 Measurement Specifications

The following table provides the specifications for the measured parameters.

Measurement	Range	Accuracy	Resolution
Indoor Temperature	32 to 140 °F	± 2 °F	0.1 °F
Outdoor Temperature	-40 to 149 °F sensor -23 to 140 °F rechargeable battery range (alkaline)	± 2 °F	0.1 °F
Indoor Humidity	1 to 99%	± 5%	1 %
Outdoor Humidity	1 to 99%	± 5%	1 %
Barometric Pressure	8.85 to 32.50 inHg	± 0.08 inHg (within range of 27.13 to 32.50 inHg)	0.01 inHg
Light	0 to 400,000 Lux	± 15%	1 Lux
Rain	0 to 394 in.	± 10%	0.01 in
Wind Direction	0 - 360 °	1°	1°
Wind Speed	0 to 100 mph (operational)	± 2.2 mph or 10% (whichever is greater)	0.1 mph

7.3 Power Consumption

- ObserverIp Receiver : 5V DC Adaptor (included), Power Consumption: ?
- Indoor Thermo-hygrometer-barometer sensor : 2xAAA batteries (not included)
- Outdoor sensor array: 3xAA alkaline rechargeable batteries (included)

8. Maintenance

1. Clean the rain gauge once every 3 months as follows. Reference Figure 27.

Step 1: Make a note of the current rain totals by referencing the calibration panel (reference Section 5.6.9). You will need to re-enter these values after the calibration procedure is complete.

Step 2: Pour water into the rain collector to moisturize the dirt inside rain bucket.

Step 3: Use an approximately 3 inch (80 mm) long cotton swab, and push the cotton tip through the rain collector hole until it reaches the self emptying mechanism, and press until the mechanism no longer rotates.

Step 4: Rotate the cotton swab back and forth, removing dirt from the tipping mechanism and rain collector hole.

Step 5: Remove the cotton swab and flush with water to remove any remaining dirt.

Step 6: Re-enter the rain totals recorded in Step 1.




Figure 27

2. Clean the solar radiation sensor every 3 months with water and towel.
3. Replace rechargeable batteries every 2 to 3 years.

9. Troubleshooting Guide

If your question is not answered here, you can contact us as follows:

1. Email Support: support@ambientweather.com
2. Live Chat Support: www.ambientweather.com/chat.html (M-F 8am to 4pm Arizona Time)
3. Technical Support: 480-346-3398 (M-F 8am to 4pm Arizona Time)

Problem	Solution
Wireless remote	The maximum line of sight communication range is about 300'. Move the

Problem	Solution
(thermo-hygrometer) not reporting in to ObserverIP Receiver.	<p>sensor assembly closer to the ObserverIP receiver.</p> <p>Install a fresh set of batteries in the remote sensor(s).</p> <p>Make sure the remote sensors are not transmitting through solid metal (acts as an RF shield), or earth barrier (down a hill). Radio Frequency (RF) Sensors cannot transmit through metal barriers (example, aluminum siding) or multiple, thick walls.</p> <p>Move the ObserverIP receiver around electrical noise generating devices, such as computers, TVs and other wireless transmitters or receivers.</p>
Outdoor sensor array does not communicate to the ObserverIP Receiver.	<p>The sensor array may have initiated properly and the data is registered by the ObserverIP receiver as invalid, and the sensory array must be reset. The reset button is next to the LED, near the mounting point on the sensor array, as shown in Figure 11.</p> <p>With an open ended paperclip, press the reset button for 3 seconds to completely discharge the voltage.</p> <p>Take out the batteries and wait one minute, while covering the solar panel to drain the voltage.</p> <p>Put batteries back in and resync with ObserverIP receiver by powering down and up the ObserverIP receiver with the sensor array about 10 feet away.</p> <p>Bring the sensor array inside the house (you can disconnect it from the rest of the sensors). The LED next to the battery compartment will flash every 16 seconds. If the LED is not flashing every 16 seconds...</p> <p>Replace the batteries in the outside sensor array. Non-rechargeable batteries are OK for testing purposes. If the batteries were recently replaced, check the polarity. If the sensor is flashing every 48 seconds, proceed to the next step.</p> <p>There may be a temporary loss of communication due to reception loss related to interference or other location factors,</p> <p>or the batteries may have been changed in the sensor array and the ObserverIP receiver has not been reset. The solution may be as simple as powering down and up the ObserverIP.</p> <p>Replace the batteries in the outside sensor array. Non-rechargeable batteries are OK for testing purposes.</p> <p>With the sensor array and ObserverIP 10 feet away from each other, remove AC power from the ObserverIP receiver and wait 10 seconds. Re-connect power.</p>
Temperature sensor reads too high in the day time.	<p>Make certain that the sensor array is not too close to heat generating sources or strictures, such as buildings, pavement, walls or air conditioning units.</p> <p>Use the calibration feature to offset installation issues related to radiant heat</p>

Problem	Solution
	sources. Reference Section 5.6.9.
Absolute pressure does not agree with official reporting station	You may be viewing the relative pressure, not the absolute pressure. Select the absolute pressure. Make sure you properly calibrate the sensor to an official local weather station. Reference Section 5.6.9 for details.
Rain gauge reports rain when it is not raining	An unstable mounting solution (sway in the mounting pole) may result in the tipping bucket incorrectly incrementing rainfall. Make sure you have a stable, level mounting solution.
Data not reporting to Wunderground.com	<ol style="list-style-type: none"> 1. Confirm your password is correct. It is the password you registered on Wunderground.com. Your Wunderground.com password cannot begin with a non-alphanumeric character (a limitation of Wunderground.com, not the station). Example, \$oewkrf is not a valid password, but oewkrf\$ is valid. 2. Confirm your station ID is correct. The station ID is all caps, and the most common issue is substituting an O for a 0 (or visa versa). Example, KAZPHOEN11, not KAZPH0EN11. 3. Make sure your time zone is set properly. If incorrect, you may be reporting old data, not real time data. 4. Check your router firewall settings. The ObserverIP sends data via Port 80.

10. Accessories

The following software and hardware accessories are available for this weather station at www.AmbientWeather.com.

Accessory	Description
Ambient Weather Mounting Solutions	Ambient Weather provides the most comprehensive mounting solutions for weather stations, including tripods, pole extensions, pole mounting kits, guy wires, ground stakes and more.
Ambient Weather WS-1000-BATT 3 x AA Rechargeable Batteries for WS-1000-WiFi Outdoor Sensor Array	Ambient Weather WS-1000-BATT 3 x AA Rechargeable Batteries for WS-1000-WiFi Outdoor Sensor Array (replacement).

11. Liability Disclaimer

Please help in the preservation of the environment and return used batteries to an authorized depot. The electrical and electronic wastes contain hazardous substances. Disposal of electronic waste in wild country and/or in unauthorized grounds strongly damages the environment.

Reading the “User manual” is highly recommended. The manufacturer and supplier cannot accept any responsibility for any incorrect readings and any consequences that occur should an inaccurate reading take place.

This product is designed for use in the home only as indication of weather conditions. This product is not to be used for medical purposes or for public safety information.

The specifications of this product may change without prior notice.

This product is not a toy. Keep out of the reach of children.

No part of this manual may be reproduced without written authorization of the manufacturer.

Ambient, LLC WILL NOT ASSUME LIABILITY FOR INCIDENTAL, CONSEQUENTIAL, PUNITIVE, OR OTHER SIMILAR DAMAGES ASSOCIATED WITH THE OPERATION OR MALFUNCTION OF THIS PRODUCT.

12. FCC Statement

Statement according to FCC part 15.19:

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference.
2. This device must accept any interference received, including interference that may cause undesired operation.

Statement according to FCC part 15.21:

Modifications not expressly approved by this company could void the user's authority to operate the equipment.

Statement according to FCC part 15.105:

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

13. Warranty Information

Ambient, LLC provides a 1-year limited warranty on this product against manufacturing defects in materials and workmanship.

This limited warranty begins on the original date of purchase, is valid only on products purchased and only to the original purchaser of this product. To receive warranty service, the purchaser must contact Ambient, LLC for problem determination and service procedures.

Warranty service can only be performed by a Ambient, LLC. The original dated bill of sale must be

presented upon request as proof of purchase to Ambient, LLC.

Your Ambient, LLC warranty covers all defects in material and workmanship with the following specified exceptions: (1) damage caused by accident, unreasonable use or neglect (lack of reasonable and necessary maintenance); (3) damage resulting from failure to follow instructions contained in your owner's manual; (4) damage resulting from the performance of repairs or alterations by someone other than an authorized Ambient, LLC authorized service center; (5) units used for other than personal use (6) applications and uses that this product was not intended (7) the products inability to receive a signal due to any source of interference or metal obstructions and (8) extreme acts of nature, such as lightning strikes or floods.

This warranty covers only actual defects within the product itself, and does not cover the cost of installation or removal from a fixed installation, normal set-up or adjustments, claims based on misrepresentation by the seller or performance variations resulting from installation-related circumstances.

