

Model 1360

Call Waiting / Caller ID

Speakerphone with 12 Number Memory

User's Guide



Equipment Approval Information

Your telephone equipment is approved for connection to the Public Switched Telephone Network and is in compliance with parts 15 and 68, FCC Rules and Regulations and the Technical Requirements for Telephone Terminal Equipment published by ACTA.

1 Notification to the Local Telephone Company

On the bottom of this equipment is a label indicating, among other information, the US number and Ringer Equivalence Number (REN) for the equipment. You must, upon request, provide this information to your telephone company.

The REN is useful in determining the number of devices you may connect to your telephone line and still have all of these devices ring when your telephone number is called. In most (but not all) areas, the sum of the RENs of all devices connected to one line should not exceed 5. To be certain of the number of devices you may connect to your line as determined by the REN, you should contact your local telephone company.

A plug and jack used to connect this equipment to the premises wiring and telephone network must comply with the applicable FCC Part 68 rules and requirements adopted by the ACTA. A compliant telephone cord and modular plug is provided with this product. It is designed to be connected to a compatible modular jack that is also compliant. See installation instructions for details.

Notes

- This equipment may not be used on coin service provided by the telephone company.
- Party lines are subject to state tariffs, and therefore, you may not be able to use your own telephone equipment if you are on a party line. Check with your local telephone company.
- Notice must be given to the telephone company upon permanent disconnection of your telephone from your line.

If your home has specially wired alarm equipment connected to the telephone line, ensure the installation of this product does not disable your alarm equipment. If you have questions about what will disable alarm equipment, consult your telephone company or a qualified installer.

US Number is located on the cabinet bottom.

REN Number is located on the cabinet bottom.

2 Rights of the Telephone Company

Should your equipment cause trouble on your line which may harm the telephone network, the telephone company shall, where practicable, notify you that temporary discontinuance of service may be required. Where prior notice is not practicable and the circumstances warrant such action, the telephone company may temporarily discontinue service immediately. In case of such temporary discontinuance, the telephone company must: (1) promptly notify you of such temporary discontinuance; (2) afford you the opportunity to correct the situation; and (3) inform you of your right to bring a complaint to the Commission pursuant to procedures set forth in Subpart E of Part 68, FCC Rules and Regulations.

The telephone company may make changes in its communications facilities, equipment, operations or procedures where such action is required in the operation of its business and not inconsistent with FCC Rules and Regulations. If these changes are expected to affect the use or performance of your telephone equipment, the telephone company must give you adequate notice, in writing, to allow you to maintain uninterrupted service.

Visit our website at: www.uniden.com

Interference Information

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference; and (2) This device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

Privacy of Communications may not be ensured when using this product.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna (that is, the antenna for radio or television that is "receiving" the interference).
- Reorient or relocate and increase the separation between the telecommunications equipment and receiving antenna.
- Connect the telecommunications equipment into an outlet on a circuit different from that to which the receiving antenna is connected.

If these measures do not eliminate the interference, please consult your dealer or an experienced radio/television technician for additional suggestions. Also, the Federal Communications Commission has prepared a helpful booklet, "How To Identify and Resolve Radio/TV Interference Problems." This booklet is available from the U.S. Government Printing Office, Washington, D.C. 20402. Please specify stock number 004-000-00345-4 when ordering copies.

Notice: The changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Hearing Aid Compatibility (HAC)


This telephone system meets FCC standards for Hearing Aid Compatibility.

Licensing

Licensed under US Patent 6,427,009.

FCC RF Radiation Exposure Statement

This equipment complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20 centimeters between the radiator and your body. This transmitter must not be co-located or operated in conjunction with any other antenna or transmitter.



Introduction

CAUTION: When using telephone equipment, there are basic safety instructions that should always be followed. Refer to the IMPORTANT SAFETY INSTRUCTIONS provided with this product and save them for future reference.

Short Glossary of Terminology Used in this Manual

Hook switch. The part of the phone that pops up to activate the phone line when the handset is lifted from the base.


Off-hook. A term used to describe the phone in its active mode when the handset is off of the base cradle or when the **speaker** button is pressed.

On-hook. A term used to describe the phone in an inactive mode.

Before You Begin

Parts Checklist

Make sure your package includes the following items:



Telephone Jack Requirements


To use this phone, you need an RJ11C type modular telephone jack, which might look like the one pictured here, installed in your home. If you don't have a modular jack, call your local phone company to find out how to get one installed.

Important Installation Information

CAUTION: Disconnect the phone cord from the wall outlet before installing or replacing the batteries.

- Never install telephone wiring during a lightning storm.
- Never touch uninsulated telephone wires or terminals, unless the telephone line has been disconnected at the network interface.
- Use caution when installing or modifying telephone lines.
- Never install telephone jacks in wet locations unless the jack is specifically designed for wet locations.
- Temporarily disconnect any equipment connected to the phone, such as faxes, other phones, or modems.

Base Layout



Installing and Replacing the Batteries


Your Caller ID phone uses 4 AA-size alkaline batteries for receiving and storing Caller ID records and for storing the numbers you use for memory dialing, pulse dialing, and redial.

IMPORTANT: You will have approximately 90 seconds to replace the batteries before the memories stored are lost. Please read the instructions before replacing the batteries and have the batteries ready to be inserted beforehand.

IMPORTANT: If you are not going to use the telephone for more than 30 days, remove the batteries because they may leak and damage the unit.

- Disconnect the telephone line cord and remove the desk stand from the back of the base.
- Release latch or the battery compartments and remove cover.
- Insert 4 AA-size alkaline batteries as shown on the diagram in the battery compartments.
- Snap the battery compartment door back into place and replace the desk stand.
- Connect the line cord and check your memory locations.

NOTE: If the low battery icon appears in the display, you need to replace the batteries. It is important that you replace the batteries as soon as possible in order to maintain Caller ID operation.



Installing the Phone

Your phone should be placed on a level surface, such as a desk or table top, or you can mount it on a wall.

Connecting the Handset

- Connect one end of the coiled handset cord to the jack on the handset.
- Plug the other end of the coiled handset cord to the jack on the base.
- Place the handset in the cradle.
- Set the ringer volume switch located at the back of the base to the desired loudness.

OFF - Telephone will not ring.
LO - Sound will be lowest.
HI - Sound will be loudest.



NOTE: The unit is properly installed if you pick up the handset and hear the dial tone. Otherwise, recheck all installation steps.

Wall Mounting

Your speakerphone can also be mounted on a wall plate (not included).

NOTE: To prevent the handset from falling out of the cradle while the phone is hanging on the wall, you must switch both the handset hook and the desk stand to their wall-mount positions.

- On the front of the base, pull the handset hook out of the slot. Rotate hook 180 degrees and flip it from front to back. Slide it back into the slot.
- Turn the base over. Press in on the tabs and remove the desk stand from the back of the base.
- Rotate the stand 180 degrees, and insert the hooks marked WALL into the notches marked WALL. Press in on the tabs and snap the stand into place.
- Connect the telephone line cord to the wall jack and the phone. If desired, wrap any excess cord around the cord hooks as shown.
- Place the mounting slots over the pins on the wall plate, and slide the base down to lock it into place.



Telephone Basics

You can use the telephone by speaking into and listening through the handset, or by using the speakerphone.

Receiving a Phone Call

- Lift the handset or press the **speaker** button to answer the call.
- Replace the handset in the cradle or press the **speaker** button to hang up.

Making a Phone Call

- Lift the handset or press the **speaker** button. Wait for a dial tone.
- Dial the telephone number you want to call.
- Replace the handset in the cradle, or press the **speaker** button to hang up.

Volume

You may adjust the handset and speakerphone volume independently with the VOL (- or +) buttons. Both handset receiver volume level and speakerphone volume level are saved in memory.

Adjusting the Handset Receiver Volume

While using the handset, you can adjust the speaker volume by pressing the VOL (- or +) buttons. The screen displays **REC (Handset Receiver) volume**.

Adjusting the Speakerphone Volume

While using the speakerphone, you can adjust the speaker volume by pressing the VOL (- or +) buttons. The screen displays **SPK volume level**.

NOTE: Both handset receiver and speakerphone volume return to the default setting (low) if the unit's power is reset.

Redial

You may redial the last number you called by pressing the **redial** button after you hear a dial tone.

NOTE: The redial feature holds the last number (up to 32 digits) that you dialed in memory. If you pressed any other numbers after dialing the phone number (for example, when accessing a voice-menu system) then those numbers are also dialed.

Mute

Use the **mute** button to interrupt a phone conversation to talk privately with someone else in the room. A conversation can be muted while using the speakerphone or handset.

- Press the **mute** button. The mute indicator illuminates.
- Press **mute** again to turn it off.

NOTE: Switching from speakerphone to handset cancels mute.

Flash

Press **flash/exit** to activate special features of your telephone network, such as call transfer, or special services from your local telephone company, such as call waiting.

Temporary Tone Dialing

If you have pulse (rotary) service and want to access customer calling services (such as telebanking and long distance services) that require tone dialing, you can use this feature to temporarily change from pulse to tone service.

- After dialing the telephone number and connecting to the customer calling service, 1. Press and release the ***tone** button.
2. When you hang up, the telephone automatically returns to pulse dialing mode.

Speakerphone Basics

Location

Your phone features a speakerphone for ease of use and convenience during a phone conversation. At any time during a conversation, you can lift the handset to stop using the speakerphone. Likewise, when you are using the handset, press the **speaker** button and place the handset in the cradle to switch to the speakerphone.

For best speakerphone performance, avoid the following:

- Areas with high background noise. (The microphone might pick up these sounds and prevent the speakerphone from going into the receiving mode when you finish talking.)
- Surfaces affected by vibration.
- Recessed areas such as in a corner, under a cupboard, or next to a cabinet, which can generate an echo effect.

Speakerphone Use

Note the following guidelines when using the speakerphone:

- The speakerphone works similar to a two-way radio in that you can only listen or talk at one time.
- Stay reasonably close to the phone so that you can be clearly heard by the person to whom you are talking.
- You can adjust the speaker volume by pressing the VOL (- or +) buttons.
- The speakerphone indicator light comes on when the speakerphone is in use.

Caller ID (CID) Features

IMPORTANT: In order to use all of the features of this telephone, you must subscribe to two separate services available from your local telephone company: the standard Name/Number Caller ID Service to know who is calling when the phone rings and Caller ID with Call Waiting Service to know who is calling while you are on the phone.

CID Summary Screen

The Summary Screen shows the current time, date, and number of new calls to review. It is displayed until any button is pressed.

NOTE: The number of new calls is displayed until all new calls have been reviewed.

Receiving and Storing CID Calls

This unit receives and displays information transmitted by your local company. This information can include the phone number, date, and time; or the name, phone number, date, and time. The unit can store up to 75 calls for later review. When the memory is full, a new call automatically replaces the oldest call in memory. The screen displays **NEW** for calls received that have not been reviewed. The screen displays **REPT** for calls received more than once which have not been reviewed.



Reviewing CID Records

- Press the **review** ◀ or ▶ buttons to view the call records.
- Press the **review** ▶ button to scroll through the call records from the most recent to the oldest.
- Press the **review** ◀ button to scroll through the call records from the oldest to the newest.
- When all of the records have been viewed, The screen displays **START/END**.

Deleting CID Records

- To delete the record shown in the display, press the **delete** button once.
- To delete all records while reviewing, press and hold the **delete** button for about three seconds. The screen displays **DELETE ALL?**. Press **delete** again to complete.

Dialing Back

When reviewing Caller ID records, you can dialback the numbers on the display by pressing the **dial** button.

NOTE: If the screen displays PICKUP PHONE, no other changes to the number can be made. The information sent from the telephone company is known to be a valid number for dialing back (used only in very limited areas). Once you pickup the phone, the number is automatically dialed.

If You Programmed Your Local Area Code

- Use the **review** ◀ or ▶ buttons to display the number you want to dial.
- Press the **dial** button.
- If you see a number with seven digits (i.e. 555-1234), then the call is from within your area code. However, this does not guarantee the call is a local call.
- If you see a number with 11 digits (i.e. 1-234-555-1234), then the call is not from within your area code.
- NOTE: A timer (10 seconds on-hook and 3 seconds off-hook) located in the upper right side of the display will start, letting you know how much time is left until the unit returns to the Summary Screen.**
- If you are at on-hook and the screen displays **PICKUP OR ADJ.**, you can adjust the phone number format by pressing the **dial** button. If the phone is off-hook and the screen displays **ADJUST**, you can adjust the phone number format by pressing the **dial** button. For example, sometimes a 7-digit local number cannot be dialed because it requires a 10-digit or 11-digit format. Press the **dial** button repeatedly to scroll through the 7, 10, and 11-digit numbers.

- 7-digits:** 7-digit telephone number (i.e. 555-5555)
- 10-digits:** 3-digit area code + 7-digit telephone number (i.e. 425-555-5555)
- 11-digits:** long distance code 1 + 3-digit area code + 7-digit telephone number (i.e. 1-425-555-5555)

- To dial the displayed number, and the phone is on-hook, pick up the handset or press the **speaker** button before the timer reaches 0. If the phone is off-hook, wait until the time reaches 0. The screen displays **NOW DIALING** and the number is dialed.

If You Did Not Program Your Local Area Code

- Use the **review** ◀ or ▶ buttons to display the number you want to dial. You will only see 10-digit numbers (i.e. 234-555-1234).
- See steps 2 through 4 in the previous section to complete the dialback process.

Setting Up the Caller ID Menu

You should not plug the telephone into the modular jack while setting up the Caller ID menu.

- Press the **menu** button to enter the menu feature configuration mode.
 - # 1. **ENG FRA ESP** (CID language default *English*)
 - # 2. **CONTRAST** (default level is 3)
 - # 3. **LOCAL AREA CODE**
 - # 4. **TONE PULSE** (Default is tone dialing).
- Press the **menu** button to scroll through the 4 menu screens.
- Use the ◀ or ▶ buttons to select the desired setting.

NOTE: You have 20 seconds following an entry before the phone returns to the Summary Screen.

Display Language

- This adjustment allows you to display the Caller ID prompts in *English, French, or Spanish*.
- Press the **menu** button until the screen displays **ENG FRA ESP**.
- Use the **review** ◀ or ▶ buttons to select **ENG, FRA** or **ESP**.
- Press the **menu** button again to save.

Contrast

- This adjustment allows you to adjust the contrast of the display.
- Press the **menu** button until the screen displays **CONTRAST**.
- Use the **review** ◀ or ▶ buttons to select level 1, 2, 3, 4, or 5.
- Press the **menu** button again to save.

Local Area Code

The telephone uses the programmed area codes to determine the number format to display when a valid Caller ID signal is received. Numbers that match the local area code are displayed as seven digits and are used for dialing back previous numbers. Entering your local area code will also help you immediately know if the call is local or long distance when viewing the CID records in the display.

NOTE: If you make a mistake and want to start over again, press the delete button to erase all of the digits.

- Press the **menu** button until the screen displays **LOCAL AREA CODE**.
- Use the number keys to enter the Local Area Code you want.
- Press the **menu** button to save.

Dialing Mode

- This adjustment allows you to select tone (touch-tone) or pulse (rotary) dialing.
- Press the **menu** button until the screen displays **TONE PULSE**.
- Press the **review** ◀ or ▶ buttons to show the current dialing mode. The default is **TONE** dialing.
- To change the dialing mode, press the **review** ◀ or ▶ buttons. The display alternates between the two modes.
- Press the **menu** button again to save.

NOTE: The phone will exit Set Up after 20 seconds if no buttons are pressed.

REMINDER: The time and date are programmed automatically when the first Caller ID record is successfully received after set up.

Memory

You may store information in any of the following memory locations: 0 to 9, A, B, and C. See "Storing a Pause in Memory" and "Temporary Tone Dialing" for more information.

Storing a Name and Number in Memory

- Press the store button. The screen displays **LOCATION?**.
- Press the desired memory location (0-9, A, B, C).
- NOTE: You may select memory locations by pressing review ◀ or ▶ buttons to scroll through the memory locations or press the 0 - 9, A, B, C.**
- Press the store button again to confirm the memory location.
 - NOTE: If necessary, to erase existing memories, or if you make a mistake, use the delete button.**
- Use the number keys to enter the telephone number (up to 32 digits) and press the store button to save. (The unit will not dial a phone number in this mode) The cursor automatically moves to the text line for name entry.
- Use the number keys to enter the name of the person associated with the telephone number you just entered. More than one letter is stored in each of the number keys. For example, to enter the name BILL SMITH, press the 2 key twice for the letter B. Press the 4 key 3 times for the letter I. Press the 5 key 3 times for the letter L.

NOTE: The flashing cursor automatically moves to the next position or you may press the review ◀ or ▶ buttons to move the cursor to the next position.

Press the 5 key 3 times for the second letter L. Press the arrow key (4) two times to insert a space, and press the 7 key 4 times for the letter S. Press the 6 key once for the letter M. Press the 4 key 3 times for the letter I. Press the 8 key for the letter T. Press the 4 key twice for the letter H.

6. Press the store button to save the name.

- To enter another name and number in a different memory location, return to step 1 and repeat the process.

Changing a Stored Number

Repeat the storage sequence under "Storing a Name and Number in Memory", and use the **delete** button to delete the old number before entering the new number.

Erasing a Stored Number

- Press the store button.
- Press the memory location (0-9, A, B, C) to be erased.
- Press the **delete** button.

Copying Caller ID Memories to User Memory

- Press the **review** ◀ or ▶ buttons to view the caller number and name you want to copy.
- Press the store button.
- Press the memory location (0-9, A, B, C). The number flashes if there is a number already stored in the memory location.
- Press the store button to enter the edit mode, and then press the store button again to edit the name.
 - NOTE: You may select a different memory location by pressing review ◀ or ▶ buttons to scroll through the memories or press a number key (0-9, A, B, C).**
- Press the store button to confirm and save, and wait for three seconds to exit.
 - NOTE: If the name you want to enter is longer than 12 characters, only the first 12 characters will be copied into memory.**

Storing a Redial Number to Memory

- Press the store button.
- Press any key (0-9, or quick call buttons A, B, or C) for the memory location. If there is a number already stored in the memory location it will appear on the display. Use the **review** ◀ or ▶ button to select a different location.
- Press the store button again to confirm.
- Press the **redial** button, and then press the store button again.
- Enter name, if necessary, and then press the store button to confirm.
 - NOTE: If you want to edit the number, press the store button again within three seconds. When you are finished, wait three seconds to exit.**

Dialing a Number Stored in Memory While On-hook

- Press the dial button.
- To select a memory, press any number key (0-9, A, B, C). The number in that memory location displays.

NOTE: You may select a different memory location by pressing review ◀ or ▶ buttons to scroll through the memories or press a number key (0-9, A, B, C).

- Press the **speaker** button, or pick up the handset to dial the displayed number.

Dialing a Number Stored in Memory

- Lift the handset, or press the **speaker** button.
- Press the **dial** button then press a memory location button.

Cascade Dialing

This process allows you to dial a succession of stored numbers from separate memory locations. This is useful when you must dial several sequences of numbers, such as with frequent calls via a telephone company long distance provider.

For example	Memory location
Local access number of long distance company	6
Authorization code (ID)	7
Long distance phone number	8

- Pick up the handset or press **speaker**.
- Press **dial** button, then press number "6" for the memory location.
- Press **dial** button, then press number "7" for the memory location.
- Press **dial** button, then press number "8" for the memory location.
- The number dials automatically.

Storing a Pause in Memory

The **redial** button has dual functionality and becomes a **pause** button when the store button is pressed first. It is valid only when storing a number into memory locations. Use the **redial/pause** button to insert a pause when a delay is needed in an automatic dialing sequence. For example, when you must dial a 9 to get an outside line or when you enter codes to access your long distance company.

Pre-Dialing

- With the handset on the cradle, enter the telephone number you wish to call. The

-