
MFJ-4119 Bias-Tee with DC Switch

1-450 MHz

INTRODUCTION

The **MFJ-4119 Bias-Tee** is ideal for running coax to distant devices allowing them to be placed anywhere regardless of power availability. Several MFJ products have a built in Bias-Tee, so the DC / RF coaxial cable can be directly connected to them as well.

The **MFJ-4119 Bias Tee** operates on frequencies ranging from 1-450 MHz. The Bias-Tee is used to inject DC voltage onto coaxial lines. The DC voltage is separated from the RF signal by another **MFJ-4119** on the terminating end (See Figure 1). Any standard 2.1 mm 1-50 VDC, 1 Amp maximum adapter will work. The **MFJ-4119** is equipped with a DC switch to turn the remote equipment on and off.

INSTALLATION INSTRUCTIONS

1. Connect the transmitter to the “**RF IN/OUT**” coaxial connector on **Bias-Tee 1** using a 50-ohm coaxial cable. (See Figure 1) This is the RF signal input connector.
2. Connect a DC adapter to the “**DC IN\OUT**” jack. This is your DC voltage input connector.
3. If the device you are using does have a built in Bias-Tee, connect the device to the “**RF/DC OUT/IN**” coaxial connector on **Bias-Tee 1** using 50-ohm coaxial cable. The device will recover the RF and DC signals.
4. If the device you are using does not have a built in Bias-Tee, connect the “**RF/DC OUT/IN**” coaxial connector from **Bias-Tee 1** to the “**RF/DC OUT/IN**” coaxial connector on **Bias-Tee 2** using a 50-ohm coaxial cable. This is your RF/DC out of Bias-Tee 1 into Bias-Tee 2 to be recovered.
5. Connect the device to the “**RF IN/OUT**” coaxial connector of **Bias-Tee 2** using a 50-ohm coaxial cable. This is your recovered RF signal output connector.
6. Connect the device to the “**DC IN\OUT**” of **Bias-Tee 2** using a DC adapter. This is your recovered DC voltage output connector.




Figure 1: MFJ-4119 Bias-Tee Operation Diagram