



# SERVICE MANUAL

## TS-130S, V / VFO-120 / AT-130 / PS-30

### HF SSB TRANSCEIVER



PS-30

TS-130S

VFO-120

AT-130

### CONTENTS

SPECIFICATIONS .....	2	FILTER UNIT (X51-1240-00)S TYPE .....	17
CIRCUIT DESCRIPTION .....	3	FILTER UNIT (X51-1250-00)V TYPE .....	17
SPECIAL COMPONENTS DATA .....	6	FINAL UNIT (X56-1300-00)V TYPE .....	18
OUTSIDE VIEW (S TYPE) .....	7	FINAL UNIT (X56-1350-00)S TYPE .....	18
PC BOARDS/CIRCUIT DIAGRAMS			
IF UNIT (X48-1300-00,-01) .....	8,9	PARTS LIST .....	19
PROCESSOR UNIT (X54-1550-00) .....	8	PACKING .....	28
PLL UNIT (X50-1700-00) .....	10,11	DISASSEMBLY .....	29
COUNTER UNIT (X54-1560-00) .....	12,13	LEVEL DIAGRAM .....	31
RF UNIT (X44-1380-00) .....	14	ADJUSTMENTS .....	32
VFO UNIT (X40-1170-00) .....	15	AT-130 .....	41
CAR UNIT (X50-1500-00) .....	15	SCHEMATIC DIAGRAM V TYPE .....	42
RELAY UNIT (X41-1300-00) .....	16	VFO-120 .....	43
SWITCH (A) UNIT (X41-1310-00) .....	16	SCHEMATIC DIAGRAM S TYPE .....	45
SWITCH (B) UNIT (X41-1320-00) .....	16	PS-30 .....	46
AF·GEN UNIT (X49-1110-01) .....	16	BLOCK DIAGRAM .....	BACK COVER

A product of  
**TRIO-KENWOOD CORPORATION**  
17-5, 2-chome, Shibuya, Shibuya-ku, Tokyo 150, Japan

**TRIO-KENWOOD COMMUNICATIONS, INC.**  
1111, West Walnut Street, Compton, California, 90220, U.S.A.

**TRIO-KENWOOD COMMUNICATIONS, GmbH**  
D-6374 Steinbach TS, Industriestrasse 8A, West Germany

**TRIO-KENWOOD(AUSTRALIA)PTY. LTD.**  
30 Whiting Street, Artarmon, Sydney N.S.W. Australia 2064

# TS-130SV

## SPECIFICATIONS

### [GENERAL]

**Frequency Range:**

80 meter band	3.5 ~ 4.0 MHz
40 meter band	7.0 ~ 7.3 MHz
*30 meter band	10.1 ~ 10.15 MHz (10.0 MHz Receiving only)
20 meter band	14.0 ~ 14.35 MHz
*17 meter band	18.068 ~ 18.168 MHz
15 meter band	21.0 ~ 21.45 MHz
*12 meter band	24.89 ~ 24.99 MHz
10 meter band	28.0 ~ 29.7 MHz

**Mode:**

SSB/CW

**Power Requirement:**

TS-130S	TS-130V
RX: 0.7A 13.8V DC	RX: 0.7A 13.8V DC
TX: 18A 13.8V DC	TX: 4A 13.8V DC

**Dimensions:**

TS-130S	TS-130V
241 (9.6) W x 94 (3.8) H x 293 (11.7) D mm (inch)	241 (9.6) W x 94 (3.8) H x 235 (9.4) D mm (inch)

**Weight:**

TS-130S	TS-130V
5.6 kg (12.4 lbs)	4.9 kg (10.8 lbs)

### [TRANSMITTER]

**Final Power Input:**

TS-130S	TS-130V
80 - 15 meter band 200 W PEP for SSB operation 160 W DC for CW operation 10 meter band 160 W PEP for SSB operation 140 W DC for CW operation	25W PEP for SSB operation 20W DC for CW operation  25W PEP for SSB operation 20W DC for CW operation

**Audio Input Impedance:**

500Ω ~ 50 kΩ

**RF Output Impedance:**

50Ω

**Frequency Stability:**

Within ± 1 kHz during the first hour after 1 minute of warmup  
Within 100 Hz during any 30-minute period after warmup

**Carrier Suppression:**

Better than 40 dB

**Sideband Suppression:**

Better than 50 dB

**Spurious Radiation:**

Better than 40 dB

**Harmonic Radiation:**

Better than 40 dB

### [RECEIVER]

**Receiver Sensitivity:**

0.25μV at 10 dB S + N/N

**Image Ratio:**

Better than 50 dB

**IF Rejection:**

Better than 70 dB

**Receiver Selectivity:**

2.4 kHz (-6 dB), 4.2 kHz (-60 dB)

**SSB/CW WIDE** 1.8 kHz (-6 dB), 3.3 kHz (-60 dB) with optional YK-88SN filter

**SSB NARROW** 500 Hz (-6 dB), 1.5 kHz (-60 dB) with optional YK-88C filter

**CW NARROW** 270 Hz (-6 dB), 1.1 kHz (-60 dB) with optional YK-88CN filter

**Audio Output Impedance:**

4 ~ 16Ω

**Audio Output:**

1.5 W

**NOTE:** Circuit and ratings may change without notice due to developments in technology.

- \* Will transmit on the new 30, 17, and 12 meter bands. Diodes installed for preventing accidental transmission before government amateur authorization.

## CIRCUIT DESCRIPTION

**Features added from former TS-120S,V are as follows;**

1. The three new HF bands (receive only).

Band	Receive frequency
10	10.0~10.25MHz
18	18.0~18.5MHz
24.5	24.5~25.0MHz

(Note) Receives WWV on 10MHz.

2. 20dB RF attenuator

3. 2-position selectivity (receive only).

- 1) Optional filters available.

Optional filter	-6dB bandwidth
YK-88SN SSB narrow filter	1.8kHz
YK-88C CW filter	500Hz
YK-88CN CW narrow filter	270Hz

(Note) YK-88S (-6 dB bandwidth:2.4kHz) is installed at the factory.

- 2) -6dB bandwidth with various optional filters.

No.	MODE Filter	CW		SSB	
		WIDE	NARROW	WIDE	NARROW
1)	YK-88S only (installed at factory)	2.4kHz	*	2.4kHz	*
2)	YK-88C or YK-88CN	2.4kHz	500Hz or 270Hz	2.4kHz	*
3)	YK-88SN	2.4kHz	1.8kHz	2.4kHz	1.8kHz
4)	YK-88C or YK-88CN, YK-88SN	2.4kHz	500Hz or 270Hz	2.4kHz	1.8kHz

(Note) 1. \*: No receive.  
 2. Jumper wire on the IF unit should be changed in No. 2 and No.4 Position.  
 3. YK-88S is always used in transmit.

4. AGC-type speech processor

Item	Rating
Center frequency fo	8830kHz
Center frequency deviation	8830kHz ±150Hz at 6dB
6dB bandwidth	±900Hz or more
60dB bandwidth	± 1800Hz or less
Guaranteed attenuation	80dB or more within fo ±2.5kHz to ±1MHz
Ripple	2dB or less
Loss	3dB ±2dB
Input and output impedance	600Ω/15pF

Table 1. SSB crystal filter (L71-0220-05)

YK-88SN (Option)

Item	Rating
Center frequency fo	8830.7kHz
Center frequency deviation	fo ±150Hz at 6dB
6dB bandwidth	±250Hz or more
60dB bandwidth	±900Hz or less
Ripple	2dB or less
Loss	6dB ±2dB
Guaranteed attenuation	80dB or more within fo ±2kHz to ±1MHz
Input and output impedance	600Ω/15pF

Table 2. CW crystal filter (L71-0211-05)

YK-88C (Option)

Item	Rating
Center frequency fo	8830.7kHz
Center frequency deviation	fo ±50Hz at 6dB
6dB bandwidth	±125Hz or more
60dB bandwidth	±600Hz or less
Ripple	2dB or less
Loss	8dB ±2dB
Guaranteed attenuation	80dB or more within fo ±2kHz to ±1MHz
Input and output impedance	600Ω/15pF

Table 3. CW crystal filter (L71-0221-05)

YK-88CN (Option)

## CIRCUIT DESCRIPTION

## SPEECH PROCESSOR CIRCUIT (X54-1550-00)

The AGC-type speech processor is composed of Q2: $\mu$ PC1158H2, Q3:2SC1815(Y) and D3:1N60.

The audio signal amplified by Q18 on the AF-GEN unit goes through diode switch D1:1S1555 to the MIC control when the processor switch is OFF. When the processor switch is ON the audio signal, which is compressed and gains talk-power by the speech processor circuit, goes through D2:1S1555 to the MIC control. Q1(V type) or Q11(S type):2SK30A on the filter unit is cut off when the processor switch is ON to shorten the ALC time constant to increase the average RF output power.

## TS-130 FREQUENCY SYSTEM

The TS-130 employs single conversion with a unique PLL circuit, as shown in Fig. 1.

The frequency system is basically that of the TS-820 with the exception of the PLL circuit.

## PLL CIRCUIT

Fig. 2 shows PLL circuit construction and Table 4 shows the frequency in each circuit.

Referring to Fig. 1. MIX (3) combines CAR and VFO signals and is operated straight through to mixer (1) on 3.5, 7 and 10 MHz. MIX (2) operates at 14 MHz and above with the output of MIX (3) to provide mixer (1) input, as shown in Table 4. MIX (1) output is filtered, amplified, shaped and divided by the programmable divider to obtain 500kHz output.

Band	RX.TX Frequency	VCO	MIX(1) Input	MIX(1) Output	Divider	D C B A
3.5	3.5	12.33	14.33	2.0	1/4	1 1 0 0
	~4.0	~12.83	~14.83			
7	7.0	15.83	14.33	1.5	1/3	1 1 0 1
	~7.5	~16.33	~14.83			
10	10.0	18.83	14.33	4.5	1/9	0 1 1 1
	~10.5	~19.33	~14.83			
14	14.0	22.83	24.33	1.5	1/3	1 1 0 1
	~14.5	~23.33	~24.83			
18	18.0	26.83	24.33	2.5	1/5	1 0 1 1
	~18.5	~27.33	~24.83			
21	21.0	29.83	34.33	4.5	1/9	0 1 1 1
	~21.5	~30.33	~34.83			
24.5	24.5	33.33	34.33	1	1/2	1 1 1 0
	~25.0	~33.83	~34.83			
28	28.0	36.83	34.33	2.5	1/5	1 0 1 1
	~28.5	~37.33	~34.83			
28.5	28.5	37.33	34.33	3.0	1/6	1 0 1 0
	~29.0	~37.83	~34.83			
29	29.0	37.83	34.33	3.5	1/7	1 0 0 1
	~29.5	~38.33	~34.83			
29.5	29.5	38.33	34.33	4.0	1/8	1 0 0 0
	~30.0	~38.83	~34.83			

Table 4. The frequency chart




Fig. 1 TS-130 Frequency configuration

## CIRCUIT DESCRIPTION

The programmable divider converts the information from the band switch into a BCD signal in the counter. By presetting, the signal is divided at the ratio shown in Table 4. The phase comparator is a Motorola MC4044P. The loop filter amplifier, component transistors, minimizes unwanted spurious signal. If output of the phase comparator unlocks for any reason, VCO output is switched off to prevent out of band emission and, simultaneously the digital display blanks.

### CAR OSCILLATOR

The CAR oscillator contains one oscillator and two crystals for LSB, USB and CW operation. The oscillator frequency in each mode is listed in Fig. 1.

Oscillator frequency can be varied by the IF SHIFT control during reception.

### VFO OSCILLATOR

The TS-130 VFO has same circuit and gear ass'y as the VFO-830. An LED indicator for VFO and FIX operation has been added.

### DIGITAL COUNTER

The TS-130 digital counter employs a VFO frequency counting system as shown in Fig.3.

The VFO frequency is mixed with a 5MHz signal obtained from the reference oscillator chain by a 3SK73 (Q7) and is converted to a 0.5MHz to 1MHz signal. This signal passes through the LPF, is amplified, buffered and shaped into a square wave, passes through the 0.1 second gate circuit and is applied to the 7-digit counter. The signal is counted from 10Hz to 10MHz.

The 100kHz, 1MHz and 10MHz order digits are preset by diode matrix operating on bandswitch information.




Fig. 2 TS-130 PLL circuit configuration




Fig. 3 TS-130 Counter unit block diagram

## CIRCUIT DESCRIPTION/SPECIAL COMPONENTS DATA

The 10MHz signal from the time-base reference oscillator is divided to produce gate, latch, and reset pulses which are fed to the counter. The 10 MHz and 500kHz signals are fed to the PLL circuit.

The marker circuit produces a 100kHz signal which synchronizes the 25kHz multivibrator to obtain a marker signal as accurate as the reference frequency. The analog dial can be accurately calibrated to the marker signal.

The 1/10 division at the first-stage count-down chain uses low-power Schottky TTL, while the remaining divisions are made by a CMOS IC for low power consumption and minimum spurious emission.

Because of the IF SHIFT circuit, the CAR frequency is independent of the transmit/receive frequency. Once the VFO frequency is counted, the operating frequency is indicated as accurately as the 10 MHz reference oscillator frequency is calibrated to WWV. Operating frequency is indicated accurate to the 100Hz order, regardless of the band or mode.

### PROTECTION CIRCUIT

When the transmit output load varies, the toroid in the final circuit samples reflected power. It is then rectified and amplified, producing a protection voltage to control the 2SK19 (Q12) on the AF·GEN unit, so transmitter output is continuously reduced.

### FILTER UNIT

#### 1. ALC: Protection circuit (VSWR)

The protection voltage picked up by L18 (S type), L11(V type) in the filter unit is amplified by Q1(S type),Q2 (V type) (2SC1815), then applied to the ALC line to control the output voltage.

#### 2. Fan drive circuit (S type)

The output of the thermistor TH3 detecting the temperature of the final unit is applied to Q6 (2SA562) via Q7 and Q8, so that Q6 is switched to operate the fan. The fan starts to rotate at about 45°C although the operating range shown in specification is 30~60°C. It stops when the temperature drops to a level 5~15°C lower than the start temperature. This circuit operates regardless of transmission or reception because it detects the temperature of the heat sink.

#### 3. AVR circuit

The 11V AVR consists of Q4, Q5 and Q6 (V type), Q4, Q5 and Q10 (S type) . The regulated voltage is supplied to every unit except for the fan drive circuit during transmission. The fan drive circuit is always supplied with the regulated voltage regardless of transmission or reception.

#### 4. Filter circuit

The filter is a 2-stage constant K filter (3-stage for 3.5 MHz band). When the processor switch is ON Q1 (V type) or Q11 (S type) is cut off to shorten the ALC time constant.

### FINAL UNIT

#### 1. Temperature protection (S type)

##### 1. Core temperature protection

operates when the output transformer temperature exceeds 120°C. It recovers at approx. 80 to 110°C.

##### 2. Operates when the heat sink temperature exceeds 90°C. It recovers at approx. 50 to 80°C.

When either of the above protection systems operate, the RL circuit in the AF·GEN unit is turned OFF and the unit is forcibly placed in the reception mode and transmission is inhibited. The protection circuit automatically recovers when the temperature drops to the normal level (i.e., the temperature drops by about 40°C).

#### 2. Temperature detection by the fan drive circuit (S type)

The heat sink temperature is detected by the thermistor TH3 to control fan operation.

### SPECIAL COMPONENTS DATA

#### • Applications

2SC2290(V03-2290-06) HF power amplifier for S type.

NPN Epitaxial planar Si transistor

#### • Absolute maximum ratings

Item	Pc	V <sub>CBO</sub>	V <sub>CES</sub>	V <sub>EBO</sub>	IC	IE	T <sub>stg</sub>
Value	175(W)	45(V)	45(V)	4.0(V)	20(A)	-20(A)	-65~175(°C) (T <sub>c</sub> =25°C)

#### • Application

2SC2509 (V03-2509-06) HF power amplifier for S,V type.

NPN Epitaxial planar Si transistor

#### • Absolute maximum ratings

Item	Pc	V <sub>CBO</sub>	V <sub>CES</sub>	V <sub>CEO</sub>	V <sub>EBO</sub>	IC	IE	T <sub>stg</sub>
Value	20(W)	40(V)	40(V)	18(V)	4(V)	5(A)	-5(A)	-55~150(°C) (T <sub>c</sub> =25°C)

#### • Application



2SC2075(V03-2075-06) HF power amplifier for V type.

NPN Epitaxial planar Si transistor

#### • Absolute maximum ratings


Item	Pc	V <sub>CBO</sub>	V <sub>CES</sub>	V <sub>CEO</sub>	V <sub>EBO</sub>	IC	IE	T <sub>stg</sub>
Value	10(W)	80(V)	80(V)	4.0(V)	4(A)	-4(A)	-55~150(°C) (T <sub>c</sub> =25°C)	

## OUTSIDE VIEWS (S TYPE)










# TS-130SV PC BOARD VIEWS

## ▼ PROCESSOR UNIT (X54-1550-00) Components side view




## ▼ IF UNIT (X48-1300-00,-01) 00:S,01:V Components side view



## CIRCUIT DIAGRAM TS-130SV


▼IF UNIT (X48-1300-00,-01) 00:S,01:V

TS-130V does not use J30 and J31.




# TS-130SV PC BOARD VIEW


## ▼ PLL UNIT (X50-1700-00) Components side view




2SC1675L  
2SC1775(E)  
2SC1923(O)  
2SC1959(Y)




2SC460(B)




3SK40(L)



SN16913P




## ▼PLL UNIT (X50-1700-00)




# TS-130SV PC BOARD VIEW


▼ COUNTER UNIT (X54-1560-00) Components side view




2SC1815(BL)  
2SC1815(Y)  
2SC1959(Y)



2SC785(O)




3SK73(GR)





RB1~4

▼ COUNTER UNIT (X54-1560-00)



# TS-130SV PC BOARD VIEW/CIRCUIT DIAGRAM

## ▼ RF UNIT (X44-1380-00) Components side view



2SC1015(Y)

2SC1675L

2SC1815(Y)






2SC1959(Y)

2SC460(B)

2SC2086


2SK19(Y)

3SK74(L)






# PC BOARD VIEWS/CIRCUIT DIAGRAMS TS-130SV

## ▼ VFO UNIT (X40-1170-00) Components side view




## ▼ CAR UNIT (X50-1500-00) Foil side view



# TS-130SV PC BOARD VIEWS


## ▼ SWITCH (A) UNIT (X41-1310-00)

Components side view



## ▼ SWITCH (B) UNIT (X41-1320-00)

Components side view



## ▼ AF-GEN UNIT (X49-1110-01)

Foil side view

Foil side view of the AF-GEN Unit (X49-1110-01). The diagram shows a complex network of components including transistors Q1-Q21, diodes D1-D28, and various resistors, capacitors, and voltage regulators. Numerous component designators are scattered across the board, indicating a dense assembly of electronic components.

## ▼ RELAY UNIT (X41-1300-00)

Foil side view

Foil side view of the Relay Unit (X41-1300-00). The diagram shows a simplified circuit with components like D1, D2, C1-C6, R1-R6, and a relay coil. A note specifies component values for resistors R1 through R6 and capacitors C1 through C6.

Q1: 2SC1959(Y) D1,2: 1S1555

Q1,18: 2SC2240(GR) Q2: μPC14305H Q3: 2SA473(Y)

Q4~6,10,11,14,16,17,19,20,23,25: 2SC1815(Y) Q7: HA1366W or HA1366WR


Q8,13: 2SC460(B) or 2SC1675L Q9: 2SC1959(Y) Q12: 2SK19(GR) Q15,21: 2SA1015(Y)

Q22: 2SC1815(GR) Q24: 2SA562(Y) D1~4, 11~14,23,24,26: 1N60 D5: WZ-061

D6~9: 1S2588 D15: 1S1587 D17~22,25, 27~29: 1S1555


16

▼ FILTER UNIT (X51-1240-00) S TYPE Components side view



Q1~5,7~9: 2SC1815(Y) Q6: 2SA562(Y) Q10: 2SA473(Y) Q11: 2SK30A(O) D1,2: 1N60 D3: WZ-044  
D4,6,7,9,12,14: 1S1555 D5,10: WZ-061 D8,11,13: WZ-090

▼ FILTER UNIT (X51-1250-00) V TYPE Components side view



Q1: 2SK30A(O) Q2,3,5,6: 2SC1815(Y) Q4: 2SA496(Y) D1: WZ-090 D2,6: 1S1555 D3,4,8: 1N60 D5: WZ-044 D7:WZ-061

2SA1015(Y)

2SC1675L

2SC1815(GR)

2SC1815(Y)

2SC1959(Y)

2SC2240(GR)

卷之三

A diagram showing two electrical terminals, each with two wires attached. The terminals are represented by small rectangular blocks with metal contacts. The wires are shown as thin lines extending from the terminals.

2SA496(Y)

2SA473(Y)








2SA562(Y)

2SK19(GR)

2SK30A(O)


μPC14305H

HA136W  
HA136WR




# TS-130SV PC BOARD VIEWS


## ▼ FINAL UNIT (X56-1300-00) V TYPE Components side view




Q1: 2SC2075 Q2,3: 2SC2509 Q4: 2SC496(Y) Q5: 2SD880(Y)  
D1: SV-4A D2: BZ-240 D3: SV-03




2SC2075  
2SD880(Y)



2SC2509




2SC496(Y)



2SC2290\*J

## ▼ FINAL UNIT (X56-1350-00) S TYPE Components side view



Q1: 2SC2075 Q2,3: 2SC2509 Q4,5: 2SC2290\*J  
Q6,7: 2SD880(Y) D1,3: SV-03 D2: SV-4A D4,5: 1N60

## PARTS LIST

**Note 1:**  
K: U.S.A. T: Britain W: Europe X: Australia

**Note 2:**


Only special type of resistors (example: cement, metal film, etc.) and capacitors (example: electrolytic, tantalum, mylar, temp. coeff. capacitors) are detailed in the PARTS LIST. For the value of all common type components, refer to the schematic diagram of the P.C. board illustration. Resistors not otherwise detailed are carbon type (1/4W or 1/8W). Order carbon resistors and capacitors according to the following example:

A carbon resistor's part number is RD14BY 2E222J.

A ceramic capacitor's number is CK45F1H103Z, CC45TH1H220J.

### RESISTOR

1. Type of the carbon resistor



2. Wattage

1W → 3A      3W → 3F      5W → 3H  
2W → 3D      4W → 3G

3' = CC45 ○ ○ ...

Ceramic capacitor (type I) temperature coeff. capacitor 1' 3'.

1st word (Color)	C (Black)	L (Red)	P (Orange)	R (Yellow)	S (Green)	T (Blue)	U (Violet)
ppm/°C	0	-80	-150	-220	-330	-470	-750

3 = CK45 ○ ○

Ceramic capacitor (type II) 3

Cord	B	D	E	F
Operating temperature °C	-30 +85	-30 +85	-30 +85	-10 +70

6 = Tolerance

Cord	C	D	G	J	K	M	X	Z	P	No cord	
(%)	±0.25	±0.5	±2	±5	±10	±20	±40 -20	±80 -20	±100 -0	More than 10 μF -10 ~ +50	

Less than 10 pF

Cord	B	C	D	F	G
(pF)	±0.1	±0.25	±0.5	±1	±2

Abbreviation	Capacitor	Abbreviation	
Cap	Ceramic	ML	Mylar
C		S	Styren
E	Electrolytic	T	Tantalum
MC	Mica		

3. Resistance value

Example 221 → 220Ω      223 → 22 kΩ      225 → 2.2 MΩ  
222 → 2.2 kΩ      224 → 220 kΩ

4. Tolerance

J = ±5% (Gold)      K = ±10% (Silver)

### CAPACITORS

Type I

CC	45	TH	1H	220	J	CK	45	F	1H	103	Z
1'	2	3'	4	5	6	1	2	3	4	5	6

1 = Type .... ceramic, electrolytic, etc.      4 = Voltage rating  
2 = Shape .... round, square, etc.      5 = Value  
3 = Temp range      6 = Tolerance  
3' = Temp coefficient



Ex. CC45TH = -470 ±60 ppm/°C

2nd Word	G	H	J	K	L
ppm/°C	±30	±60	±120	±250	±500

5 = Capacitor value

Example: 010 → 1 pF  
100 → 10 pF  
101 → 100 pF  
102 → 1000 pF = 0.001μF  
103 → 0.01 μF

CC45



## TS-130 SEMICONDUCTOR

★: New parts

Item	Name	Parts No.	Re-marks
Diode	1N60 1S1007 1S1555 1S1585 1S1587 1S2588 S31C UO5B	V11-0051-05 V11-4160-66 V11-0076-05 V11-3172-76 V11-0370-05 V11-0414-05 V11-2163-86 V11-0270-05	
Varistor	MV-13 SV-03 SV-4A	V21-0004-05 V21-0007-05 V11-4363-36	★
Vari-cap diode	1SV53A	V11-4161-36	

Item	Name	Parts No.	Re-marks
Thermistor	25D29 31D26	V11-3360-16      500Ω at 25°C V11-7762-16      1kΩ at 25°C	★
LED	PR2112D TLY-205	V11-7260-66 V11-3163-16	
Zener diode	BZ-240 XZ-055 XZ-060 WZ-044 WZ-061 WZ-090 WZ-110	V11-4160-96 V11-4105-50 V11-4101-20 V11-4161-06 V11-0243-05 V11-0240-05 V11-4161-46	
Indicating tube	9-BT-12	V40-7760-86	

## PARTS LIST

Item	Name	Parts No.	Re-marks
TR	2SA473 (Y)	V01-0473-06	
	2SA496(Y)	V01-0113-05	
	2SA562(Y)	V01-0032-05	
	2SA1015(Y)	V01-1015-06	
	2SC460 (B)	V03-0079-05	
	2SC496(Y)	V03-0336-05	
	2SC785(O)	V03-0473-05	
	2SC1675L	V03-1675-10	
	2SC1775(E)	V03-1775-06	
	2SC1815(BL)	V03-1815-26	
	2SC1815(GR)	V03-1815-16	
	2SC1815(Y)	V03-1815-06	
	2SC1923(O)	V03-1923-06	
	2SC1959(Y)	V03-1959-06	
	2SC2075	V03-2075-06	
	2SC2086	V03-2086-06	
	2SC2240(GR)	V03-2240-06	
	2SC2290*J	V03-2290-16	
	2SC2509	V03-2509-06	
	2SD880(Y)	V04-0880-16	
FET	2SK19(GR)	V09-0012-05	
	2SK19(Y)	V09-0011-05	
	2SK30A(O)	V09-0056-05	
	2SK125	V09-0136-10	
	3SK40(L)	V09-0079-05	
	3SK73(GR)	V09-1002-46	
	3SK74(L)	V09-1002-56	
IC	74LS163N	V30-1037-06	
	HA1366W	V30-1045-06	
	HD74LS00P	V30-0192-16	
	MC14510BCP	V30-1227-16	
	MC4044P	V30-0173-05	
	SN74LS90N	V30-1005-26	
	SN16913P	V30-1048-06	
	TC4011BP	V30-0301-70	
	TC4029BP	V30-1051-06	
	TC4081BP	V30-0299-10	
	TC4518BP	V30-1039-06	
	TC5064BP	V30-1056-06	
	TC5066BP	V30-1057-06	
	TC5070P	V30-1172-06	
	$\mu$ PC1158H2	V11-1177-26	☆
	$\mu$ PC14305H	V30-1029-36	☆

Ref.No.	Parts No.	Description	Re-marks
<b>TS-130 S,V GENERAL</b>			
	A01-0725-02	Case (upper) <b>V</b>	
	A01-0743-02	Case (upper) <b>S</b>	☆
	A01-0784-02	Case (lower) <b>S</b>	☆
	A01-0785-02	Case (lower) <b>V</b>	☆
	A20-2392-03	Panel ass'y <b>S</b>	☆
	A20-2393-03	Panel ass'y <b>V</b>	☆
	B05-0701-04	SP grill cloth	
	B10-0633-04	Front glass	☆
	B30-0818-05	Pilot lamp	12V,40mA
	B31-0628-05	Meter	<b>S</b>
	B31-0629-05	Meter	<b>V</b>
	B39-0407-04	Spacer	☆
	B42-1644-04	Seal (VOX)	
	B42-1693-04	Seal (Adj.)	
	B43-0645-04	Name plate	<b>S(T)</b>
	B43-0646-04	Name plate	<b>S(K),S(W)</b>
	B43-0647-04	Name plate	<b>V(T)</b>
	B43-0648-04	Name plate	<b>V(K),V(W)</b>
	B46-0058-00	Warranty card	<b>(K)</b>
	B50-2750-00	Operating manual	<b>(K),(W)</b>
	B50-2751-00	Operating manual	<b>(T)</b>
	D21-0807-05	Band shaft	
	D22-0404-05	Universal joint	
	D40-0615-04	Gear ass'y	
	E04-0152-05	UHF type receptacle	<b>ANT</b>
	E06-0252-05	2P male socket	<b>POWER</b>
	E06-0451-15	4P male socket	<b>MIC</b>
	E06-0751-05	7P DIN socket	<b>REMOTE</b>
	E06-0851-05	8P DIN socket	<b>EXT.VFO</b>
	E07-0252-05	2P metal plug	<b>POWER</b>
	E07-0403-05	4P MIC plug	<b>(W),(T)</b>
	E07-0751-05	7P DIN plug	<b>REMOTE</b>
	E08-0671-05	6P square socket	<b>POWER</b>
	E09-0671-05	6P plug	<b>POWER</b>
	E11-0005-15	3P phone jack	<b>KEY</b>
	E11-0402-15	US jack	<b>EXT. SP</b>
	E11-0404-05	3P phone jack	<b>PHONES</b>
	E11-0404-05	3P phone jack	<b>KEY.PHONES</b>
	E12-0001-05	phone plug	<b>EXT. SP</b>
	E23-0015-04	Lug terminal	<b>S</b>
	E23-0417-05	Pin for 6P square socket	<b>POWER</b>
	E23-0418-05	Pin for 6P plug	<b>POWER</b>
	E23-0420-05	Lug terminal	<b>S</b>
	E29-0407-05	Bridge connector	
	E30-1632-05	DC cord with plug	<b>FAN</b>
	E30-1638-05	DC cord ass'y	<b>S</b>
	E30-1675-05	DC cord ass'y	<b>V</b>
	E31-0431-05	Speaker cord with 2P plug	☆
	F05-2034-05	Fuse (20A)	<b>S</b>
	F05-4022-05	Fuse (4A)	<b>V</b>
	F07-0826-03	Heat sink cover	<b>S</b>
	F09-0405-14	Fan	<b>S</b>
	F29-0406-03	Fan motor housing	<b>S</b>
	G01-0801-04	Gnd spring	<b>BAND</b>
	G02-0505-05	Knob spring	
	H01-2705-04	Carton case (inside)	<b>S(K),S(W)</b>
	H01-2706-04	Carton case (inside)	<b>S(T)</b>
	H01-2708-04	Carton case (inside)	<b>V(K),V(W)</b>
	H01-2709-04	Carton case (inside)	<b>V(T)</b>
	H03-1769-04	Carton case (outside)	<b>S</b>
	H03-1770-04	Carton case (outside)	<b>V</b>

## PARTS LIST

Ref.No.	Parts No.	Description	Re-marks	Ref.No.	Parts No.	Description	Re-marks
	H10-2509-02	Packing fixture (F)	V		X56-1300-00	Final unit	V
	H10-2510-02	Packing fixture (R)	S		X56-1350-00	Final unit	S
	H10-2520-02	Packing fixture (R)					
	H12-0441-04	Cushion	V				
	H12-0462-04	Cushion	S				
	H20-1405-03	Protective cover	V				
	H20-1410-03	Protective cover	S				
	H21-0701-04	Protective sheet	VOX				
	H25-0112-04	Protective bag					
	H25-0116-04	Protective bag					
	J02-0323-05	Foot	S				
	J02-0407-04	Assistant foot					
	J13-0404-05	Fuse holder					
	J19-1301-04	Diode holder					
	J21-2504-04	SP mounting hardware	S				
	J21-2573-04	Foot mounting hardware					
	J21-2631-04	Motor mounting hardware					
	J31-0141-04	Spacer ring	MIC				
	J42-0038-04	Cap	Case (lower)				
	J42-0423-04	Knob bush					
	J61-0019-05	Vinyle tie					
	J61-0401-05	Nylon band					
	K21-0723-04	Pointer knob	BAND				
	K23-0710-04	Knob					
	K23-0711-04	Pointer knob	MODE				
	K23-0712-04	Knob	VOX				
	K29-0740-04	Push knob					
	K29-0741-04	Knob					
	L40-1511-03	Ferri-inductor	150μH				
	L40-4711-03	Ferri-inductor	470μH				
	N14-0508-04	Spanner nut M9	BAND				
	N14-0518-04	Spanner nut M7	MODE				
	N19-0607-04	Nylon washer					
VR1	R19-3409-05	Pot. 10kΩ(Α)/10kΩ(Β) RF/AF					
VR2	R19-9405-05	Pot. 10kΩ(Φ)/5kΩ(Β) RIT/IF					
R7	R92-0620-05	Cement resistor 15mΩ					
	S01-2422-05	Rotary switch	MODE				
	S01-2423-05	Rotary switch	BAND	S			
	S36-2402-05	Power switch					
	S44-1407-05	Paddle switch	STBY				
	T03-0027-15	Speaker					
	T40-0301-05	Fan motor		S			
	X40-1170-00	VFO unit					
	X41-1300-00	Relay unit					
	X41-1310-00	Switch (A) unit	power side				
	X41-1320-00	Switch (B) unit	MIC side				
	X44-1380-00	RF unit					
	X48-1300-00	IF unit	S				
	X48-1300-01	IF unit	V				
	X49-1110-01	AF-GEN unit					
	X50-1500-00	CAR unit					
	X50-1700-00	PLL unit					
	X51-1240-00	Filter unit	S				
	X51-1250-00	Filter unit	V				
	X54-1450-01	Indicator unit	VFO				
	X54-1550-00	Processor unit					
	X54-1560-00	Counter unit					

## PARTS LIST

Ref.No.	Parts No.	Description	Re-marks	Ref.No.	Parts No.	Description	Re-marks	
<b>IF UNIT (X48-1300-00,-01) 00:S, 01:V</b>								
L1,2	J31-0502-04	PC Board collar		C3,4	CC45SL1H470J	C 47pF		
	J42-0404-05	PC Board bush		C6	CE04W1C100	E 10μF 16V		
L3	L40-1592-02	Ferri-inductor 1.5μH	☆	C23	C91-0456-05	C 0.047μF 25V		
L4	L34-0966-05	Trap coil 8.83M	☆	C26	CC45SL1H050C	C 5pF ±0.25pF		
L5	L34-0558-05	Trap coil		C27	CC45SL1H180J	C 18pF		
L6	L40-1021-03	Ferri-inductor 1mH		C32	CC45SL1H050C	C 5pF ±0.25pF		
L7	L40-4711-03	Ferri-inductor 470μH		C34,36	C91-0456-05	C 0.047μF 25V		
L8	L34-0967-05	BPF coil 3.5A	☆	C38	CC45SL1H100D	C 10pF ±0.5pF		
L9	L34-0968-05	BPF coil 3.5B	☆	C39,42	CC45SL1H470J	C 47pF		
L10	L34-0969-05	BPF coil 3.5A	☆	C44,51	CE04W1H010	E 1μF 50V		
L11	L34-0970-05	BPF coil 7A	☆	C53	CC45SL1H030C	C 3pF ±0.25pF		
L12	L34-0971-05	BPF coil 7B	☆	C62,63	C90-0817-05	E 1000μF 16V		
L13	L34-0972-05	BPF coil 7C	☆					
L14	L34-0973-05	BPF coil 10A	☆					
L15	L34-0974-05	BPF coil 10B	☆					
L16	L34-0975-05	BPF coil 10C	☆					
L17	L34-0976-05	BPF coil 14A	☆					
L18	L34-0977-05	BPF coil 14B	☆					
L19	L34-0978-05	BPF coil 14C	☆					
L20	L34-0979-05	BPF coil 18A	☆					
L21	L34-0980-05	BPF coil 18B	☆					
L22	L34-0981-05	BPF coil 18C	☆					
L23	L34-0982-05	BPF coil 21A	☆					
L24	L34-0983-05	BPF coil 21B	☆					
L25	L34-0984-05	BPF coil 21C	☆					
L26	L34-0985-05	BPF coil 24.5A	☆					
L27	L34-0986-05	BPF coil 24.5B	☆					
L28	L34-0707-05	BPF coil 24.5C	☆					
L29	L34-0987-05	BPF coil 28A		L1~9	L40-1511-03	Ferri-inductor 150μH S		
L30	L34-0738-05	BPF coil 28B	☆	L1~6	L40-1511-03	Ferri-inductor 150μH V		
L31	L40-4711-03	BPF coil 28C		T1	L34-0957-05	Tuning coil	☆	
L32	L40-1021-03	Ferri-inductor 470μH		T2	L34-0942-05	Tuning coil		
L33	L40-1011-03	Ferri-inductor 100μH		T3	L34-0538-05	Tuning coil		
L34	L40-1592-02	Ferri-inductor 1.5μH		T4,5	L34-0535-05	Tuning coil		
L35	L34-0966-05	Trap coil 8.83M	☆	T6	L34-0536-05	Tuning coil		
L36	L40-1511-03	Ferri-inductor 150μH		T7	L34-0535-05	Tuning coil		
L37,38	L40-4711-03	Ferri-inductor 470μH		T8	L34-0536-05	Tuning coil		
L39	L40-4782-02	Ferri-inductor 0.47μH		CF1	L72-0310-05	Ceramic filter 8.83MHz		
L40~42	L40-4711-03	Ferri-inductor 470μH		XF1	L71-0208-05	MCF 8.83MHz		
L43	L40-1021-03	Ferri-inductor 1mH		VR1	R12-6405-05	Trim. pot 470kΩ		
L44	L40-1011-03	Ferri-inductor 100μH		VR2	R12-0416-05	Trim. pot 470Ω	☆	
L45	L40-1021-03	Ferri-inductor 1mH			R92-0150-05	Short jumper		
L46,47	L40-1011-03	Ferri-inductor 100μH			S51-4401-05	Relay (LZN-4)		
L48	L33-0032-05	Choke coil 3μH		<b>AF-GEN UNIT (X49-1110-01)</b>				
T1	L34-0696-35	Input coil	☆	C1	CC45CH1H100D	C 10pF ±0.5pF		
T2	L19-0303-05	Wide bandwidth trans		C3	CQ92M1H333K	ML 0.033μF		
T3	L30-0506-05	IFT		C4	CE04W1HR47	E 0.47μF 50V		
T4	L34-0697-05	Output coil		C5	CE04W1A221	E 220μF 10V		
T5	L19-0303-05	Wide bandwidth trans		C7,8	CE04W1C100	E 10μF 16V		
T6	L19-0302-05	Wide bandwidth trans		C9	CQ92M1H104K	ML 0.1μF		
VR1	R12-0416-05	Trim. pot 470Ω	☆	C10,11	C90-0817-05	E 1000μF 16V		
VR2	R12-1408-05	Trim. pot 4.7kΩ	☆	C12	CQ92M1H104K	ML 0.1μF		
	R92-0150-05	Short jumper	☆	C13	CE04W1C470	E 47μF 16V		
	S29-3406-05	Rotary wafer ass'y	☆					

## PARTS LIST

Ref.No.	Parts No.	Description			Re-marks	Ref.No.	Parts No.	Description			Re-marks
C14	CQ92M1H104K	ML	0.1μF			L8	L40-1021-03	Ferri-inductor	1mH		
C16	CE04W1C470	E	47μF	16V		T1	L15-0016-05	Choke			
C17	CE04W1H010	E	1μF	50V		T2	L34-0567-05	Tuning coil			
C18	CQ92M1H223K	ML	0.022μF			R14	RS14GB3D8R2J	Metal film	8.2Ω	2W	
C19	CE04W1C100	E	10μF	16V		VR1	R12-3025-05	Trim.pot	10kΩ(B)	RIT	
C21,22	CE04W1C470	E	47μF	16V		VR2	R12-4016-05	Trim.pot	50kΩ(B)	RF	
C23	CQ92M1H104K	ML	0.1μF			VR3	R12-0042-05	Trim.pot	500Ω(B)	9V	
C24	CE04W1C221	E	220μF	16V		VR4	R12-4016-05	Trim.pot	50kΩ(B)	SIDE TONE	
C30~33	CC45CH1H220J	C	22pF			VR5	R12-0401-05	Trim.pot	100Ω(B)	BM	
C37	CC45SL1H151J	C	150pF			VR6	R12-0405-05	Trim.pot	330Ω(B)	ANTI.V	☆
C38	CC45CH1H100D	C	10pF	±0.5pF		VR7	R12-3408-05	Trim.pot	47kΩ(B)	V.GAIN	☆
C39	CC45SL1H180J	C	18pF			VR8	R12-5402-05	Trim.pot	220kΩ(B)	DELAY	☆
C41,42	CC45SL1H101J	C	100pF			R92-0150-05		Short jumper			
C43	CE04W1H010	E	1μF	50V		<b>CAR UNIT (X50-1500-00)</b>					
C44	CE04W1A221	E	220μF	10V		C2	CC45UJ1H220J	C	22pF		
C45	CE04W1C100	E	10μF	16V		C3	CC45UJ1H270J	C	27pF		
C46	CE04W1H010	E	1μF	50V		C4	CC45UJ1H220J	C	22pF		
C47	CQ92M1H473K	ML	0.047μF			C9	CS15E1VR22M	T	0.22μF	35V	
C48	CE04W1A470	E	47μF	10V		C13	CC45SL1H101J	C	100pF		
C49	CE04W1C100	E	10μF	16V		C14	CC45CH1H020C	C	2pF	±0.25pF	
C50	CE04W1H010	E	1μF	50V		C15	CC45CH1H330J	C	33pF		
C51	CE04W1H3R3	E	3.3μF	50V		C16	C91-0456-05	C	0.047μF	25V	
C52	CE04W1H010	E	1μF	50V		TC1,2	C05-0056-05		Ceramic trimmer	30pF	
C55	CC45UJ1H220J	C	22pF								
C56	CC45SL1H101J	C	100pF								
C59	CC45CH1H050C	C	5pF	±0.25pF							
C64,66	CC45SL1H470J	C	47pF								
C67	CE04W1C100	E	10μF	16V							
C68	CE04W1H010	E	1μF	50V							
C69,70	CQ92M1H123K	ML	0.012μF								
C71	CQ92M1H104K	ML	0.1μF								
C72,73	CQ92M1H123K	ML	0.012μF								
C74	CE04W1H010	E	1μF	50V							
C75	CE04W1A101	E	100μF	10V							
C76,77	CE04W1A470	E	47μF	10V							
C78	CQ92M1H223K	ML	0.022μF								
C79	CE04W1H3R3	E	3.3μF	50V							
C80	CE04W1H010	E	1μF	50V							
C81	CQ92M1H473K	ML	0.047μF								
C83	CQ92M1H472K	ML	0.0047μF								
C84	CQ92M1H473K	ML	0.047μF								
C85	CE04W1E4R7	E	4.7μF	25V							
C86	CE04W1E3R3	E	3.3μF	25V							
C90	CE04W1C220	E	22μF	16V							
C91	CQ92M1H153K	ML	0.015μF								
C92	CC45SL1H050C	C	5pF	±0.25pF							
TC1~6	C05-0030-15	Ceramic trimmer	20pF								
	E18-0401-05	Crystal socket	4P								
	E40-0273-05	Mini connect wafer	2P								
	E40-0773-05	Mini connect wafer	7P		☆						
	E40-0911-05	Mini connect wafer	9P								
	E40-1073-05	Mini connect wafer	10P								
	E40-1273-05	Mini connect wafer	12P		☆						
	E40-1373-05	Mini connect wafer	13P								
	F20-0078-05	Insulating board									
	F29-0014-05	Shoulder washer									
L1	L40-1021-03	Ferri-inductor	1mH								
L2,3	L40-1511-03	Ferri-inductor	150μH								
L4	L40-4711-03	Ferri-inductor	470μH								
L5	L40-3392-02	Ferri-inductor	3.3μH								
L6,7	L40-1511-03	Ferri-inductor	150μH								
	<b>PLL UNIT (X50-1700-00)</b>										
	C1	CC45TH1H270J	C	27pF							
	C2	CC45TH1H100D	C	10pF	±0.5pF						
	C3	CC45TH1H220J	C	22pF							
	C5	CC45RH1H390J	C	39pF							
	C6	CC45SH1H560J	C	56pF							
	C7	CE04W1A470Q	E	47μF	10V						
	C8	CC45TH1H270J	C	27pF							

## PARTS LIST

Ref.No.	Parts No.	Description			Re-marks	Ref.No.	Parts No.	Description			Re-marks
C9	CC45TH1H150J	C	15pF			C126	CE04W1A470Q	E	47μF	10V	
C10	CC45TH1H180J	C	18pF			C127	CC45SL1H390J	C	39pF		
C12	CE04W1A470Q	E	47μF	10V		C128	CC45SL1H070D	C	7pF	±0.5pF	
C14	CC45UJ1H680J	C	68pF			C129	CC45CH1H0R5C	C	0.5pF	±0.25pF	
C15	CC45UJ1H100D	C	10pF	±0.5pF		C130	CE04W1C470M	E	47μF	16V	
C16	CC45TH1H150J	C	15pF					E23-0046-04	Square terminal		
C18	CC45TH1H220J	C	22pF					E40-0273-05	Mini connect wafer 2P		
C19	CE04W1A470Q	E	47μF	10V				E40-0573-05	Mini connect wafer 5P		
C20	CC45UJ1H680J	C	68pF					E40-0673-05	Mini connect wafer 6P		
C21	CC45UJ1H330J	C	33pF					E40-0873-05	Mini connect wafer 8P		
C23	CC45TH1H150J	C	15pF					J31-0502-04	PC Board collar		
C24	CC45TH1H080D	C	8pF	±0.5pF				J42-0404-05	PC Board bush		
C25	CC45TH1H120J	C	12pF								
C26	CE04W1A470Q	E	47μF	10V							
C28	CC45TH1H330J	C	33pF			L1~5	L40-1511-03	Ferri-inductor	150μH		
C29	CC45TH1H150J	C	15pF			L6	L40-4701-03	Ferri-inductor	47μH		
C30	CC45UJ1H270J	C	27pF			L7	L40-1511-03	Ferri-inductor	150μH		
C31	CC45TH1H330J	C	33pF			L8	L40-1592-02	Ferri-inductor	1.5μH		
C32	CC45UJ1H220J	C	22pF			L9,10	L40-1092-02	Ferri-inductor	1.0μH		
C34	CE04W1A470Q	E	47μF	10V		L11	L40-1292-02	Ferri-inductor	1.2μH		
C36	CC45UJ1H220J	C	22pF			L12~17	L40-1511-03	Ferri-inductor	150μH		
C37	CC45UJ1H050C	C	5pF	±0.25pF		L18	L40-1011-03	Ferri-inductor	100μH		
C38	CC45CH1H100D	C	10pF	±0.5pF		L19	L40-1511-03	Ferri-inductor	150μH		
C39	CC45CH1H020C	C	2pF	±0.25pF		L20~22	L40-2201-03	Ferri-inductor	22μH		
C41,43	C91-0456-05	C	0.047μF	25V		L23	L40-4711-03	Ferri-inductor	470μH		
C44	CC45SL1H151J	C	150pF			L24,25	L40-1511-03	Ferri-inductor	150μH		
C45	CC45SL1H271J	C	270pF			L26	L40-1001-03	Ferri-inductor	10μH		
C46	CC45SL1H121J	C	120pF			L27	L40-4711-03	Ferri-inductor	470μH		
C48	CC45CH1H100D	C	10pF	±0.5pF		L28	L40-2701-03	Ferri-inductor	27μH		
C49	CC45SL1H470J	C	47pF			L29	L40-1511-03	Ferri-inductor	150μH		
C52	CC45RH1H390J	C	39pF								
C53	CC45RH1H560J	C	56pF			T1	L32-0193-05	OSC coil			
C65	CC45RH1H470J	C	47pF			T2	L32-0195-05	OSC coil			
C66	CC45RH1H220J	C	22pF			T3	L32-0196-05	OSC coil			
C67	CC45RH1H470J	C	47pF			T4	L32-0197-05	OSC coil			
C70	CC45RH1H100D	C	10pF	±0.5pF		T5	L32-0198-05	OSC coil			
C71	CC45SL1H120J	C	12pF			T6	L34-0529-05	Trap coil	8.83M		
C75	CC45TH1H330J	C	33pF			T7	L34-0709-05	Tuning coil	10M		
C76	CC45TH1H150J	C	15pF			T8	L34-0710-05	Tuning coil	20M		
C77	CC45TH1H330J	C	33pF			T9	L34-0712-05	Tuning coil			
C80	CC45UJ1H150J	C	15pF			T10	L34-0713-05	Tuning coil			
C81	CC45UJ1H050C	C	5pF	±0.25pF		T11	L34-0711-05	Tuning coil			
C82	CC45UJ1H150J	C	15pF			T12	L34-0716-05	Tuning coil			
C85	CC45RH1H100D	C	10pF	±0.5pF		T13	L34-0715-05	Tuning coil			
C86	CC45SL1H070D	C	7pF	±0.5pF		T14	L34-0714-05	Tuning coil			
C88	CC45CH1H010C	C	1pF	±0.25pF		T15	L34-0757-05	Tuning coil			
C89	CC45CH1H050C	C	5pF	±0.25pF		T16	L34-0718-05	Tuning coil			
C100,101	CC45SL1H221J	C	220pF			T17	L34-0717-05	Tuning coil			
C102	CQ92M1H122K	ML	0.0012μF			VR1	R12-5014-05	Trim. pot	100kΩ		
C103	CC45SL1H330J	C	33pF				R92-0150-05	Short jumper			
C104,105	CC45SL1H680J	C	68pF								
C106	CC45SL1H330J	C	33pF								
C108,109	C91-0456-05	C	0.047μF	25V							
C110	CC45SL1H390J	C	39pF								
C111	CC45SL1H271J	C	270pF								
C112	C91-0456-05	C	0.047μF	25V							
C113	CE04W1A101Q	E	100μF	10V							
C114	C91-0456-05	C	0.047μF	25V							
C115	CE04W1A470Q	E	47μF	10V							
C120	C91-0456-05	C	0.047μF	25V							
C121	CQ92M1H102K	ML	0.001μF								
C122	CQ92M1H104K	ML	0.1μF								
C123	C91-0456-05	C	0.047μF	25V							
C124	CE04W1A101Q	E	100μF	10V							

## PARTS LIST

Ref.No.	Parts No.	Description			Re-marks	Ref.No.	Parts No.	Description			Re-marks
<b>FILTER UNIT (X51-1240-00) S TYPE</b>											
C2	CC45SL2H221J	C	220pF	500V		L8,9	L34-3001-15	Filter coil (D)			
C3	C91-0456-05	C	0.047μF	25V		L10,11	L34-0830-05	Filter coil (E)			
C4	CC45CH1H680J	C	68pF			L12	L40-1021-03	Ferri-inductor	1mH		☆
C5	CC45CH2H030C	C	3pF ±0.25pF	500V		L13	L34-0989-05	Filter coil (G)			
C7	C91-0456-05	C	0.047μF	25V		L14,15	L40-1021-03	Ferri-inductor	1mH		
C8	CE04W1H010	E	1μF	50V		L16,17	L40-1511-03	Ferri-inductor	150μH		
C10	CE04W1HR47	E	0.47μF	50V		L18	L39-0406-05	Detector coil			
C11	C91-0456-05	C	0.047μF	25V		L19	L40-1511-03	Ferri-inductor	150μH		
C13	CE04W1C100	E	10μF	16V		L20,21	L34-0988-05	Filter coil (F)			☆
C18	CE04W1C221	E	220μF	16V		L22	L34-0989-05	Filter coil (G)			☆
C19	C91-0456-05	C	0.047μF	25V		R23	RC05GF2H151J	Solid	150Ω	1/2W	
C23	CM93D2H561J	MC	560pF	500V		VR1	R12-4016-05	Trim. pot	50kΩ(B)		
C24,25	CM93D2H122J	MC	0.0012μF	500V		VR2	R12-3025-05	Trim. pot	10kΩ(B)		
C26	CM93D2H821J	MC	820pF	500V		VR3	R12-4016-05	Trim. pot	50kΩ(B)		
C27	CC45CH2H151J	C	150pF	500V		VR4	R12-0042-05	Trim. pot	500Ω(B)		
C28	CC45SL2H181J	C	180pF	500V		VR5	R12-1020-05	Trim. pot	1kΩ(B)		
C29	CM93D2H621J	MC	620pF	500V			R92-0150-05	Short jumper			
C30	CC45CH2H151J	C	150pF	500V		RL1	S51-4402-05	Relay (LZN403)			
C31	CC45SL2H181J	C	180pF	500V		<b>FILTER UNIT (X51-1250-00) V TYPE</b>					
C32,33	CC45CH2H121J	C	120pF	500V		C1	CC45SL2H102JTD	C	0.001μF	500V	
C34	CM93D2H471J	MC	470pF	500V		C2	CC45SL2H821JTD	C	820pF	500V	
C35	CC45CH2H680J	C	68pF	500V		C3	CC45SL2H331J	C	330pF	500V	
C36	CC45CH2H151J	C	150pF	500V		C4	CC45SL2H561JTD	C	560pF	500V	
C37	CC45SL2H221J	C	220pF	500V		C5	CC45SL2H331J	C	330pF	500V	
C38	CC45CH2H121J	C	120pF	500V		C6	CC45SL2H561JTD	C	560pF	500V	
C39	CC45CH2H101J	C	100pF	500V		C7	CC45SL2H331J	C	330pF	500V	
C40	CC45CH2H151J	C	150pF	500V		C8	CC45CH2H131J	C	130pF	500V	
C41	CC45SL2H181J	C	180pF	500V		C9	CC45SL2H331J	C	330pF	500V	
C42	CC45CH2H680J	C	68pF	500V		C10	CC45SL2H161J	C	160pF	500V	
C43	CC45CH2H820J	C	82pF	500V		C11	CC45SL2H151J	C	150pF	500V	
C44	CC45CH2H560J	C	56pF	500V		C12	CC45SL2H241J	C	240pF	500V	
C45	CC45CH2H680J	C	68pF	500V		C13	CC45CH2H121J	C	120pF	500V	
C46	CC45CH2H101J	C	100pF	500V		C14	CC45CH2H820J	C	82pF	500V	
C47	CC45CH2H121J	C	120pF	500V		C15	CC45SL2H161J	C	160pF	500V	
C48	CC45CH2H560J	C	56pF	500V		C16	CC45CH2H820J	C	82pF	500V	
C49	CC45CH2H680J	C	68pF	500V		C17	CC45CH2H750J	C	75pF	500V	
C50	CC45CH2H470J	C	47pF	500V		C19	CC45CH1H100D	C	10pF	±0.5pF	
C51	CC45CH2H390J	C	39pF	500V		C20	CC45CH1H101J	C	100pF	500V	
C52,53	CC45CH2H820J	C	82pF	500V		C21	CC45SL2H221J	C	220pF	500V	
C54,55	CC45CH2H680J	C	68pF	500V		C22	C91-0456-05	C	0.047μF	25V	
C56	CC45CH2H820J	C	82pF	500V		C23	CC45SL2H151J	C	150pF	500V	
C57,58	CC45CH2H151J	C	150pF	500V		C26	C91-0456-05	C	0.047μF	25V	
C59,60	CC45CH2H101J	C	100pF	500V		C27	CE04W1HR47	E	0.47μF	50V	
TC1	C05-0043-05	Ceramic trimmer	20pF			C29	CE04W1H010	E	1μF	50V	
	E04-0154-05	Coax. connector				C30	CC45CH2H150J	C	15pF	500V	
	E23-0046-04	Square terminal				C33	CE04W1C470Q	E	47μF	16V	
	E40-0273-05	Mini connect wafer 2P				C34	CE04W1C221Q	E	220μF	16V	
	E40-0373-05	Mini connect wafer 3P				C35	C91-0456-05	C	0.047μF	25V	
	E40-0973-05	Mini connect wafer 9P				TC1	C05-0043-05	Ceramic trimmer	20pF		
	E40-1273-05	Mini connect wafer 12P					E04-0154-05	Coax. connector			
	F20-0078-05	Insulating board					E23-0046-04	Square terminal			
	F29-0014-05	Shoulder washer					E40-0273-05	Mini connect wafer 2P			
	J31-0502-04	PC Board collar					E40-0373-05	Mini connect wafer 3P			
	J42-0404-05	PC Board bush									
L1~3	L34-0826-05	Filter coil (A)									
L4,5	L34-0827-05	Filter coil (B)									
L6,7	L34-0828-05	Filter coil (C)									

## PARTS LIST

Ref.No.	Parts No.	Description	Re-marks	Ref.No.	Parts No.	Description	Re-marks
	E40-0673-05 E40-1073-05	Mini connect wafer 6P Mini connect wafer 10P		C11 C12 C13 C14 C15 C16 C17 C18 C19 C20 C21,22 C23 C24 C25 C26 C27 C28~30 C31,33 C34 C35 C36 C38,39 C40 C41,42 C43 C44,45 C46 C47 C48 C49 C50,51 C52 C53 C55,57,62	CE04W1A101Q C91-0456-05 CC45SL1H470J CC45CH1H390J CC45CH1H101J CC45CH1H270J C91-0456-05 CC45SL1H221J CC45SL1H220J CC45SL1H050C C91-0456-05 CE04W1A101Q CC45SL1H101J CC45SL1H270J CC45SL1H560J CC45SL1H270J CC45SL1H470J C91-0456-05 CC45SL1H101J CC45SL1H221J CC45SL1H101J C91-0456-05 CC45SL1H150J C91-0456-05 C91-0456-05 CQ92M1H103K C91-0456-05 CE04W1A101Q CE04W0J221Q CE04W1V100Q CQ92M1H103K CE04W1V100Q C91-0456-05 CE04W1V100Q C91-0456-05	100μF 10V 0.047μF 25V 47pF 39pF 100pF 27pF 0.047μF 25V 220pF 22pF 5pF ±0.25pF 0.047μF 25V 100μF 10V 100pF 27pF 56pF 27pF 47pF 0.047μF 25V 100pF 220pF 100pF 0.047μF 25V 15pF 0.047μF 25V 0.01μF 0.047μF 25V 100μF 10V 220μF 6.3V 10μF 35V 0.01μF 10μF 35V 0.047μF 25V 0.047μF 25V	
L1,2 L3,4 L5 L6 L7,8 L9,10 L11 L12,13 L14,15 L16,17	L34-0826-05 L34-0827-05 L34-0828-05 L34-0724-05 L34-0829-05 L34-0830-05 L39-0404-05 L40-1511-03 L40-1021-03 L40-1511-03	Filter coil Filter coil Filter coil Filter coil Filter coil Filter coil Detector coil Ferri-inductor 150μH Ferri-inductor 1mH Ferri-inductor 150μH		R4	RC05GF2H103K	Solid 10kΩ 1/2W	
VR1 VR2,3 VR4	R12-3025-05 R12-4016-05 R12-1020-05	Trim. pot 10kΩ(Β) Trim. pot 50kΩ(Β) Trim. pot 1kΩ(Β)		VR1 VR2,3 VR4	R92-0150-05 S01-2424-05 S51-4402-05	Short jumper Rotary switch Relay (LZN403)	★
<b>PROCESSOR UNIT (X54-1550-00)</b>							
C1~4 C5 C6,7 C8 C9 C10 C11	CE04W1H010Q CE04W1H3R3Q CE04W1H010Q CE04W1H4R7Q CE04W1C100Q CE04W1H4R7Q CE04W1C470Q	E 1μF 50V E 3.3μF 50V E 1μF 50V E 4.7μF 50V E 10μF 16V E 4.7μF 50V E 47μF 16V		TC1	C05-0035-05 E31-0466-05 E40-0273-05 E40-0373-05 E40-1273-05 E40-1373-05	Ceramic trimmer 50pF Tape cable Mini connect wafer 2P Mini connect wafer 3P Mini connect wafer 12P Mini connect wafer 13P	
VR1,S1 VR2	R19-3408-05 R12-5406-05	Pot. with SW 10kΩ(Α),10kΩ(Β) Pot. 100kΩ	★	R92-0150-05	J31-0502-04 J42-0404-05	PC Board collar PC Board bush	
		Short jumper	★	L1~4 L5,6 L7,8 L9,10 L11,12 L13	L40-4711-03 L40-4701-03 L40-4711-03 L40-2211-03 L40-1511-03 L40-1011-04	Ferri-inductor 470μH Ferri-inductor 47μH Ferri-inductor 470μH Ferri-inductor 220μH Ferri-inductor 150μH Ferri-inductor 100μH	
<b>COUNTER UNIT (X54-1560-00)</b>							
C1 C2 C3 C4 C5 C6 C7 C9,10	CC45CH1H330J CC45SL1H391J CC45CH1H470J C91-0456-05 CC45SL1H150J CC45SL1H020C CC45SL1H100D C91-0456-05	C 33pF C 390pF C 47pF C 0.047μF 25V C 15pF C 2pF ±0.25pF C 10pF ±0.5pF C 0.047μF 25V		X1 R68 RB1 RB2,3 RB4	L77-0482-05 RC05GF2H151K R90-0522-05 R90-0521-05 R90-0522-05 R92-0150-05	OSC trans Crystal 10MHz Solid 150Ω 1/2W Resistor block 47kΩ X6 Resistor block 47kΩ X7 Resistor block 47kΩ X6 Short jumper	


## PARTS LIST

Ref.No.	Parts No.	Description			Re-marks	Ref.No.	Parts No.	Description			Re-marks	
<b>FINAL UNIT (X-56-1300-00) V TYPE</b>												
C1,3	C91-0456-05	C	0.047μF	25V			E23-0043-04	Antenna earth lug				
C5,6,10	C91-0456-05	C	0.047μF	25V			E23-0046-04	Square terminal				
C12~14	C91-0456-05	C	0.047μF	25V			E23-0401-05	Round terminal				
C16,18	C91-0456-05	C	0.047μF	25V			E23-0420-05	Earth lug				
C19	CE04W1C101	E	100μF	16V			E40-0273-05	Mini connect wafer 2P				
C20	CE04W1C100	E	10μF	16V			E40-0373-05	Mini connect wafer 3P				
C21	CC45SL2H151J	C	150pF	500V			F01-0735-05	Heat sink				
C22	CC45SL1H471J	C	470pF				F20-0078-05	Insulating board				
C23	CC45SL2H680J	C	68pF	500V			F29-0014-05	Shoulder washer				
C24	C91-0456-05	C	0.047μF	25V			J31-0503-05	Bead				
		E23-0401-05	Round terminal				J32-0730-04	Hex. boss			☆	
		F01-0717-13	Heat sink A			★	L1	L40-1001-04	Ferri-inductor 10μH			
		F20-0078-05	Insulating board				L3,4	L33-0032-05	RFC			
		F29-0014-05	Shoulder washer				L7	L33-0617-05	RFC			☆
L1	L40-4701-03	Ferri-inductor	47μH				L8	L33-0025-05	RFC			
L3,6	L33-0032-05	RFC	3μH				L9	L33-0625-15	RFC			
L7	L33-0617-05	RFC					L10~12	L40-1011-04	Ferri-inductor 100μH			
T1	L19-0315-25	Wide bandwidth trans					L13,14	L40-1021-03	Ferri-inductor 1mH			
T2	L19-0306-15	Output trans				☆	T1	L19-0315-25	Wide bandwidth trans			☆
R6,7	RC05GF2H560J	Solid	56Ω	1/2W			T2	L19-0311-05	Input trans			☆
R11	RC05GF2H4R7J	Solid	4.7Ω	1/2W			T3	L19-0313-15	NF trans			☆
R17,18	RC05GF2H560J	Solid	56Ω	1/2W			T4	L19-0312-05	Output trans			☆
VR1	R12-0412-05	Trim. pot	200Ω(B)				N19-0611-04	Washer				
	R92-0150-05	Short jumper					R3	RC05GF2H4R7J	Solid	4.7Ω	1/2W	
							R12,13	RC05GF2H101J	Solid	100Ω	1/2W	
							R14~17	RS14AB3A3R9J	Metal film	3.9Ω	1W	
							R18,19	RC05GF2H150J	Solid	15Ω	1/2W	
							R20~23	RC05GF2H5R6J	Solid	5.6Ω	1/2W	
							VR1,2	R12-0058-05	Trim. pot	470Ω(B)		
							R92-0150-05	Short jumper				
							TM1	S59-1404-05	Thermostat	Heat sink		
							TM2	S59-1403-05	Thermostat	core		
<b>FINAL UNIT (X56-1350-00) S TYPE</b>												
C1	C91-0455-05	C	0.01μF	25V			<b>VFO ASS'Y UNIT (X60-1160-00)</b>					
C3,4	C91-0456-05	C	0.047μF	25V			B01-0621-04	Dial escutcheon				
C6	C91-0455-05	C	0.01μF	25V			B08-4301-04	Dial back board			☆	
C11	C91-0456-05	C	0.047μF	25V			B10-0634-04	Front glass (A)			☆	
C12	CE04W1E100	E	10μF	25V			B20-0811-04	Dial scale (B)	25K			
C13,14	C91-0456-05	C	0.047μF	25V			B20-0817-04	Dial scale (A)	500K		☆	
C15	CM93AD2H151J	MC	150pF	500V			B42-1645-04	Seal Bottom				
C18,19	C91-0456-05	C	0.047μF	25V			B42-1671-04	Seal Top			☆	
C20	CE04W1E101	E	100μF	25V			G01-0804-04	Coil spring				
C21,24	C91-0456-05	C	0.047μF	25V			J19-1317-04	Diode holder				
C25	CE04W1E100	E	10μF	25V			K21-0722-04	Main knob				
C33,34	C91-0448-05	Laminated cap.	0.68μF				N19-0613-04	washer B				
C35	C91-0456-05	C	0.047μF	25V			X40-1170-00	VFO unit				
C37	CE04W1H101Q	E	100μF	50V			X54-1450-01	INDICATOR unit				
C38	C91-0456-05	C	0.047μF	25V							☆	
C39	CM93AD2H271J	MC	270pF	500V								
C40	CM93AD2H331J	MC	330pF	500V								
C41~43	C91-0455-05	C	0.01μF	25V								
C44	CM93AD2H271J	MC	270pF	500V								
C47	CM93AD2H331J	MC	330pF	500V								
C50	CC45SL1H220J	C	22pF									
C51,52	C91-0455-05	C	0.01μF	25V								
C53	CC45SL1H471J	C	470pF									
	E04-0152-05	UHF type receptacle										
	E08-0271-05	DC socket	FAN									



## PARTS LIST/PACKING

Ref.No.	Parts No.	Description	Re-marks
<b>VFO UNIT (X40-1170-00)</b>			
C2	C91-0456-05	C 0.047μF 25V	
C4	CC45RG1H030C	C 3pF ±0.25pF	
C5	CC45PG1H020C	C 2pF ±0.25pF	
C6	C91-0456-05	C 0.047μF 25V	
C7	CC45LG1H151J	C 150pF	
C9	CC45LG1H121J	C 120pF	
C12	CC45LG1H680J	C 68pF	
C13	CC45LG1H220J	C 22pF	
C14	CC45CG1H100D	C 10pF ±0.5pF	
C15	CC45LG1H151J	C 150pF	
C16	CC45LG1H151J	C 150pF	
C17	CC45CH1H020C	C 2pF ±0.25pF	
C18	C91-0456-05	C 0.047μF 25V	
C21	CC45SL1H390J	C 39pF	
C22	CC45CH1H100D	C 10pF ±0.5pF	
C23	CC45SL1H390J	C 39pF	
C24	C91-0456-05	C 0.047μF 25V	
TC1	C05-0009-15	Ceramic trimmer 6pF	
TC2	C05-0013-15	Ceramic trimmer 20pF	
	C02-0019-05	Variable cap.	☆
	D40-0614-05	Dial mechanism ass'y	☆
	E40-0574-05	Mini connect wafer 5P	
L1	L32-0628-05	OSC coil	
L2	L33-0025-05	Choke coil 1μH	
L3	L32-0629-05	OSC coil (C)	☆
L4	L32-0609-05	OSC coil (B)	
L5	L40-1021-03	Ferri-inductor 1mH	
L6	L40-4711-03	Ferri-inductor 470μH	
L7	L40-1021-03	Ferri-inductor 1mH	
L8	L40-1501-03	Ferri-inductor 15μH	
L9~11	L40-4711-03	Ferri-inductor 470μH	
R92-0150-05	R92-0150-05	Short jumper	

## PACKING




## DISASSEMBLY




## DISASSEMBLY


### FINAL UNIT (S type)




### FINAL UNIT (V type)



## RECEIVER SECTION



## TRANSMITTER SECTION (S TYPE)



## LEVEL DIAGRAM

## ADJUSTMENTS

## GENERAL

Adjustment procedures for this transceiver are classified into formal adjustments requiring a full service bench and simplified adjustment using a VTVM, AF and RF VTVM, AG, and AF and RF dummy load.

Complete adjustment also requires a frequency counter, SSG, sweep generator, etc.

## TEST EQUIPMENT REQUIRED

## 1. VTVM or DVM

- 1) Input resistance: More than  $1M\Omega$
- 2) Voltage range: 1.5 to 1000V AC/DC

**NOTE :** A high-precision voltmeter may be used. However, accurate readings can not be obtained for high-impedance circuits.

## 2. DC current meter

- 1) Current range: 100mA, 200mA, 2A, 10A, High-precision current meter may be used.

## 3. RF VTVM

- 1) Input impedance:  $1M\Omega$  and less than 3 pF, min.
- 2) Voltage range: 10mV to 300V
- 3) Frequency range: 50MHz or greater

**NOTE:** During adjustment special accuracy is not required (such as input level or PLL circuit carrier oscillator output), a VTVM or VOM may substitute for an RF VTVM by measuring through the output of a detector as shown in item 14.

## 4. AF VTVM

- 1) Frequency range: 50Hz to 10kHz
- 2) Input resistance:  $1M\Omega$  or greater
- 3) Voltage range: 10mV to 30V

## 5. AF GENERATOR (AG)

- 1) Frequency range: 200Hz to 5kHz
- 2) Output: 2mV~1V, low distortion

## 6. AF DUMMY LOAD

- 1) Impedance:  $8\Omega$
- 2) Dissipation: 3W or greater

## 7. RF DUMMY LOAD

- 1) Impedance:  $50\Omega$ ,  $150\Omega$
- 2) Dissipation: 100W continuous or greater
- 3) Frequency limits: 1.8 to 30MHz

The above-mentioned instruments may be used for simplified adjustment. For complete, precise adjustment, the following instruments are also necessary.

## 8. OSCILLOSCOPE

Requires high sensitivity, and external synchronization capability.

## 9. SWEEP GENERATOR

- 1) Center frequency: 8.83MHz
- 2) Frequency deviation: Maximum  $\pm 5\text{kHz}$
- 3) Output voltage: More than 0.1V
- 4) Sweep rate: At least 0.5 sec/cm

## 10. Standard Signal Generator (SSG)

- 1) Frequency range: 1.8 to 30MHz
- 2) Output:  $-20\text{dB}/0.1\mu\text{V} \sim 120\text{dB}/1\text{V}$

**NOTE:** Generator must be frequency stable.

## 11. FREQUENCY COUNTER

- 1) Minimum input voltage: 50mV
- 2) Frequency range: Greater than 40MHz

## 12. NOISE GENERATOR

Must generate ignition noise containing harmonics beyond 30MHz.


## 13. Spectrum analyzer

- 1) Frequency range: 100K to 110MHz
- 2) Bandwidth: 1kHz to 3MHz


**NOTE:** R-1000 receiver may be used.

## 14. Detector

- 1) For adjustment of TX BPF



- 2) For adjustment of PLL unit BPF



## 15. Directional coupler

## 16. FIX-CH adjusting crystal element

- 1) 5.750MHz (center: 250kHz)

## REFERENCE

Japanese "SSG"	American "SG"
-6dB . . . . .	.025μV
0dB . . . . .	.5μV
6dB . . . . .	.1μV
12dB . . . . .	.2μV
24dB . . . . .	.8μV
30dB . . . . .	.15.8μV
40dB . . . . .	.50μV
50dB . . . . .	.158μV
60dB . . . . .	.500μV
70dB . . . . .	.158mV
80dB . . . . .	.5mV
90dB . . . . .	.15.8mV
100dB . . . . .	.50mV
120dB . . . . .	.05V

## ADJUSTMENTS

### PREPARATION

Unless otherwise specified, set the controls as follows.

POWER . . . . .ON

AF GAIN . . . . .COUNTERCLOCKWISE

RF GAIN . . . . .FULL CLOCKWISE

RIT SW. . . . .OFF

IF SHIFT . . . . .CENTERED

NODE . . . . .SSB

SEND/REC . . . . .REC

NB . . . . .OFF

FIX./VFO . . . . .VFO

VOX/MAN. . . . .MAN


PROC. . . . .OFF

WIDE/NAR . . . . .WIDE

**Caution:**  
3.3V is required if  
3SK40(L) or (K)  
are used in the RF  
unit(Q1,3,4) and  
IF unit(Q2~4).

(V): TS-130 V type



(S): TS-130 S type

Item	Condition	Measuring point			Adjust			Specifications/Remarks		
		Test equipment	Unit	Terminal	Unit	Parts	Reference			
1. Power Supply voltage	DC VTVM	AF-GEN	J4,7P	AF-GEN		3.8V				
			J4,4P		VR3	9V				
			J4,5P			50V				
	STBY:SEND	Filter	AVB	Filter	VR2	2.8V	←			
2. CAR 1) CAR output 2) Freq. RX	BAND:3.5	RF VTVM	AF-GEN	J3,2P	CAR	T1	0.3Vrms	0.3V±1dB		
	STBY:REC					TC2	8.82850MHz			
	IF SHIFT: Centered	Frequency counter			TC1	8.83150MHz				
	MODE:SSB MODE:REV	Frequency counter	AF-GEN	J3,2P	CAR	VR2	8.83070MHz			
3. IF SHIFT	MODE:SSB STBY:Alter- nate SEND/REC	Frequency counter	AF-GEN	J3,2P	CAR	VR1	8.82850MHz	RX and TX frequency no change.		
4. VFO 1) Output 2) 800Hz shift	VFO scale:250 MODE:CW STBY:SEND	RF VTVM Frequency counter	AF-GEN	J1,6P	VFO	TC2 L4	0.2Vrms Adjust for 800Hz higher than receive state.	0.2V±1dB rms 800±50Hz		
3) Frequency tracking and check	VFO:50 Set the CAL control to the index. VFO scale: Approx. 450 Set the CAL control calibra- ted under this VFO setting ex- actly to the index.					L3	5550.00kHz ±200Hz	Repeat this adjustment several times until the frequency is within specification.		
						TC1	5950.00kHz ±200Hz			
				Set the VFO main tuning to 5750.000kHz.						
	Under the above condition, set the CAL control to the index. Turn the main tuning, and set the calibrated CAL control to the index in the order of 0, 100, 200, 300, 400, and 500 to check frequency deviation at each 100kHz point.					0 100 200 300 400 500	5.5MHz 5.6 5.7 5.8 5.9 6.0	Within ±2kHz		
	Set the CAL control back to 250 under the above condition (do not turn excessively.), then further set back the CAL control to 0 with respect to the frequency at 250 to check The difference from the reference frequency.						Less than 400Hz	Backlash		

## ADJUSTMENTS

Item	Condition	Measuring point			Adjust			Specification/Remarks																																																												
		Instruments	Unit	Terminal	Unit	Parts	Reference																																																													
5. RIT	1) Adjust VFO frequency to 5.75MHz 2) RIT control: Centered	Frequency counter	AF-GEN	J1,6P	AF-GEN	VR1	Alternate RIT ON and OFF	1) No frequency change between RIT ON and OFF 2) More than $\pm 1.5\text{kHz}$ variable RIT range																																																												
6. VCO	VFO BAND 250 3.5 250 7 250 14 250 18 250 21 500 28.5	DCVTVM Frequency counter	PLL	TP1	PLL	T1 T2 T3 T5 T4 —	3.5V 5.5V 4.0V 6.1V 3.75V 4.75V (check)	Oscillator level $1\text{V} + 3\text{dB}, -1\text{dB}$ at J18, 1P on PLL unit																																																												
								<table border="1"> <tr> <th>VFO BAND</th> <th>0</th> <th>250</th> <th>500</th> <th></th> </tr> <tr> <td>3.5</td> <td>12.33M</td> <td>(3.5V)</td> <td>12.58M</td> <td>12.83M</td> </tr> <tr> <td>7.0</td> <td>15.83M</td> <td>(5.5V)</td> <td>16.08M</td> <td>16.33M</td> </tr> <tr> <td>10.0</td> <td>18.33M</td> <td>19.08M</td> <td>19.33M</td> <td></td> </tr> <tr> <td>14.0</td> <td>22.83M</td> <td>(4V)</td> <td>23.08M</td> <td>23.33M</td> </tr> <tr> <td>21.0</td> <td>29.83M</td> <td>(3.75V)</td> <td>30.08M</td> <td>30.33M</td> </tr> <tr> <td>24.5</td> <td>33.33M</td> <td>33.58M</td> <td>33.83M</td> <td></td> </tr> <tr> <td>18.0</td> <td>26.83M</td> <td>(6.1V)</td> <td>27.08M</td> <td>27.33M</td> </tr> <tr> <td>28.0</td> <td>36.83M</td> <td>37.08M</td> <td>37.33M</td> <td></td> </tr> <tr> <td>28.5</td> <td>37.33M</td> <td>37.58M</td> <td>37.83M</td> <td></td> </tr> <tr> <td>29.0</td> <td>37.83M</td> <td>38.08M</td> <td>38.33M</td> <td></td> </tr> <tr> <td>29.5</td> <td>38.33M</td> <td>38.58M</td> <td>38.83M</td> <td></td> </tr> </table>	VFO BAND	0	250	500		3.5	12.33M	(3.5V)	12.58M	12.83M	7.0	15.83M	(5.5V)	16.08M	16.33M	10.0	18.33M	19.08M	19.33M		14.0	22.83M	(4V)	23.08M	23.33M	21.0	29.83M	(3.75V)	30.08M	30.33M	24.5	33.33M	33.58M	33.83M		18.0	26.83M	(6.1V)	27.08M	27.33M	28.0	36.83M	37.08M	37.33M		28.5	37.33M	37.58M	37.83M		29.0	37.83M	38.08M	38.33M		29.5	38.33M	38.58M	38.83M	
VFO BAND	0	250	500																																																																	
3.5	12.33M	(3.5V)	12.58M	12.83M																																																																
7.0	15.83M	(5.5V)	16.08M	16.33M																																																																
10.0	18.33M	19.08M	19.33M																																																																	
14.0	22.83M	(4V)	23.08M	23.33M																																																																
21.0	29.83M	(3.75V)	30.08M	30.33M																																																																
24.5	33.33M	33.58M	33.83M																																																																	
18.0	26.83M	(6.1V)	27.08M	27.33M																																																																
28.0	36.83M	37.08M	37.33M																																																																	
28.5	37.33M	37.58M	37.83M																																																																	
29.0	37.83M	38.08M	38.33M																																																																	
29.5	38.33M	38.58M	38.83M																																																																	
								Note( ):control voltage																																																												
7. TX BPF (RX BPF)	MODE:SSB STBY:SEND Make adjustments in the following sequence: 3.5 → 7 → 10 → 14 → 18 → 21 → 24.5 → 28 MHz. Disconnect connector J18 on the PLL unit and connect the sweep generator RF output to it. Connect the detector input to the DRV terminal on the RF unit.	Sweep generator, Oscilloscope, Detector	PLL RF	J18 DRV	RF	L7~30	Adjust coils for waveform as shown.	<p>The figure shows eight frequency bands with their respective center frequencies and ripple requirements:</p> <ul style="list-style-type: none"> <li>3.5M: Ripple less than 5dB</li> <li>7M: Ripple less than 2dB</li> <li>10M: Ripple less than 2dB</li> <li>14M: Ripple less than 2dB</li> <li>18M: Ripple less than 2dB</li> <li>21M: Ripple less than 1dB</li> <li>24.5M: Ripple less than 1dB</li> <li>28M: Ripple less than 2dB</li> </ul>																																																												
8. PLL BPF 1) BPF-A	STBY:REC Disconnect connectors J17 and J19 on the PLL unit. Connect the cathode of D17 on the PLL unit to the jumper wire next to the D22 on the AF-GEN unit with a lead. Connect the sweep generator RF output to the J19, 3P (VFO) on the PLL unit. Connect the detector input to Q16 emitter on the PLL unit.	Detector, Oscilloscope, Sweep generator	PLL	Q16(E)	PLL	T9 T10 T11	Adjust T9~T11 for waveform as shown at right.	<p>The figure shows a single waveform with three distinct peaks labeled 14.23, 14.58, and 14.93, representing the three bands of the BPF-A filter.</p>																																																												

## ADJUSTMENTS

Item	Condition	Measuring point			Adjust			Specifications/Remarks
		Instruments	Unit	Terminal	Unit	Parts	Reference	
2) BPF-B	Disconnect connectors J17 and J19 on the PLL unit. Connect the cathode of D24 and D27 on the PLL unit to the jumper wire next to the D22 on the AF-GEN unit with a lead. Connect the sweep generator RF output to the anode of D28 on the PLL unit via a 15pF capacitor. Detector input: Same as above	Detector, Oscillo-scope, Sweep generator	PLL	Q16 (E)	PLL	T12 T13 T14 T7	Adjust T12~T14 for waveform as shown at right. Adjust T7 for maximum output.	
3) BPF-C	Disconnect connectors J17 and J19 on the PLL unit. Connect the cathode of D20 and D27 on the PLL unit to the jumper wire next to the D22 on the AF-GEN unit. Sweep generator RF output: Same as above. Detector input: Same as above					T15 T16 T17 T8	Adjust T15~T17 for waveform as shown at right. Adjust T8 for maximum output	
9. VFO.MIX spurious	Note: This adjustment should be done after completing the BPF-A adjustment(or check). Disconnect connector J17 on the PLL unit. Connect the cathode of D17 on the PLL unit to the jumper wire next to the D22 on the AF-GEN unit. VFO scale:250 MODE:CW	Spectrum analyzer or monitor receiver	PLL	Q16 (E)	PLL	VR1	Adjust for minimum output at 14.99MHz.	Less than -55dB
10. PLL-IF trap	Disconnect connector J17 on the PLL unit. Connect the SSG output 8.83MHz, 60dB to Q7 emitter on the PLL unit via a 0.01μF capacitor.	SSG, RF VTVM	PLL	Q7 (E) J18,1P	PLL	T6	Adjust for minimum output.	




## ADJUSTMENTS

Item	Condition	Measuring point			Adjust			Specifications/Remarks
		Instruments	Unit	Terminal	Unit	Parts	Reference	
11. IF AMP	VFO:250 IF SHIFT: Centered VFO/FIX: VFO MODE:SSB BAND:14 AF GAIN:10 o'clock RF GAIN: Fully clockwise Connect the SSG output 14.25MHz, -6dB to the ANT terminal.	SSG, Oscillo- scope, AF VTVM, AF Dum- my load		SP	RF	T3	The slug of T3 should be turned counter- clockwise from the peak point to reduce audio output by 2dB. Adjust T1~T6 for maximum audio output.	
12. IF trap	1) BAND: 10MHz VFO:any fre- quency SSG:8.83 MHz, 80dB	SSG, AF VTVM		SP	RF	L3 L4 L35	Adjust for minimum S-meter reading and AF output level. Repeat the procedure two or three times.	L3 and L4 should be adjusted while they are turned counterclockwise.
13. NB	BAND:10 VFO:250 NB SW:ON Connect the SSG output 10.25 MHz, 60dB to the ANT terminal.	DC VTVM, SSG	IF	TP (Q15 (C))	IF	T7 T8	Adjust for mini- mum DC voltage.	
	Disconnect the SSG output. Connect the noise genera- tor output to the ANT ter- minal. Set the noise ge- nerator output level to S5~7.	Noise generator			IF	T2	Turned counter- clockwise 90 de- gree from the peak point.  If adequate effect is not obtained, repeat the adjust- ment several times.	T2 has been adjusted for the peak point in item 11.  The NB must provide adequate effect.
14. Carrier balance (IF SHIFT)	IF SHIFT: Centered RF GAIN: Counterclock- wise	RF VTVM	IF	Q7 (E)	AF-GEN	TC1	Adjust for mini- mum.	
15. S meter 1) Starting level 2) S1 3) S9	RF GAIN: Fully counter- clockwise				IF	VR2	Set to starting level.	
	BAND:14 VFO:175 MODE:CW SSG:14.175M, 8dB				T5	Set to S1.	T5 should be adjusted while it is turned counterclockwise.	
	SSG:14.175M, 40dB				VR1	Set to S9.		
16. Counter standard Oscillator	BAND:10 VFO:0 Receive WWV signal.				Counter	TC1	Set to zero beat.	

## ADJUSTMENTS

Item	Condition	Measuring point			Adjust			Specifications/Remarks
		Instruments	Unit	Terminal	Unit	Parts	Reference	
17. Base current 1) S type	MODE:SSB MIC GAIN: Full counter-clockwise DC current meter:Connect $\oplus$ to D14 lead, $\ominus$ to D14 terminal. STBY:SEND STBY:REC	DC current meter	Final	D14	Final	VR1	150mA	
	DC current meter:Connect $\ominus$ to red wire from F14 terminal, $\oplus$ to 3P terminal. STBY:SEND STBY:REC		F14 3P terminal			VR2	100mA	
	DC current meter:Connect $\oplus$ to 14A, $\ominus$ to D2 side. STBY:SEND STBY:REC		Final	14A	Final	VR1	100mA	
	BAND:14 MODE:CW STBY:SEND Reduce RF power(S type) to 30W, RF meter(V type) to 3 by CAR level control. STBY:REC	Power meter			AF-GEN RF	T2 T4	Adjust for maximum RF output.	
	BAMD:14 CAR LEVEL: Centered VFO:200 MODE:CW STBY:SEND Filter unit, VR2:Counter-clockwise BAND:28.5				Filter	VR3	Set to 95W.	
	Same as above.				VR2		Set to 75W.	
19. ALC (RF power) 1) S type	BAND:14 CAR LEVEL: Centered VFO:200 MODE:CW STBY:SEND Filter unit, VR2:Counter-clockwise BAND:28.5	Power meter			Filter	VR3	Set to 11W.	
	Same as above.				VR2		Set to 11W.	
20. RF meter (V type only)	BAND:14 MODE:CW Meter:RF(IC) STBY:SEND STBY:REC	Power meter			Filter	VR1	Set to RF8.	
					VR2		Set to 75W.	
21. IC meter (S type only)	MODE:CW DC current meter:Connect $\ominus$ to red wire from F14 terminal, $\oplus$ to 3P terminal. STBY:SEND STBY:REC	Power meter, DC current meter			Filter	VR4	Set to 11A on IC meter.	
					VR2		Set to 11A on IC meter.	


## ADJUSTMENTS

Item	Condition	Measuring point			Adjust			Specifications/Remarks
		Instruments	Unit	Terminal	Unit	Parts	Reference	
22. Protection 1) S type	Filter unit,VR1: Fully clockwise BAND:14 MODE:CW ANT:Power meter(50Ω) STBY:SEND	DVM, power meter (50Ω)	Filter	TP1 TP2	Filter	TC1	Adjust for mini- mum.	Approx. 0.2~0.4V 
	150Ω,100W Dummy load				VR1		Adjust VR1 to obtain 39W RF power.	
2) V type	Filter unit,VR1: Fully clockwise BAND:14 MODE:CW ANT:50Ω Dummy STBY:SEND STBY:REC	Through type power meter	Filter	TP1 TP2	Filter	TC1	Adjust for mini- mum.	Approx. 40~50mV.
	ANT:Shorted STBY:SEND STBY:REC	DC current meter			Filter	VR2	Set to 2.3A.	
	BAND:21 VFO:250 MODE:SSB MIC,CAR level: Fully counter- clockwise STBY:SEND STBY:REC	RF VTVM	RF	Common terminal of rotary switch	RF	VR1	Adjust for mini- mum.	
	BAND:14 MIC input: AG 1.5kHz, 7mV MODE:SSB STBY:SEND 1) Adjust MIC GAIN control until RF power becomes 50 W(S type),5W (V type). 2) Change AG frequency to 300Hz and 2.7kHz alter- nately. MODE:SSB and REV	Power meter, Synchro- scope, AG			CAR	TC1 (SSB) TC2 (REV)	Adjust TC1 and TC2 so that RF power is equal at AG frequency 300Hz and 2.7 kHz.	Within -6dB at AG frequency 400Hz and 2.6kHz respect to 1.5kHz signal level.
25. Carrier suppression Note: This ad- justment should be done after completing the SSB carrier point adjust- ment (or check) in item 24.	BAND:14 MODE:CW↔ SSB,REV STBY:SEND MIC:No input	Power meter, Oscillo- scope		ANT	AF-GEN	VR5 TC2	Adjust VR5 and TC2 alternately for minimum output.	Carrier better than 40dB down from output signal.
	STBY:REC							
26. Speech processor	MODE:SSB MIC input: AG 1kHz,10mV PROC: ON↔OFF	AF VTVM	Processor	TP1	Processor	VR2	Adjust for equal level.	Approx. 150mV
27. Side tone	MODE:CW AF GAIN: 12:00 KEY:Plug a key and operate.	AF VTVM, KEY		SP	AF-GEN	VR4	Set to 0.63V/8Ω.	


## ADJUSTMENTS

## PC BOARD ALIGNMENT



## ▼ RF UNIT (X44-1380-00)



## ▼ VFO UNIT (X40-1170-00)







## ▼ IF UNIT (X48-1300-00)



## DISPLAY SECTION


## ADJUSTMENTS

## ▼ FILTER UNIT (X51-1240-00) S TYPE

◀ FILTER UNIT  
(X51-1250-00) V TYPEFINAL UNIT ▶  
(X56-1300-00) V TYPEFINAL UNIT ▶  
(X56-1350-00) S TYPE

## **ADJUSTMENTS**

▼ PLL UNIT (X50-1700-00)



## **TEST AND ALIGNMENT SET-UP**






Fig. 4 7. TX BPF (RX BPF)




**Fig. 5** 8. PLL BPF-A,B,C  
9. VFO MIX spurious (Disconnect Sweep generator and Oscilloscope)

▼ CAR UNIT (X50-1500-00)



## **OUTSIDE VIEW**




## SPECIFICATIONS

- |                               |  |
|-------------------------------|--|
| <b>1. Antenna Coupler</b>     |  |
| Frequency range . . . . .     | 8 amateur bands from<br>3.5 to 29.7 MHz                |
| Input impedance . . . . .     | .50Ω   |
| Output impedance . . . . .    | .20 to 300Ω, unbalanced.                               |
| Through power . . . . .       | .150W max. (3.5 MHz<br>band, 120W)                     |
| Insertion loss . . . . .      | .Less than 0.5dB at<br>optimum match.                  |
| <b>2. SWR Meter</b>           |  |
| Frequency range . . . . .     | .3.5 to 29.7MHz  |
| Max. power . . . . .          | .150W  |
| Measurable range . . . . .    | .1.0:1 to 10:1   |
| Min. power required . . . . . | .2W  |
| <b>3. General</b>             |  |
| INPUT Connector . . . . .     | .UHF type (50Ω)  |
| ANT Connector . . . . .       | .UHF type (50Ω)  |
| GND . . . . .                 | .Wing nut and STUD.                                    |
| Dimensions . . . . .          | H. 60mm (2-3/8")<br>W. 152mm (6")<br>D. 159mm (6-1/4") |
| Weight . . . . .              | .1.6kg (3.5 lbs) approx.                               |


**NOTE:** The circuit and ratings may change without notice due to developments in technology.

## **SCHEMATIC DIAGRAM**



## SCHEMATIC DIAGRAM (V) TYPE

— Signal Line    - - - Control Line    — Common DC line



## AT-130/VFO-120

## AT-130 PARTS LIST

Ref.No.	Parts No.	Description	Remarks
<b>GENERAL</b>			
	A01-0752-08	Case (A)	
	A01-0791-08	Case (B)	☆
	A20-2362-03	Die cast panel	
	A20-2401-08	Panel	(T)
	A20-2402-08	Panel	(K),(W) ☆
	B31-0620-08	Meter	
	B46-0058-00	Warranty card	(K)
	B50-2764-08	Operating manual	(K),(W)
	B50-2765-08	Operating manual	(T) ☆
VC1,2	C02-0014-05	Variable capacitor 250pF 1kV	
C6	CM93B2H250J	MC 25pF 500V	
C7	CM93B2H101J	MC 100pF 500V	
C8	CM93B2H131J	MC 130pF 500V	
C9	CM93B2H151J	MC 150pF 500V	
C10	CM93B2H201J	MC 200pF 500V	
C11	CM93B2H251J	MC 250pF 500V	
C12	CM93B2H431J	MC 430pF 500V	
C13	CM93B2H631J	MC 630pF 500V	
C14	CM93B2H571J	MC 570pF 500V	
C15	CM93B2H951J	MC 950pF 500V	
D23-0061-04		Bearing	
E04-0102-05		UHF type receptacle	
E08-0203-25		2P socket	
E09-0203-25		2P plug	
E23-0015-04		Earth lug	
H01-2726-08		Carton case	(T)
H01-2727-08		Carton case	(K),(W) ☆
H12-0461-08		Cushion	
J02-0069-05		Foot	
J29-0402-08		Angle	
J42-0401-04		Knob bush	
K21-0744-08		Main knob	
K21-0745-08		Knob BAND	
K21-0746-04		Knob CAL	
K27-0406-04		Knob Push	
L3	L34-2003-08	Tuning coil	
L4	L34-2002-08	Tuning coil	
L5,6	L34-0849-08	Coil	
N09-0630-08		Wing screw	
N14-0509-05		Wing nut GND	
N19-0620-08		Nylon washer	
VR1	R05-3406-08	Pot. 20kΩ (B) CAL	
S1	S40-2403-05	Push switch	
S3	S01-5405-08	Rotary switch	Lamp
	X41-1280-00	Detector unit	BAND


Ref.No.	Parts No.	Description	Remarks
<b>DETECTOR UNIT (X41-1280-00)</b>			
C1,2	CM93B2H150J	MC 15pF 500V	
L1,2	L39-0403-08	Pick up coil	☆
D1,2	V11-7763-26	Diode 2-1K261	☆

## VFO-120 SPECIFICATIONS


Oscillator frequency . . . . . 5.50~6.00MHz  
Oscillator circuit . . . . . Clapp  
Output voltage . . . . . 0.2V ±1dB(across 470-ohm load)  
Frequency stability . . . . . Within 100Hz per 30 minutes after 3 minutes warm-up (at room temperature).  
Solid-state complement . . . . . FET : 2  
Transistor : 2  
Diode : 6  
Power source . . . . . From TS-120/TS-130  
Dimensions . . . . . 123(4-7/8)W X 96(3-13/16)H X 235(9-1/4) D mm (inches)  
Weight . . . . . 2.5kg(5.5lbs)

NOTE: The circuit and ratings may change without notice due to developments in technology.


## VFO-120 OUTSIDE VIEW



## SCHEMATIC DIAGRAM



## BLOCK DIAGRAM



## PARTS LIST


Ref.No.	Parts No.	Description	Remarks
<b>GENERAL</b>			
A01-0739-03		Case(A) upper	
A01-0740-03		Case(B) lower	
A20-2341-04		Panel	(T)
A20-2342-04		Panel	(K),(W)
B39-0407-04		Spacer for foot	
B46-0058-00		Warranty card	(K)
B50-2633-10		Operating manual	(K),(W)
B50-2634-10		Operating manual	(T) ☆
E02-0107-05		Diode socket	
E06-0852-05		8P DIN socket	
E30-1623-05		Earth cable	
E30-1628-15		VFO cable	
E31-0482-15		Connector with lead	
G09-0405-05		Spring	
H01-2609-04		Carton case (inside)	(K),(W)
H01-2610-04		Carton case (inside)	(T)
H10-2513-02		Packing fixture (F)	
H10-2514-02		Packing fixture (R)	
H12-0445-04		Cushion	
H20-1407-03		Protective cover	
H25-0117-04		Accessory bag 80X250	

# VFO-120

# SCHEMATIC DIAGRAM

Ref.No.	Parts No.	Description	Remarks
D1	J02-0323-05	Foot	
	J02-0409-04	Assistance foot	
	J61-0019-05	Vinyle tie	
	K23-0721-04	Knob RIT	
	K29-0709-04	Push knob (square)	
	K29-0715-04	Pointer knob FUNCTION	
	N14-0509-05	Wing nut GND	
	N99-0306-04	Hex. head screw (VFO M4X10)	
	V11-7260-66	LED PR2112D RIT	
	X41-1240-00	Switch unit	
	X60-1160-01	VFO ass'y unit	★
<b>SWITCH UNIT (X41-1240-00)</b>			
CJ-1	B30-0818-05	Pilot lamp 12V, 40mA	
CJ-3	E40-0373-05	Mini connect wafer 3P	
CJ-4	E40-0774-05	Mini connect wafer 7P	
	E40-0274-05	Mini connect wafer 2P	
VR1	R01-2404-05	Pot. 5kΩ (B) RIT	
VR2	R12-3025-05	Pot. 10kΩ (B)	
S1	S29-1410-05	Slide rotary switch	
S2	S40-2409-15	Push switch T-F SET	
S3	S40-2404-05	Push switch RIT	
RL1	S51-2408-05	Relay G2V-2	
D1	V11-0219-05	Diode V06B	
Q1	V03-1959-06	2SC1959(Y)	
<b>VFO ASS'Y UNIT (X60-1160-01)</b>			
B01-0621-04	Dial escutcheon		
B08-4301-04	Dial back board		
B10-0620-04	Front glass (A) MAIN-RMT		
B20-0811-04	Dial scale (B) 25K		
B20-0817-04	Dial scale (A) 500K		★
B42-1645-04	Seal bottom		
B42-1671-04	Seal top		
G01-0840-04	Coil spring		
K21-0722-04	Main knob		
N19-0608-04	Washer	Main knob	
X40-1170-00	VFO unit		
X54-1450-00	Indicator unit		

Ref.No.	Parts No.	Description	Remarks
<b>VFO UNIT (X40-1170-00)</b>			
C2	C91-0456-05	C 0.047μF 25V	
C4	CC45RG1H030C	C 3pF ±0.25pF	
C5	CC45PG1H020C	C 2pF ±0.25pF	
C6	C91-0456-05	C 0.047μF 25V	
C7	CC45LG1H151J	C 150pF	
C9	CC45LG1H121J	C 120pF	
C12	CC45LG1H680J	C 68pF	
C13	CC45LG1H220J	C 22pF	
C14	CC45CG1H100D	C 10pF ±0.5pF	
C15,16	CC45LG1H151J	C 150pF	
C17	CC45CH1H020C	C 2pF ±0.25pF	
C18	C91-0456-05	C 0.047μF 25V	
C21	CC45SL1H390J	C 39pF	
C22	CC45CH1H100D	C 10pF ±0.5pF	
C23	CC45SL1H390J	C 39pF	
C24	C91-0456-05	C 0.047μF 25V	
	C02-0019-05	Variable capacitor	★
TC1	C05-0009-15	Ceramic trimmer 6pF	
TC2	C05-0013-15	Ceramic trimmer 20pF	
	D40-0614-05	Dial mechanism ass'y	★
	E40-0574-05	Mini connect wafer 5P	
L1	L32-0628-05	OSC coil	
L2	L33-0025-05	Choke coil 1μH	★
L3	L32-0629-05	OSC coil (C)	
L4	L32-0609-05	OSC coil (B)	
L5	L40-1021-03	Ferri-inductor 1mH	
L6	L40-4711-03	Ferri-inductor 470μH	
L7	L40-1021-03	Ferri-inductor 1mH	
L8	L40-1501-03	Ferri-inductor 15μH	
L9~11	L40-4711-03	Ferri-inductor 470μH	
	R92-0150-05	Short jumper	
Q1,2	V09-0011-05	FET 2SK19(Y)	
Q3	V03-0079-05	TR 2SC460(B)	
Q4	V03-1959-06	TR 2SC1959(Y)	
D1	V11-0414-05	Diode 1S2588	
D2	V11-4161-36	Varicap diode 1SV53A	
<b>INDICATOR UNIT (X54-1450-00)</b>			
D1	V11-3163-16	LED TLY-205 MAIN	
D2	V11-3162-86	LED TLG-205 RMT	




## SCHEMATIC DIAGRAM (S) TYPE

Voltage measurement conditions  
f=14.25MHz, MODE SSB, RX no signal, ( ) : in TX

Signal Line

Control Line

Common DC line



## SPECIFICATIONS

## Power Supply Section

Input voltage . . . . .	AC120V/220V or 220V/240V ±10%
50/60 Hz	
Output voltage . . . . .	DC 13.8V (standard voltage)
Output current . . . . .	20A (intermittent load 50% cuty cycle)
Continuous load current . . . . .	15A max. (inclusive of external output terminal)
Output voltage fluctuation . . . . .	Within ±0.7V at AC 120V, 220V, 240V ±10% (Load current: 15A) Within 0.7V at 2~15A of load current (No-load output voltage: Less than 16V at AC 120V, 220V, 240V)

Ripple voltage . . . . . Less than 20 mV(rms), output current 15A  
 Power consumption . . . . . Approx. 470W at AC 120V, 220V, 240V. (Load current: 20A)

## General

Dimensions . . . . . 180(7" - 1/16")W x 133(5" - 1/4")H x 287(11" - 5/16")D mm (inch)  
 Weight . . . . . Approx. 8.9kg(19.6 lbs.)


NOTE: The circuit and ratings may change without notice due to developments in technology.

## PARTS LIST


\*: New parts

Ref. No.	Parts No.	Description	Remarks
<b>GENERAL</b>			
C1	C90-0813-05	Electrolytic 6800μF 25WV	☆
C2~5	CK45E2H103P	Ceramic 0.01μF +100% -0%	
C6,7	C90-0300-05	Ceramic 470pF AC150WV	
C8	C91-0412-05	Ceramic 4700pF AC500WV	
C9	CK45F1H473Z	Ceramic 0.047μF +80% -20%	
C10	CE04W1E4R7	Electrolytic 4.7μF 25WV	
Q1,2	V08-1012-06	Transistor 2N5885	☆
D1	V11-1365-06	Diode S25VB10	☆
-	V11-7260-56	LED GD4-203S-RD	☆
RL1	S51-1406-05	Relay	☆
-	A01-0746-12	Case (upper)	☆
-	A01-0755-02	Case (Lower)	☆
-	A20-2363-03	Front panel (T)	☆
-	A20-2364-03	Front panel (K.W)	☆
-	A23-1432-02	Rear panel (K)	☆
-	A23-1433-02	Rear panel (W.T)	☆
-	B46-0058-00	Warranty card (K)	
-	B50-2652-10	Operating manual (K.W)	☆
-	B50-2656-00	Operating manual (T)	
-	E20-0282-05	2P Terminal plate	
-	E22-0207-05	Lug plate x 3	
-	E30-0181-05	AC cord with plug (K)	
-	E30-0585-05	AC cord with plug (W)	
-	E30-0602-05	AC cord with plug (T)	
-	E31-0500-05	Power cord with plug	☆
-	F01-0738-03	Heat sink	☆
-	F05-2035-15	Fuse (20A)	☆
-	F05-6021-05	Fuse (6A) x 2 (K)	
-	F05-4022-05	Fuse (4A) x 2 (W.T)	
-	H01-2624-04	Carton case (inside) (K)(W)	☆
-	H01-2625-04	Carton case (inside) (T)	
-	H03-1711-04	Carton case (outside) (T)	
-	H03-1712-04	Carton case (outside) (K)	
-	H03-1726-04	Carton case (outside) (W)	
-	H10-2523-02	Styren foam cushion (F)	☆
-	H10-2524-02	Styren foam cushion (R)	☆
-	H12-0455-04	Cushion	☆


## OUTSIDE VIEWS



## SCHEMATIC DIAGRAM



## OUTSIDE VIEWS



## SCHEMATIC DIAGRAM

